

Bellemave Twin XL Over Queen Bunk Bed

Bellemave Twin XL Over Queen Bunk Bed Instruction Manual

Model: Twin XL Over Queen Bunk Bed

1. INTRODUCTION

Thank you for choosing the Bellemave Twin XL Over Queen Bunk Bed. This bunk bed is designed to provide a durable, functional, and modern sleeping solution with integrated storage shelves and LED lighting. This manual contains important information regarding the assembly, operation, maintenance, and safety of your new bunk bed. Please read it thoroughly before assembly and retain it for future reference.

2. SAFETY INFORMATION

WARNING: Failure to follow these warnings could result in serious injury.

- Do not exceed the weight capacity of **500 lbs** for each bed (upper and bottom).
- Ensure proper assembly to maintain stability and safety. All connections must be securely tightened.
- The top bunk is not suitable for children under 6 years of age.
- Always use the ladder for access to the upper bunk. Do not jump on or off the bunk bed.
- Periodically check all connections and tighten them as necessary.
- Use only mattresses that comply with the recommended thickness: **6 inches for the upper bed and 8 inches for the bottom bed.**
- Ensure that the mattress on the upper bunk is at least 5 inches below the top of the guardrails.
- Do not attach or hang items to any part of the bunk bed that are not designed for use with the bed; for example, but not limited to, hooks, belts, and jump ropes.

3. PARTS LIST AND PRE-ASSEMBLY

Before beginning assembly, ensure all parts are present and undamaged. Refer to the included hardware pack and detailed instructions for a complete list of components. If any parts are missing or damaged, do not proceed with

assembly. Contact customer support for assistance.

The product is shipped in **2 packages**. Please ensure both packages have arrived before starting assembly.

Included Components:

- Metal frame components
- MDF panels for shelves and headboards/footboards
- Ladder
- Guardrails
- LED Strip Light
- Assembly hardware (screws, bolts, nuts, etc.)
- Assembly tools (usually an Allen wrench)

Size: inch



Image 1: Overall dimensions of the Bellemave Twin XL Over Queen Bunk Bed.

4. ASSEMBLY INSTRUCTIONS

Full assembly is required for this bunk bed. It is recommended that **at least two people** participate in the assembly

process to ensure safety and ease of construction. Follow the step-by-step instructions provided in the separate assembly manual included with your product. Ensure all connections are tight before use.

1. **Prepare the Area:** Clear a spacious area for assembly. Lay out all components and hardware.
2. **Assemble the Lower Bed Frame:** Follow the instructions to connect the main frame components for the queen-size lower bed.
3. **Install Lower Bed Slats:** Securely attach the metal slats to the lower bed frame.
4. **Assemble the Upper Bed Frame:** Construct the twin XL upper bed frame, including the guardrails.
5. **Install Upper Bed Slats:** Securely attach the metal slats to the upper bed frame.
6. **Attach Storage Shelves:** Integrate the storage shelves between the upper and lower bunks as per the manual.
7. **Attach Ladder:** Securely fasten the ladder to the designated attachment points.
8. **Install LED Strip Light:** Follow the instructions for attaching and connecting the LED light strip to the designated area on the storage shelf.
9. **Final Check:** Verify that all bolts and screws are tightened. Ensure the bed is stable and level.



Image 2: Fully assembled Bellemave Twin XL Over Queen Bunk Bed.

5. OPERATING INSTRUCTIONS

5.1. Using the LED Lights

The bunk bed features an integrated LED light strip for ambient lighting. To operate the LED lights, locate the power switch or remote control (if included) connected to the LED strip. Turn the lights on or off as desired. Ensure the power adapter is securely plugged into a functional wall outlet.



Image 3: Bunk bed with LED lighting in operation.

5.2. Utilizing Storage Shelves

The bunk bed includes built-in storage shelves on both levels. These shelves are designed to hold books, small decorative items, and other personal belongings. Avoid placing excessively heavy items on the shelves to prevent damage or instability.



Image 4: Close-up view of the storage shelves.

6. MAINTENANCE

- **Cleaning:** Wipe down the metal and MDF surfaces with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners that could damage the finish.
- **Hardware Check:** Periodically inspect all bolts, screws, and connections. Tighten any loose hardware to ensure the bed remains stable and safe. This should be done at least once every three months.
- **LED Lights:** If the LED lights stop working, check the power connection and ensure the adapter is functioning correctly. If issues persist, contact customer support.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Bed squeaks or wobbles	Loose hardware connections. Uneven floor.	Tighten all bolts and screws. Ensure the bed is on a level surface. Consider adding felt pads under legs if the floor is uneven.
LED lights not working	Power connection issue. Faulty LED strip/adapter.	Check if the power adapter is securely plugged in. Ensure the wall outlet is functional. If problem persists, contact customer support.
Lower bed feels unstable	Insufficient support.	Ensure all frame connections are tight. If necessary, additional support legs can be purchased and installed for enhanced stability.

8. SPECIFICATIONS

Feature	Detail
Product Type	Metal Bunk Bed
Size	Twin XL over Queen
Material	Engineered Wood, Metal
Overall Product Dimensions (L x W x H)	83.5" x 63" x 62.6"
Overall Product Weight	136.3 lbs
Weight Capacity (Upper/Bottom Bed)	500 lbs / 500 lbs
Recommended Mattress Thickness (Upper Bed)	6 inches
Recommended Mattress Thickness (Bottom Bed)	8 inches
Number of Packages	2
Assembly Required	Full Assembly Needed
Special Features	Space Saving, Storage Shelves, LED Strip Light, Ladder



Image 5: Detail of the metal slat support system.

9. WARRANTY AND SUPPORT

Bellemave stands behind the quality of its products. While specific warranty details are not provided in this manual, please refer to your purchase documentation or contact Bellemave customer support for information regarding warranty coverage and claims.

For any questions, missing parts, or assistance with assembly or operation, please contact Bellemave customer service. Have your product model and purchase date available when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question