

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [aowoka](#) /

› [aowoka S5-1 Portable Bluetooth Speaker User Manual](#)

**aowoka S5-1**

# aowoka S5-1 Portable Bluetooth Speaker User Manual

Model: S5-1

## 1. INTRODUCTION

Thank you for choosing the aowoka S5-1 Portable Bluetooth Speaker. This manual provides essential information for setting up, operating, and maintaining your speaker to ensure optimal performance and longevity. The S5-1 speaker features HD stereo sound, Bluetooth 5.4 connectivity, TWS pairing capability, IPX7 waterproofing, a long-lasting battery, and dynamic LED lights, making it suitable for various environments.



Image: The aowoka S5-1 Portable Bluetooth Speaker, highlighting its PulseSound technology and suitability for outdoor use.

## 2. PACKAGE CONTENTS

Please check the package for the following items:

- 1 x aowoka S5-1 Portable Bluetooth Speaker
- 1 x Type-C Charging Cable
- 1 x Quick Start Guide

### 3. PRODUCT OVERVIEW

Familiarize yourself with the speaker's components and controls.



Image: Front view of the aowoka S5-1 Portable Bluetooth Speaker, showcasing its design and LED light strip.

#### 3.1 Controls and Ports

## Smart Button Control



Image: Detailed diagram illustrating the smart button controls and various input ports on the aowoka S5-1 speaker.

- **Power Button:** Press and hold for 2 seconds to power on/off. Press and hold for 15 seconds to reset.
- **Volume Down / Previous Track:** Press once for volume down, press and hold for previous track.
- **Play/Pause / Call Control:** Press once to play/pause music or answer/end calls. Press and hold to reject a call.
- **Volume Up / Next Track:** Press once for volume up, press and hold for next track.
- **Light Mode Button:** Press once to cycle through LED light modes. Press and hold to turn lights off.
- **Mode Button:** Press once to switch between Bluetooth, TF card, AUX, and USB input modes.
- **TWS Button:** Press once to initiate TWS pairing. Press and hold to disconnect TWS.
- **Ports:** AUX-IN, TF Card Slot, USB Port, Type-C Charging Port.

## 4. SETUP

### 4.1 Charging the Speaker

1. Connect the provided Type-C charging cable to the speaker's Type-C port.
2. Connect the other end of the cable to a USB power adapter (not included) or a computer's USB port.
3. The charging indicator light will illuminate. It will turn off or change color once fully charged.

A full charge provides over 30 hours of playtime. For optimal battery life, fully charge the speaker before first use.

# 30 Hours of Non-Stop Music

4000mAh high-capacity battery,  
Listen all day on a single charge.



Image: The aowoka S5-1 speaker illustrating its 30-hour battery life capability.

## 4.2 Power On/Off

- **To Power On:** Press and hold the Power Button for 2 seconds. You will hear an audible prompt.
- **To Power Off:** Press and hold the Power Button for 2 seconds. You will hear an audible prompt.

## 4.3 Bluetooth Pairing

1. Ensure the speaker is powered on and in Bluetooth mode (indicated by a flashing blue LED). If not, press the Mode Button to switch to Bluetooth mode.
2. On your device (smartphone, tablet, etc.), enable Bluetooth and search for available devices.
3. Select "aowoka S5-1" from the list of devices.
4. Once connected, the Bluetooth indicator light will turn solid blue, and you will hear a confirmation sound.

## 5. OPERATING INSTRUCTIONS

## 5.1 True Wireless Stereo (TWS) Pairing

To achieve an immersive stereo sound experience, you can pair two aowoka S5-1 speakers together.

1. Ensure both S5-1 speakers are powered on and not connected to any Bluetooth device.
2. On one speaker (this will be the primary speaker), press the TWS Button once. The speaker will enter TWS pairing mode.
3. The two speakers will automatically connect to each other. You will hear a confirmation sound once TWS pairing is successful.
4. Now, connect your device to the primary speaker via Bluetooth as described in section 4.3.

To disconnect TWS, press and hold the TWS Button on either speaker.

## 5.2 Music Playback

- **Play/Pause:** Press the Play/Pause Button once.
- **Volume Up:** Press the Volume Up Button once.
- **Volume Down:** Press the Volume Down Button once.
- **Next Track:** Press and hold the Volume Up Button.
- **Previous Track:** Press and hold the Volume Down Button.

## 5.3 Hands-free Calling

When connected to your phone via Bluetooth:

- **Answer/End Call:** Press the Play/Pause Button once.
- **Reject Call:** Press and hold the Play/Pause Button.

## 5.4 LED Light Modes

The speaker features dynamic RGB lights that sync with your music.

# Dynamic 6-Color Party Illumination

let's enjoy the party



Image: The aowoka S5-1 speaker demonstrating different dynamic 6-color party illumination modes.

- Press the Light Mode Button once to cycle through different light effects (e.g., Starry Sky, Breathing, Flowing, Quick Jump, Rhythm Jump).
- Press and hold the Light Mode Button to turn the LED lights off.

## 5.5 Multiple Input Modes

The speaker supports various audio input sources:



Bluetooth  
5.4



TF  
Karte



AUX  
Kabel



BASS



Type-C



Hands-free  
Calling

Image: The aowoka S5-1 speaker highlighting its multiple connectivity options including Bluetooth 5.4, TF card, AUX cable, Type-C, and Hands-free Calling.

- **Bluetooth:** Connect wirelessly to your device (see section 4.3).
- **TF Card:** Insert a TF (MicroSD) card with MP3 audio files into the TF card slot. The speaker will automatically play music from the card.
- **AUX-IN:** Connect an audio device using a 3.5mm AUX cable (not included) to the AUX-IN port.
- **USB:** Insert a USB flash drive with MP3 audio files into the USB port. The speaker will automatically play music from the drive.

Press the Mode Button to switch between these input sources.

## 5.6 Power Bank Function

The speaker can be used for emergency charging of other devices.

# Be Powerbank

Emergency Charging for Phones



Phone



MP3



Pad



Projector



Image: The aowoka S5-1 speaker demonstrating its capability to act as an emergency power bank for charging phones and other small devices.

- Connect your device's charging cable to the speaker's USB port.
- The speaker will begin charging your device. Note that using this feature will reduce the speaker's playback time.

## 6. MAINTENANCE

### 6.1 Cleaning

- Wipe the speaker with a soft, damp cloth. Do not use abrasive cleaners or solvents.
- Ensure all ports are dry before charging or connecting external devices.

### 6.2 Storage

- Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures.

- If storing for an extended period, charge the battery to approximately 50% every few months to maintain battery health.

## 7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Speaker does not power on	Low battery; Power button not pressed long enough	Charge the speaker; Press and hold the Power Button for 2 seconds.
No sound	Volume too low; Incorrect input mode; Device not connected	Increase volume on speaker and device; Press Mode Button to select correct input; Re-pair Bluetooth device.
Bluetooth pairing fails	Speaker not in pairing mode; Device too far; Interference	Ensure speaker is in Bluetooth mode (flashing LED); Move device closer; Turn off other Bluetooth devices.
TWS pairing fails	Speakers already connected to a device; Speakers too far apart	Disconnect both speakers from any Bluetooth device; Ensure speakers are within 10 meters of each other.
LED lights not working	Lights turned off	Press the Light Mode Button to cycle through modes.

## 8. SPECIFICATIONS



Image: Diagram highlighting key features of the aowoka S5-1 speaker, including audio driver, light show, lanyard, battery life, Bluetooth 5.4, and IPX7 waterproof rating.

Feature	Detail
Model Name	S5-1-YTUS-BK
Speaker Type	Portable Speaker

Feature	Detail
Connectivity Technology	Bluetooth 5.4
Audio Output Power	40W (2 x 20W)
Audio Driver Size	66 mm
Battery Life	Up to 30 hours
Waterproof Rating	IPX7
Product Dimensions	4.09"D x 8.74"W x 4.21"H
Item Weight	2.42 pounds
Input Ports	Bluetooth, TF Card, AUX-IN, USB
Special Features	TWS Pairing, LED Lights, Hands-free Calling, Power Bank Function

## 9. SAFETY INFORMATION

- Do not expose the speaker to extreme temperatures (hot or cold) or direct sunlight for prolonged periods.
- Do not attempt to disassemble, repair, or modify the speaker. This will void the warranty and may cause injury.
- Keep the speaker away from medical devices, as it may interfere with their operation.
- Dispose of the speaker and its battery responsibly according to local regulations. Do not dispose of in fire.
- While the speaker is IPX7 waterproof, avoid prolonged submersion in water or exposure to saltwater. Ensure the charging port cover is securely closed before exposure to water.



**IPX7  
Waterproof**

Image: The aowoka S5-1 speaker partially submerged in water, illustrating its IPX7 waterproof capability.

## **10. WARRANTY AND SUPPORT**

The aowoka S5-1 Portable Bluetooth Speaker comes with a standard manufacturer's warranty. For detailed warranty information, please refer to the warranty card included in your package or contact aowoka customer support.

If you encounter any issues or have questions regarding your speaker, please contact aowoka customer support through the retailer where you purchased the product or visit the official aowoka website for assistance.