

[manuals.plus](#) /› [ROBOTIME](#) /› [ROBOTIME Mud Kitchen \(Model RBT-1-WG426\) Instruction Manual](#)

ROBOTIME RBT-1-WG426

ROBOTIME Mud Kitchen Instruction Manual

Model: RBT-1-WG426

Brand: ROBOTIME

1. INTRODUCTION

Thank you for choosing the ROBOTIME Mud Kitchen. This outdoor play kitchen is designed to provide children aged 3 and up with a versatile and engaging sensory experience, combining pretend cooking, water play, and gardening activities. This manual provides essential information for assembly, safe operation, and maintenance to ensure long-lasting enjoyment.

2. SAFETY INFORMATION

- **Adult Supervision Required:** Always supervise children during play to prevent accidents.
- **Age Recommendation:** Suitable for children aged 3 years and older. Small parts may pose a choking hazard for younger children.
- **Stable Placement:** Ensure the mud kitchen is placed on a flat, stable surface to prevent tipping.
- **Material Safety:** The product is crafted from natural wood with smooth, sanded edges and non-toxic finishes. Regularly inspect for any damage or splinters.
- **Water Play Safety:** Use clean water only. Do not allow children to drink water from the play faucet. Empty the water tank after each use to prevent stagnant water.
- **Tool Use:** Gardening tools are designed for pretend play. Ensure children use them appropriately and safely.
- **Outdoor Use Only:** This product is designed for outdoor use.

3. WHAT'S INCLUDED

The ROBOTIME Mud Kitchen comes with the following components and accessories:

- Wooden Mud Kitchen Frame
- Functional Water Faucet and Sink
- 3 Planting Cups
- 3 Gardening Tools (Rake, Trowel, Hand Spade)
- Pretend Cooking Pots (Stockpot, Frying Pan)

- Side Bins for storage
- Assembly Hardware and Instructions



Figure 3.1: All included accessories for the mud kitchen.

This image displays the various accessories that accompany the mud kitchen, including a stockpot, frying pan, three planting pots, a rake, a trowel, a hand spade, and side bins for organization.

4. ASSEMBLY INSTRUCTIONS

The ROBOTIME Mud Kitchen is designed for straightforward assembly. Follow the step-by-step instructions provided in the separate assembly guide included in the packaging. All parts are clearly labeled, and holes are pre-drilled for convenience.

- Unpack all components and verify against the parts list.
- Ensure you have the necessary tools (a screwdriver may be required, though basic tools are often included).
- Follow the numerical sequence of steps in the assembly guide.
- Tighten all screws securely, but do not overtighten to avoid damaging the wood.

PRODUCT DIMENSION



Suitable
Ages 3+



Figure 4.1: Product dimensions for assembly planning.

This image illustrates the overall dimensions of the mud kitchen, providing a visual reference for its size and helping with space planning during assembly and placement.

5. OPERATING INSTRUCTIONS

The mud kitchen offers various interactive features for imaginative play:

5.1. Water Play

Fill the green water tank with clean water. The functional faucet allows children to wash toys, rinse mud, or transfer water into the sink for sensory experiments. Ensure the sink's drain plug is properly seated to hold water, and remove it to drain.

REALISTIC FAUCET & SINK

Multi-Sensory Outdoor Experience for Kids



Water Playing



Mud Playing



Sand Playing

Figure 5.1: Demonstrating water, mud, and sand play in the sink.

This image highlights the versatility of the sink area, showing how it can be used for water play, mud play, or sand play, encouraging diverse sensory experiences.

5.2. Pretend Cooking Area

The cooktop features realistic clicking knobs that turn, simulating a real kitchen experience. Place the included pots and pans on the burners for imaginative cooking scenarios. The oven door opens for additional storage or pretend baking.

REALISTIC & INTERACTIVE DETAILS

Click!



Cooktop Rotary Switch



Outdoor Home Cooking



Kitchen Storage Area



Sand Dredging Shovel Set of 3

Figure 5.2: Interactive details of the cooktop and storage.

This image provides close-up views of the mud kitchen's interactive elements, such as the cooktop rotary switches, the pretend cooking area, the kitchen storage, and the sand dredging shovel set.

5.3. Gardening and Planting

Use the three planting cups and gardening tools to engage in pretend planting activities. Children can dig in soil, plant small seeds or flowers, and learn about nature. The cups can be placed on the integrated shelf.



Figure 5.3: Engaging in planting activities.

This image shows a child actively participating in planting, demonstrating how the mud kitchen's planting cups and gardening tools facilitate imaginative gardening play.

5.4. Storage

The mud kitchen includes a handy storage shelf and an enclosed cabinet for organizing pots, tools, and other play accessories. Encourage children to put away items after play to maintain tidiness.

Your browser does not support the video tag.

Video 5.1: Overview of the ROBOTIME Outdoor Play Kitchen features.

This video provides a comprehensive overview of the ROBOTIME Outdoor Play Kitchen, showcasing its various features such as the water faucet, cooking area, planting cups, and storage options in action.

6. MAINTENANCE AND CARE

Proper care will extend the life of your ROBOTIME Mud Kitchen:

- **Cleaning:** The smooth wooden surfaces can be wiped clean with a damp cloth. For stubborn dirt, use mild soap and water, then rinse thoroughly. Avoid harsh chemicals.

- **Drying:** After water play or cleaning, allow the mud kitchen to air dry completely to prevent mold or wood damage.
- **Weather Protection:** While designed for outdoor use, prolonged exposure to extreme weather conditions (heavy rain, direct scorching sun, snow) can affect the wood. Consider covering the kitchen or storing it in a sheltered area during harsh weather.
- **Inspection:** Periodically check all screws and connections to ensure they are tight. Inspect the wood for any signs of wear, splinters, or damage. Repair or replace damaged parts as needed.



Figure 6.1: Features of the safe and durable wood construction.

This image emphasizes the quality of the wood used in the mud kitchen, showcasing its smooth edges, distinctive grain, and overall high durability, which contributes to its longevity and safety.

7. TROUBLESHOOTING

If you encounter any issues with your ROBOTIME Mud Kitchen, please refer to the following common solutions:

- **Missing Parts:** If any parts are missing upon unboxing, please contact customer support immediately with your purchase details.
- **Loose Connections:** If the structure feels wobbly, check all screws and tighten them as necessary.
- **Water Faucet Leaking/Not Flowing:** Ensure the water tank is properly seated and filled. Check that the

faucet is securely attached and not damaged.

- **Wood Damage:** For minor scratches or splinters, light sanding may be sufficient. For significant damage, contact customer support for advice on repair or replacement.

8. SPECIFICATIONS

Feature	Detail
Model Number	RBT-1-WG426
Product Dimensions (L x W x H)	33.86 x 13.78 x 33.86 inches (86 x 35 x 86 cm)
Item Weight	22.7 pounds (10.3 kg)
Recommended Age	3 years and up
Material	Natural Wood with non-toxic finishes
Features	Functional water faucet & sink, clicking stove knobs, planting cups, storage cabinet

9. WARRANTY INFORMATION

ROBOTIME products are manufactured to high-quality standards. This product comes with a limited manufacturer's warranty against defects in materials and workmanship. Please refer to the warranty card included in your packaging or visit the official ROBOTIME website for specific terms and conditions. Keep your proof of purchase for warranty claims.

10. CUSTOMER SUPPORT

For any questions, concerns, or assistance with your ROBOTIME Mud Kitchen, please contact our customer support team:

- **Email:** support@robotime.com
- **Website:** www.robotime.com
- Please have your model number (RBT-1-WG426) and purchase date ready when contacting support.