

[manuals.plus](#) /

› [NBD](#) /

› [NBD 5K 64MP Digital Camera Instruction Manual](#)

NBD NBD 5K 64MP

NBD 5K 64MP Digital Camera Instruction Manual

Model: NBD 5K 64MP

1. INTRODUCTION

Thank you for choosing the NBD 5K 64MP Digital Camera. This manual provides essential information for setting up, operating, and maintaining your camera to ensure optimal performance and longevity. Please read this manual thoroughly before using your device.



Image: The NBD 5K 64MP Digital Camera, a compact and versatile device for high-resolution photography and videography.



Image: Overview of the NBD 5K 64MP UHD Digital Camera, highlighting its capabilities for capturing perfect moments.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- NBD 5K 64MP Digital Camera
- 2 x Lithium-Ion Batteries
- Battery Charger
- 32GB TF Card (pre-installed or separate)
- USB Cable
- Wrist Strap
- Lens Cap
- Cleaning Cloth
- User Manual (this document)




Image: A visual representation of the NBD 5K 64MP Digital Camera and its included accessories, such as batteries, charger, TF card, and USB cable.

3. SETUP

3.1. Charging the Battery

1. Insert a battery into the provided battery charger.
2. Connect the charger to a power source using the USB cable.
3. The indicator light on the charger will show the charging status. Charge until fully charged.

3.2. Inserting the Battery and TF Card

1. Open the battery compartment cover on the bottom of the camera.
2. Insert the charged battery according to the polarity indicators.
3. Insert the 32GB TF card into the designated slot until it clicks into place. Ensure the correct orientation.
4. Close the battery compartment cover securely.

3.3. Attaching the Wrist Strap

Thread the wrist strap through the strap lug on the side of the camera to prevent accidental drops.

Video: An unboxing and setup guide for the NBD K200 4K Camera, demonstrating battery and memory card installation.

4. OPERATING THE CAMERA

4.1. Power On/Off

Press and hold the power button located on the top of the camera to turn it on or off.

4.2. Using the Flip Screen

The 3-inch LCD screen can be flipped 180 degrees, making it ideal for selfies and vlogging. Adjust the screen to your desired angle for optimal viewing.




Image: The NBD 5K camera capturing Ultra HD video, showcasing its 180-degree flip screen for versatile shooting angles.

4.3. Capturing Photos and Videos

Use the physical mode dial to select between various shooting modes:

- **Photo Mode:** Capture 64MP high-resolution images. The camera features autofocus for sharp details.
- **Video Mode:** Record stunning 5K videos.
- **Slow Motion:** Capture dramatic slow-motion video sequences.
- **Time-Lapse:** Condense long events into short, captivating videos.
- **Continuous Shooting:** Take multiple photos in quick succession.
- **Self-Timer:** Set a delay before taking a photo, useful for group shots or self-portraits.
- **Loop Recording:** Continuously record video, overwriting older footage when the memory card is full.




Image: The NBD 64MP Digital Camera demonstrating fast and precise autofocus for professional-level photos.



Image: An example of the NBD camera's 18X digital zoom capability, capturing distant subjects with clarity.



Image: A visual guide to the NBD camera's multi-functional modes, including video, time-lapse, continuous shooting, filter mode, macro mode, slow motion, and intelligent scene recognition.

4.4. Using the Flash

The camera features a built-in flash for illuminating subjects in low-light conditions. Press the flash button to activate

or deactivate it, or set it to auto mode.




Image: The NBD camera's anti-shake feature, illustrating how it helps capture clear images even with movement.

4.5. Applying Filters

Enhance your photos and videos with the camera's built-in filters. Navigate through the menu to select from various artistic effects.

Video: A demonstration of the NBD K100 camera's multiple built-in filters for creative photography.

4.6. Wi-Fi Connectivity and Sharing

The camera supports Wi-Fi connectivity for easy transfer of photos and videos to your smartphone or other devices. This allows for quick sharing to social media platforms.

Video: A detailed overview of the NBD 5K Digital Camera, highlighting its Wi-Fi and vlogging capabilities.

4.7. Webcam Mode

Connect the camera to your computer via USB to use it as a high-definition webcam for live streaming or video calls.




Image: The NBD camera functioning in webcam mode, connected to a laptop for online interactions.

5. MAINTENANCE

5.1. Cleaning the Camera

Use the provided cleaning cloth to gently wipe the lens and screen. Avoid using harsh chemicals or abrasive materials that could damage the camera's surfaces.

5.2. Battery Care

Store batteries in a cool, dry place when not in use. Avoid exposing them to extreme temperatures. Fully charge batteries before extended storage and periodically recharge them to maintain their lifespan.

5.3. Storage

When not in use, store the camera in a dry, dust-free environment, preferably in its protective bag, to prevent scratches and damage.

6. TROUBLESHOOTING

- Camera not turning on:** Ensure the battery is fully charged and correctly inserted.
- Poor image quality:** Check that the lens is clean and free from smudges. Ensure adequate lighting for your shot.
- Memory card error:** Reinsert the TF card or try a different compatible card. Ensure the card is not full.
- Wi-Fi connection issues:** Ensure the camera's Wi-Fi is enabled and your device is within range. Refer to the camera's on-screen instructions for connecting to Wi-Fi.
- Camera makes noise:** Some operational sounds are normal. If the noise is excessive or unusual, consult the manufacturer's support.

7. SPECIFICATIONS

Feature	Specification
Photo Sensor Technology	CMOS
Supported File Format	MOV
Brand	NBD
Model Name	NBD
Maximum Webcam Image Resolution	64 MP
Photo Sensor Size	1/2.3-inch
Form Factor	Compact
Effective Still Resolution	64 MP
Special Feature	Compact
Color	Black
Are Batteries Included	Yes
Manufacturer	NBD

File Format	MOV
Connectivity Technology	USB
Screen Size	3 Inches
Display Type	LCD
Sensor Type	CMOS
Photo Sensor Resolution	64 MP
Video Resolution	5K
Battery Weight	28 Grams
Battery Cell Type	Lithium Ion
Number of Batteries	2 Lithium Ion batteries required. (included)

8. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the documentation included with your purchase or visit the official NBD website. Keep your proof of purchase for any warranty claims.