

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [LEGO](#) /

› [LEGO Icons Captain Jack Sparrow's Pirate Ship \(10365\) Instruction Manual](#)

LEGO 10365

LEGO Icons Captain Jack Sparrow's Pirate Ship (10365) Instruction Manual

Model: 10365

INTRODUCTION AND OVERVIEW

Embark on a creative voyage with the LEGO Icons Captain Jack Sparrow's Pirate Ship (10365) building set. This detailed LEGO interpretation of the legendary ghost galleon, The Black Pearl, is designed for adult builders aged 18 and up. The set contains 2,862 pieces and features soaring masts and torn black sails, bringing the iconic ship to life.

The model includes 8 iconic movie character minifigures: Jack Sparrow, Will Turner, Gibbs, Cotton, Anamaria, Marty, Elizabeth Swann, and Hector Barbossa. A figurehead minifigure can be mounted on the bow for added detail.



Image: The fully assembled LEGO Icons Captain Jack Sparrow's Pirate Ship (10365) building set, showcasing its

intricate details and scale.



Image: A close-up of the eight included LEGO minifigures: Jack Sparrow, Will Turner, Gibbs, Cotton, Anamaria, Marty, Elizabeth Swann, and Hector Barbossa.

SETUP AND ASSEMBLY

The assembly process for the LEGO Icons Captain Jack Sparrow's Pirate Ship (10365) is designed to be an engaging experience for adults. The set comes with detailed building instructions. For an enhanced building experience, the LEGO Builder app features a digital version of the instructions with 3D viewing tools.

Carefully open the numbered bags containing the LEGO elements and follow the step-by-step guide. It is recommended to organize pieces by color and type to streamline the building process.



2862



***Pirates of the Caribbean* building kit for adults**

Image: The product box for the LEGO Icons Captain Jack Sparrow's Pirate Ship, highlighting the 2,862 piece count and its adult builder focus.



Image: An adult builder carefully assembling sections of the LEGO Black Pearl ship, demonstrating the detailed

OPERATING FEATURES

The LEGO Icons Captain Jack Sparrow's Pirate Ship (10365) includes several authentic and interactive details:

- **Cannons:** Rotate dials to deploy the port or starboard cannons.
- **Steering:** Turn the ship's wheel to steer the rudder.
- **Captain's Quarters:** Open the deck to reveal the captain's quarters, complete with furnishings, candlesticks, and an apple.
- **Detachable Rowboat:** Place minifigures in the included detachable rowboat.



Image: A detailed view of the ship's hull, showing the dials that can be rotated to deploy the cannons from either side.




Image: The ship's wheel on the main deck, connected to a visible rudder mechanism at the stern, allowing for interactive steering.




Image: The detailed interior of the captain's quarters, accessible by lifting the deck, featuring miniature furnishings and accessories.



Image: The detachable rowboat, capable of holding minifigures, and the green figurehead that attaches to the bow of the ship.

Official Product Videos

Your browser does not support the video tag.

Video: An official overview of the LEGO Icons Captain Jack Sparrow's Pirate Ship (10365), showcasing its assembled form and key features.

Your browser does not support the video tag.

Video: A 360-degree spin of the LEGO Icons Captain Jack Sparrow's Pirate Ship (10365), providing a comprehensive view of the model from all angles.

Your browser does not support the video tag.

Video: A demonstration of a remote control version of the 10365 model, showcasing potential lighting and movement modifications.

MAINTENANCE

To ensure the longevity and appearance of your LEGO Icons Captain Jack Sparrow's Pirate Ship (10365), follow these maintenance guidelines:

- **Cleaning:** Dust the model regularly with a soft brush or compressed air. For deeper cleaning, gently wipe with a damp cloth and mild soap, then rinse and air dry. Avoid harsh chemicals.
- **Storage:** Store the model in a cool, dry place away from direct sunlight to prevent discoloration and warping of plastic elements.
- **Handling:** Handle the model with care, especially when moving it, to prevent pieces from detaching.

TROUBLESHOOTING

If you encounter any issues during or after assembly, consider the following:

- **Missing Pieces:** In the rare event of missing pieces, contact LEGO Customer Service directly through their official website. They typically provide replacement parts free of charge.
- **Assembly Errors:** Refer to the digital instructions in the LEGO Builder app for 3D viewing tools that can help identify and correct assembly mistakes.
- **Stability Issues:** Ensure all connections are firmly pressed together. If displaying the model, use the provided stand for stability.

SPECIFICATIONS

Attribute	Detail
Product Dimensions	14.88 x 21.85 x 6.18 inches
Item Weight	9.18 pounds
ASIN	B0FMS97LGV
Item Model Number	10365
Manufacturer Recommended Age	18 years and up
Release Date	January 1, 2026
Manufacturer	LEGO
Number of Pieces	2,862

WARRANTY AND SUPPORT

LEGO products are manufactured to high-quality standards. For any issues related to product defects, missing parts, or general inquiries, please visit the official LEGO customer service website or contact their support line. Information regarding specific warranty details can be found on the LEGO website or within the product packaging.

For further assistance, you may visit the [LEGO Store on Amazon](#).

© 2026 LEGO Group. All rights reserved.