

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

- > [Diydeg](#) /
- > [Diydeg 4G LTE Mobile Hotspot User Manual](#)

Diydeg Diydeghebi7gopvf

Diydeg 4G LTE Mobile Hotspot User Manual

Model: Diydeghebi7gopvf

1. INTRODUCTION

Thank you for choosing the Diydeg 4G LTE Mobile Hotspot. This portable device provides high-speed 3G/4G internet access, allowing you to connect up to 10 devices simultaneously. Its compact design makes it ideal for travel, business, and home use. This manual will guide you through the setup, operation, and maintenance of your mobile hotspot.




Image: The Diydeg 4G LTE Mobile Hotspot providing internet connectivity to a user's laptop.

2. PRODUCT OVERVIEW

2.1 Key Features

- **High-Speed 4G LTE Connectivity:** Provides fast internet access for various online activities.
- **Multi-User Support:** Connects up to 10 WiFi-enabled devices simultaneously.
- **Long-Lasting Battery:** Equipped with a 2100mAh battery for extended standby time (up to 10 hours).
- **Portable Design:** Lightweight, thin, and compact for easy carrying.
- **Wide Compatibility:** Works with mobile phones, laptops, desktops, and tablets.
- **LED Smart Display:** Easy-to-read display for operational status.

2.2 Package Contents

Please check the package for the following items:

- Diydeg 4G LTE Mobile Hotspot Device
- Rechargeable Battery
- USB Charging Cable
- User Manual (this document)



Image: The Diydeg Mobile Hotspot device shown alongside its USB charging cable.

3. SETUP INSTRUCTIONS

3.1 Installing the SIM Card and Battery

1. Carefully remove the back cover of the mobile hotspot device.
2. Insert your micro SIM card into the designated SIM card slot. Ensure the card is oriented correctly according to the diagram inside the device.
3. Take out the battery and locate the yellow insulation tape. Gently tear off this insulation tape from the battery terminals.
4. Insert the battery into the battery compartment, ensuring the contacts align properly.
5. Replace the back cover until it clicks securely into place.



Image: A three-step visual guide showing how to remove the battery, peel off the insulation tape, and insert the battery into the device.

3.2 Powering On the Device

Press and hold the power button (usually located on the side) for a few seconds until the LED display illuminates. The device will begin searching for a network signal.



Image: Side view of the Diydeg Mobile Hotspot, highlighting the power button location.

4. OPERATING INSTRUCTIONS

4.1 Connecting to the WiFi Network

1. Ensure your mobile hotspot is powered on and has established a network connection (indicated by the signal strength icon on the display).
2. On your WiFi-enabled device (phone, laptop, tablet), open the WiFi settings.
3. Look for the network name (SSID) displayed on your hotspot's screen or on a sticker inside the battery compartment.
4. Select the hotspot's SSID from the list of available networks.
5. Enter the WiFi password (Key) displayed on the hotspot's screen or sticker.

6. Your device should now be connected to the internet.



Image: A user working on a laptop, connected to the Diydeg Mobile Hotspot for internet access.

4.2 Charging the Device

Connect the provided USB charging cable to the hotspot's charging port and plug the other end into a USB power adapter or a computer's USB port. The battery indicator on the display will show charging status.

4.3 Powering Off the Device

Press and hold the power button for a few seconds until the LED display turns off, indicating the device has shut down.

5. MAINTENANCE

- Keep the device dry and away from moisture.
- Avoid extreme temperatures.
- Clean the device with a soft, dry cloth. Do not use liquid cleaners.
- Do not attempt to disassemble or repair the device yourself.
- For optimal battery life, avoid fully discharging the battery frequently.

6. TROUBLESHOOTING

6.1 No Network Signal

- Ensure the SIM card is correctly inserted and activated.
- Check if you are in an area with 3G/4G network coverage.
- Restart the device.
- Verify that your SIM card plan supports data usage.

6.2 Cannot Connect to WiFi

- Confirm the WiFi password (Key) is entered correctly.
- Ensure the hotspot is powered on and broadcasting its WiFi signal.
- Check if too many devices are already connected (maximum 10).
- Restart both the hotspot and the device you are trying to connect.

6.3 Slow Internet Speed

- Move to an area with better network signal strength.
- Reduce the number of connected devices.
- Check your data plan for any speed limitations or data caps.
- Restart the device.

7. SPECIFICATIONS

Feature	Specification
Model Number	Diydeghebi7gopvf
Battery Capacity	2100mAh
Max WiFi Users	10
Wireless Connection Speed	Up to 150Mbps
Item Weight	3.88 ounces
Package Dimensions	4.33 x 3.15 x 1.57 inches
Manufacturer	Diydeg

Note: Specifications are subject to change without prior notice.

8. WARRANTY AND SUPPORT

Diydeg is committed to providing quality products and customer satisfaction. This product comes with:

- **12-Hour Response:** Our support team aims to respond to inquiries within 12 hours.
- **365-Day Limited Warranty:** Covers manufacturing defects for one year from the date of purchase.
- **Lifelong Unlimited Technical Support:** Assistance with product usage and troubleshooting for the lifetime of the product.

For technical support or warranty claims, please contact Diydeg customer service through your purchase platform or visit our official website.

