

[Manuals.plus](#) /

› [Catry](#) /

› Catry Trinity 5-Level Cat Tree Instruction Manual (Model CT240359)

Catry CT240359

Catry Trinity 5-Level Cat Tree Instruction Manual

Model: CT240359

1. INTRODUCTION

This manual provides detailed instructions for the assembly, operation, maintenance, and troubleshooting of your Catry Trinity 5-Level Cat Tree. This multi-level cat tree is designed to offer a comprehensive activity center for cats of all life stages, featuring recycled paper scratching posts, laminated wood surfaces, washable plush beds, an integrated massager, and interactive toys.





The Catry Trinity 5-Level Cat Tree, showcasing its multi-tiered design, scratching posts, and a comfortable top perch.

2. SAFETY INSTRUCTIONS

- Always place the cat tree on a flat, stable surface to prevent tipping.
- Ensure all components are securely fastened during assembly and periodically check for loose parts.
- Keep small children away from the cat tree during assembly to avoid choking hazards from small parts.
- Do not allow children to climb or play on the cat tree. It is designed for feline use only.
- Inspect the cat tree regularly for any damage or wear, especially to scratching posts and toys. Replace worn parts promptly.
- This product is intended for indoor use only.

3. COMPONENTS LIST

Before assembly, verify that all parts are present and undamaged. Refer to the included hardware and parts list in your product packaging for specific identifiers.

- Laminated Wood Base
- Laminated Wood Platforms (various sizes)
- Plush Cushions/Beds (washable)
- Recycled Paper Rope Scratching Posts
- Support Posts (wood/laminated)
- Base Condo/House
- Integrated Massager
- Interactive Toys (rotating clip-on, interchangeable)
- Assembly Hardware (screws, bolts, Allen wrench)

4. ASSEMBLY INSTRUCTIONS

Assembly of the Catry Trinity Cat Tree is designed to be straightforward and typically takes under 30 minutes. Follow the step-by-step instructions provided in your product packaging, utilizing the labeled hardware for ease of installation.

General Assembly Steps:

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Compare them against the components list to ensure everything is present.
2. **Attach Base Components:** Begin by attaching the lowest support posts and the base condo to the main laminated wood base. Ensure all connections are tight.
3. **Build Upwards:** Progressively attach platforms and scratching posts, working your way up the structure. Each level should be securely fastened before proceeding to the next.
4. **Install Plush Beds and Toys:** Place the washable plush cushions onto the designated platforms and inside the condo. Attach the rotating and interchangeable toys as indicated in the specific manual.
5. **Final Check:** Once fully assembled, gently shake the cat tree to ensure stability. Tighten any loose connections. Consider using the included wall anchor for added stability, especially in multi-cat households or with active cats.





Detailed view of the Catry Trinity Cat Tree with its overall dimensions, indicating a height of 66.3 inches and a base of 22x22 inches.

5. OPERATING INSTRUCTIONS (USING THE CAT TREE)

The Catry Trinity Cat Tree provides multiple zones for your cat's natural behaviors and comfort.

- **Scratching Posts:** Encourage your cat to use the five recycled paper rope scratching posts to maintain claw health and protect your furniture.
- **Plush Beds & Platforms:** The various levels and plush-padded platforms offer comfortable spots for resting, napping, and observing surroundings.
- **Base Condo:** The enclosed base condo provides a secure and private space for your cat to hide, sleep, or feel safe.
- **Interactive Toys:** The rotating clip-on toy and interchangeable toy are designed to engage your cat in playful activity, promoting exercise and mental stimulation.
- **Integrated Massager:** The built-in massager offers a unique texture for your cat to rub against, providing soothing relief and relaxation.



An illustrative diagram of the Catry Trinity Cat Tree, pointing out its functional areas designed for a cat's diverse activities such as sleeping, playing, climbing, scratching, massaging, and resting.



A closer look at the integrated massager, providing soothing relief, and the interactive toy designed for stimulating play.

6. MAINTENANCE AND CARE

- **Cleaning Plush Beds:** The plush cushions are washable. Remove them from the platforms and follow the care instructions on their labels for cleaning. Allow them to air dry completely before reattaching.
- **Cleaning Surfaces:** Wipe laminated wood surfaces with a damp cloth and mild cleaner as needed. Avoid harsh chemicals that could damage the finish.
- **Scratching Post Replacement:** The recycled paper rope scratching posts are designed to be replaceable after heavy use. Refer to the warranty section for replacement part information.
- **General Inspection:** Periodically check all screws and bolts to ensure they remain tight. Inspect the entire structure for any signs of wear, tear, or damage.
- **Indoor Use:** To prolong the life of the product, keep the cat tree indoors and away from direct sunlight or moisture.

7. TROUBLESHOOTING

Problem	Possible Cause	Solution
Cat tree feels unstable or wobbly.	Loose connections; uneven floor; heavy cat activity.	Ensure all screws and bolts are tightened. Place on a level surface. Utilize the included wall anchor for added stability.
Missing or damaged part during assembly.	Manufacturing defect; shipping damage.	Contact Catry customer support immediately with your purchase details for replacement parts. Refer to the warranty section.
Cat not using scratching posts.	Preference for other surfaces; unfamiliarity.	Gently guide your cat's paws to the posts. Use catnip spray on the posts to attract your cat.
Toys are damaged or detached.	Normal wear and tear from play.	Replace damaged toys. Ensure toys are securely attached to their designated points.

8. SPECIFICATIONS

Feature	Detail
Model Name	TRINITY
Item Model Number	CT240359
Product Dimensions (LxWxH)	22" x 22" x 66.3" (55.9 cm x 55.9 cm x 168.4 cm)

Feature	Detail
Item Weight	51.4 Pounds (23.3 kg)
Material	Laminated Wood, Paper Rope, Plush
Color	Brown
Number of Levels	5
Target Audience	Cats, house-cats (All Life Stages, All Breed Sizes)
Included Components	Cat Tower (with condo, scratching posts, beds, toys, massager)

9. WARRANTY AND SUPPORT

Warranty Information:

Catry offers a **90-day replacement parts policy** for orders placed within 3 months of purchase. Lifetime replacements for certain parts may also be available. For detailed instructions and to claim replacement parts, please visit the official Catry website or contact customer support.

Customer Support:

For any questions, concerns, or assistance with your Catry Trinity Cat Tree, please contact Catry customer service. Refer to your product packaging or the official Catry website for current contact information.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question