

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

Manuals.plus /

> [YHNNH](#) /

> YHNNH K-1028E Universal Air Conditioner Remote Control Instruction Manual

## YHNNH K-1028E

# YHNNH K-1028E Universal Air Conditioner Remote Control

## INSTRUCTION MANUAL

### 1. Introduction

This manual provides detailed instructions for the setup, operation, and maintenance of your YHNNH K-1028E Universal Air Conditioner Remote Control. This remote is designed to control a wide range of air conditioning units, offering convenient and efficient temperature management.





Figure 1: Front view of the K-1028E Universal A/C Remote Control, showing the display and various control buttons.

The K-1028E features soft keys for comfortable use, quick response times for immediate command execution, and a strong signal for reliable communication with your air conditioner. Its design prioritizes simple operation with clear font on the display and is constructed from durable ABS material.



Figure 2: Key features of the K-1028E remote, including soft keys, quick response, and strong signal transmission.



Figure 3: Design aspects of the K-1028E remote, emphasizing simple operation, clear display font, and durable ABS material construction.

## 2. Setup

---

The YHNNH K-1028E Universal Air Conditioner Remote Control is designed for immediate use without complex programming. Simply install batteries to begin operation.

### 2.1 Battery Installation

1. Open the battery compartment cover located on the back of the remote control.
2. Insert two AAA batteries, ensuring correct polarity (+ and -). Batteries are not included with the product and must be purchased separately.
3. Close the battery compartment cover securely.



## Easy To Use

Work right out of the box,  
no programming or setup needed,  
All you have to do is open the  
back cover and install two AAA  
batteries.

(Batteries need to be prepared by yourself.  
This product does not provide batteries)

Figure 4: Rear view of the K-1028E remote with the battery compartment open, illustrating where to insert two AAA batteries.

Once batteries are installed, the remote is ready for use with most air conditioners without requiring any additional setup or code input.

## 3. Operating Instructions

The K-1028E remote control provides comprehensive functionality for managing your air conditioner. Familiarize yourself with the buttons and their functions:

### 3.1 Button Functions

- **ON/OFF:** Powers the air conditioner on or off.
- **MODE:** Cycles through operating modes (e.g., Cool, Heat, Fan, Dry, Auto).
- **TEMP ▲/▼:** Adjusts the temperature setting up or down.
- **WIND:** Adjusts fan speed or airflow intensity.
- **LIGHT:** Controls the display light on the remote or the air conditioner unit (if supported).
- **M.SWING:** Activates or adjusts manual swing of the air conditioner's louvers.
- **A.SWING:** Activates or adjusts automatic swing of the air conditioner's louvers.

- **TIME ON:** Sets a timer for the air conditioner to turn on automatically.
- **TIME OFF:** Sets a timer for the air conditioner to turn off automatically.
- **F.Cool:** Activates a fast cooling function (if supported by the A/C unit).
- **F.Heat:** Activates a fast heating function (if supported by the A/C unit).
- **SET:** Used for entering or confirming settings, often in conjunction with other buttons for advanced functions.
- **CLOCK:** Sets the current time on the remote's display.
- **OK:** Confirms selections or settings.

### 3.2 Basic Operation

1. **Power On/Off:** Press the **ON/OFF** button to turn your air conditioner on or off.
2. **Adjusting Temperature:** Use the **TEMP ▲** or **TEMP ▼** buttons to increase or decrease the desired temperature.
3. **Changing Mode:** Press the **MODE** button repeatedly to cycle through available operating modes (e.g., Cool, Heat, Fan).
4. **Setting Fan Speed:** Press the **WIND** button to adjust the fan speed.

### 3.3 Timer Functions

The remote allows you to set timers for automatic operation, contributing to energy saving management.

- **TIME ON:** To set a turn-on timer, press **TIME ON**, then use **TEMP ▲/▼** to adjust the desired time, and press **OK** to confirm.
- **TIME OFF:** To set a turn-off timer, press **TIME OFF**, then use **TEMP ▲/▼** to adjust the desired time, and press **OK** to confirm.

## 4. Compatibility

---

The YHNNH K-1028E is a universal remote control designed to be compatible with most air conditioners available on the market. It supports various types of units, including:

- Cabinet type air conditioners
- Cylindrical air conditioners
- Wall-mounted air conditioners
- Single cold (cooling-only) units
- Ceiling type air conditioners
- Window type air conditioners

# MOST AIR CONDITIONERS ON THE MARKET CAN BE USED



Cabinet type



Cylindrical



Wall-mounted



Single cold



Ceiling type



Window type

Figure 5: Visual representation of different air conditioner types compatible with the K-1028E universal remote.

This remote offers direct use with most models, requiring no complex setting procedures after battery installation.

# APPLICABLE TO MOST AIR CONDITIONERS IN THE MARKET

► Direct use

► No setting required



Figure 6: The K-1028E remote emphasizing its direct usability and lack of required setup for broad compatibility.

## 5. Maintenance

### 5.1 Battery Replacement

When the remote control's display becomes dim or its response slows, it is time to replace the batteries. Follow the battery installation steps in Section 2.1.

- Always replace both AAA batteries at the same time.
- Do not mix old and new batteries, or different types of batteries.
- Remove batteries if the remote will not be used for an extended period to prevent leakage.

### 5.2 Cleaning

To clean the remote control, gently wipe its surface with a soft, dry cloth. Do not use liquid cleaners, abrasive pads, or chemical solvents, as these may damage the remote's finish or internal components.

## 6. Troubleshooting

- Remote not responding:

- Check if the batteries are correctly inserted with the right polarity.
  - Replace old batteries with new AAA batteries.
  - Ensure there are no obstructions between the remote and the air conditioner's receiver.
  - Confirm the remote is pointed directly at the air conditioner.
- **Air conditioner not responding to specific functions:**
    - Some advanced functions (e.g., F.Cool, F.Heat, specific swing modes) may not be supported by all air conditioner models. Refer to your air conditioner's manual for its specific features.
  - **Display is dim or blank:**
    - Replace the batteries.

## 7. Specifications

Feature	Specification
Model	K-1028E
Brand	YHNNH
Wireless Communication	IR (Infrared)
Use	Air Conditioner
Power Source	2 x AAA Batteries (not included)
Item Weight	1.76 ounces
Package Dimensions	0.39 x 0.39 x 0.39 inches (approximate)
Material	ABS

## 8. Warranty and Support

For warranty information or technical support, please refer to the documentation provided with your purchase or contact the seller directly. The manufacturer, YHNNH, can be reached through their official channels for product-specific inquiries.

You can visit the YHNNH Store for more information: [YHNNH Store on Amazon](#).