

[Manuals.plus](#) /

› [MRSVI](#) /

› MRSVI V8 2.4GHz & Bluetooth Dual-Mode Mini Keyboard with Touchpad User Manual

MRSVI V8

MRSVI V8 2.4GHz & Bluetooth Dual-Mode Mini Keyboard with Touchpad User Manual

Model: V8 | Brand: MRSVI

INTRODUCTION

This manual provides comprehensive instructions for the MRSVI V8 2.4GHz & Bluetooth Dual-Mode Mini Keyboard with Touchpad. Please read this manual carefully before use to ensure proper operation and to maximize the product's lifespan. Keep this manual for future reference.



Image 1: MRSVI V8 Mini Keyboard with Touchpad. This image displays the full layout of the mini keyboard, including the QWERTY keys, touchpad, and multimedia control buttons, with ergonomic grips on the sides.

PACKAGE CONTENTS

- MRSVI V8 Mini Keyboard with Touchpad
- USB Charging Cable
- 2.4GHz USB Receiver (stored in battery compartment)
- User Manual



Image 2: MRSVI V8 Mini Keyboard and its packaging. The image shows the keyboard alongside its retail box, indicating the product's presentation.

PRODUCT FEATURES

Connect Simply, Do More.



Image 3: Overview of MRSVI V8 product features and compatibility. This graphic highlights key features like Bluetooth 5.0, 2.4GHz connectivity, adjustable backlight, USB Plug and Play, multi-system compatibility, touchpad, full QWERTY keyboard, compact design, 15-meter connection range, adjustable DPI, comfortable feel, and low power consumption. It also illustrates compatibility with various devices such as projectors, TV boxes, mobile phones, smart TVs, desktops, notebooks, and recreational machines.

- **Dual Wireless Connectivity:** Supports both Bluetooth 5.0 and 2.4GHz RF for versatile connection options.
- **Integrated Touchpad:** QWERTY keyboard with a built-in touchpad, including left and right click buttons and multi-finger gesture support.
- **7-Color Backlight:** Adjustable backlight for use in low-light conditions.
- **Rechargeable Battery:** Built-in Li-ion battery with an auto-sleep function for extended use.
- **Wide Compatibility:** Compatible with Android TV Boxes, Smart TVs, PS3, PCs, tablets, and more.
- **Portable Design:** Compact and lightweight for easy handling and transport.

SETUP AND CONNECTION

1. Charging the Keyboard

Before initial use, fully charge the keyboard. Connect the provided USB charging cable to the keyboard's charging port and the other end to a USB power source (e.g., computer USB port, USB wall adapter). The charging indicator LED will light up red during charging and turn off when fully charged.



Image 4: MRSVI V8 Mini Keyboard showing the USB charging port. A USB cable is connected to the port, illustrating the charging process.

2. Powering On/Off

Locate the power switch on the side of the keyboard. Slide it to the "ON" position to power on the device. Slide it to "OFF" to power off.

3. Connecting via 2.4GHz Wireless

1. Locate the 2.4GHz USB receiver. It is typically stored in the battery compartment of the keyboard.
2. Insert the USB receiver into an available USB port on your device (e.g., Smart TV, PC, Android TV Box).
3. Turn on the keyboard. The keyboard should automatically connect to the receiver. The yellow LED indicator will flash slowly if not connected, and turn off when a connection is established.
4. If connection is not established, press **Fn + F1** simultaneously to select 2.4GHz mode.

4. Connecting via Bluetooth

1. Ensure the keyboard is powered on.
2. Press **Fn + F3** simultaneously to enter Bluetooth pairing mode. The yellow LED indicator will flash quickly.
3. On your device (e.g., smartphone, tablet, Smart TV), navigate to the Bluetooth settings and enable Bluetooth.
4. Search for available devices. The keyboard should appear as "MRSVI Keyboard" or similar.
5. Select the keyboard to pair. Once paired, the yellow LED indicator will turn off.
6. *Note: For Amazon Fire TV Stick, Bluetooth mode is recommended. For 2.4GHz mode, an OTG adapter may be required.*

OPERATING INSTRUCTIONS

Keyboard Layout and Basic Functions

The MRSVI V8 features a full QWERTY keyboard layout with an integrated touchpad.

Everything, Refined



Image 5: Detailed view of the MRSVI V8 Mini Keyboard, highlighting its QWERTY layout, integrated touchpad, and dual connectivity options (Bluetooth and 2.4GHz). Dimensions are also shown.

Touchpad Operation

- **Single Finger Tap:** Left mouse click.
- **Two Finger Tap:** Right mouse click.
- **Two Finger Drag:** Scroll up/down.
- **Three Finger Tap:** Simulates a middle mouse click (if supported by the device).
- **Left/Right Click Buttons:** Dedicated buttons are located below the touchpad for left and right clicks.
- To turn off/on the touchpad, press **Fn + F8**.

Backlight Control

The keyboard features a 7-color adjustable backlight.

- Press **Fn + F2** repeatedly to cycle through the 7 backlight colors.
- Continue pressing **Fn + F2** to turn off the backlight.

Multi-color Backlit

Type in the Dark – 7-Color Backlight Knows Your Needs



Quick-Color Switching: Press Fn + F2 to Cycle 7 Colors

Image 6: The MRSVI V8 Mini Keyboard displaying its 7-color backlight feature. The image shows the keyboard illuminated with various colors, demonstrating the adjustable lighting options.

Multimedia and Shortcut Keys

The keyboard includes dedicated multimedia keys and function key shortcuts for enhanced control.



Work Anywhere, Type Everywhere.



Image 7: A visual guide to the shortcut keys on the MRSVI V8 Mini Keyboard. This image details combinations like Fn + mouse sensitivity adjustment, Fn + Enter for Task Manager, Fn + F7 for Print Screen, Fn + F8 for touchpad toggle, Fn + F9 for maximizing current page, Fn + F10 for opening development tools, and navigation keys like Fn + Home/PgUp/PgDn/End. It also notes that some functions may vary by device or application.

- **Multimedia Controls:** Dedicated buttons for volume up/down, mute, play/pause, next/previous track are located above the touchpad.
- **Fn + Mouse Sensitivity:** Adjusts the touchpad sensitivity.
- **Fn + Enter:** Task Manager shortcut (Windows).
- **Fn + F7:** Print Screen shortcut.
- **Fn + F9:** Maximize current page.
- **Fn + F10:** Open development tools.
- **Fn + Home/PgUp/PgDn/End:** Navigation shortcuts for text.
- **F1:** Repair key (used at factory, refer to product manual for details).

Note: Some features and shortcut keys may not be supported on all devices or applications. Functionality depends on the connected device's operating system and capabilities.

MAINTENANCE

- **Cleaning:** Use a soft, dry cloth to clean the keyboard surface. For stubborn dirt, a slightly damp cloth can be used, ensuring no liquid enters the device.
- **Storage:** Store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures.
- **Battery Care:** To prolong battery life, avoid fully discharging the battery frequently. Charge the keyboard regularly, even if not in constant use.
- **USB Receiver:** When not in use, store the 2.4GHz USB receiver in its designated compartment within the keyboard to prevent loss.

TROUBLESHOOTING

- **Keyboard not responding:**
 - Ensure the keyboard is powered on.
 - Check battery level and charge if necessary.
 - For 2.4GHz mode, ensure the USB receiver is properly inserted and try a different USB port. Re-pair by pressing **Fn + F1**.
 - For Bluetooth mode, ensure Bluetooth is enabled on your device and the keyboard is paired. Re-pair by pressing **Fn + F3**.
 - Restart the connected device.
- **Touchpad not working:**
 - Ensure the touchpad is not disabled. Press **Fn + F8** to toggle it on/off.
 - Some devices may have limited touchpad functionality. Verify device compatibility.
- **Backlight not working or changing colors:**
 - Press **Fn + F2** repeatedly to cycle through colors and ensure it's not turned off.
 - Check battery level. Low battery might affect backlight functionality.
- **Short connection range or intermittent connection:**
 - Ensure there are no obstructions between the keyboard and the receiver/device.
 - Avoid using the keyboard near strong interference sources (e.g., Wi-Fi routers, other wireless devices).
 - Move closer to the connected device.

SPECIFICATIONS

Model	V8
Connectivity	2.4GHz Wireless (USB-A receiver), Bluetooth 5.0
Keyboard Layout	QWERTY
Special Features	7-Color Backlight, Integrated Touchpad, Multimedia Hotkeys
Battery Type	Built-in Rechargeable Li-ion Battery
Compatible Devices	Android TV Box, Smart TV, Projector, PS3, PC, Tablet, Laptop
Operating Systems	Windows, iOS, Android
Dimensions	7.72 x 4.21 x 1.02 inches (approx.)
Weight	4.2 ounces (approx.)
Manufacturer	Shenzhen Wuxiandian Technology Co. , Ltd.
UPC	794969894823

WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided with your purchase or visit the official MRSVI website. Keep your proof of purchase for warranty claims.

Note: No specific warranty duration or support contact information was provided in the product data. Please consult the

seller or manufacturer for details.

IMPORTANT NOTES

- Some features may not be supported on all devices or applications.
- Touchpad functionality depends on the connected device's capabilities.
- Verify your device's compatibility before purchase and use.

© 2025 MRSVI. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question