

[Manuals.plus](#) /

› [Lamshaw](#) /

› Lamshaw Screen Protector for AGXOV P20 4.02 Inches MP3 Player User Manual

Lamshaw AGXOV P20

Lamshaw Screen Protector for AGXOV P20 4.02 Inches MP3 Player User Manual

INTRODUCTION

This manual provides detailed instructions for the installation and maintenance of your Lamshaw TPU Screen Protector, designed specifically for the AGXOV P20 4.02 Inches MP3 Player. This protector offers full coverage, anti-scratch properties, and maintains original touch sensitivity.




This image displays the Lamshaw TPU Screen Protector packaging alongside an AGXOV MP3 Player with the screen protector partially applied, illustrating the product and its intended use.

PACKAGE CONTENTS

Verify that all items listed below are included in your package:

- 6 x Screen Protectors
- 1 x Squeegee
- 1 x Microfiber Cloth
- 3 x Alcohol Cleaning Wipes (Wet & Dry)



This diagram illustrates the items included in the package: screen protectors, squeegee, microfiber cloth, and alcohol cleaning wipes. Below, a four-step visual guide demonstrates the screen protector application process.

PRODUCT FEATURES

- **Soft TPU Material:** Crafted from premium thermoplastic polyurethane (TPU), this film offers durability and flexibility, conforming to your screen's curvature.
- **Anti-Scratch & Self-Healing Protection:** Guards against daily wear, scratches, and minor scuffs. A self-healing coating smooths out imperfections over time.
- **Crystal-Clear HD Clarity:** Ensures uncompromised touch sensitivity and vibrant visuals with high transparency.
- **Oleophobic Coating:** Resists fingerprints and smudges, keeping your screen clean.

Special Oleophobic Coating

Keep clean and clear against smudges and oil residue



Water droplets bead up on a screen, illustrating the oleophobic coating's ability to repel liquids and resist smudges.

Original Touch Response

Responds quickly without any lag or mistake




A finger touches a screen protected by the film, highlighting the protector's ability to maintain original touch sensitivity and responsiveness.

Automatic Repair

The self-healing technology constantly eliminates minor scratches and bubbles within 24hrs.



This image depicts two devices, symbolizing the screen protector's automatic repair capabilities that help eliminate minor scratches and bubbles over time.



A screen protector is shown resisting damage from a sharp object, demonstrating its anti-scratch and protective qualities.

INSTALLATION GUIDE

Follow these steps carefully for optimal application of your screen protector. Ensure you are in a dust-free environment.

Easy Installation

Please watch our online video
before your installation



A hand is shown carefully peeling off a protective layer from a screen protector during the installation process, demonstrating a key step in applying the film.

1. **Clean the Screen:** Use the provided alcohol cleaning wipes (first 'Wet' then 'Dry') to thoroughly clean the MP3 player screen. Use the microfiber cloth to remove any remaining dust or smudges. Ensure the screen is completely dry and free of particles.
2. **Prepare the Protector:** The screen protector has three layers. Carefully peel off the red-labeled 'Back 1' layer. This exposes the adhesive side that will attach to your device.
3. **Align and Apply:** Carefully align the screen protector with the edges of your MP3 player's screen. Once aligned, gently lay it down, allowing the adhesive to make contact.
4. **Remove Bubbles:** Use the squeegee to gently push out any air bubbles from the center towards the edges.
5. **Remove Top Layer:** Finally, peel off the black-labeled 'Front 2' layer. The middle layer is the actual screen protector that remains on your device.
6. **Final Polish:** Use the microfiber cloth to gently wipe the newly applied screen protector.

Important Note: If you accidentally peel off the 'Front 2' layer first, the adhesive side may not be exposed correctly. In this case, gently wrinkle the 'Back 1' layer to separate it into two layers, then peel off the middle layer and re-align it with the 'Front 2' side before attempting installation again.

MAINTENANCE

To ensure the longevity and clarity of your screen protector:

- Clean the screen protector regularly with a soft, lint-free cloth.
- For stubborn smudges, lightly dampen the cloth with water or a screen-safe cleaner.
- Avoid using harsh chemicals or abrasive materials, as these can damage the oleophobic coating and the protector itself.

TROUBLESHOOTING

- **Bubbles After Installation:** Small bubbles are common immediately after application. Use the squeegee to push them towards the edges. For very small bubbles, the self-healing property of the TPU material may cause them to disappear naturally within 24-48 hours.
- **Dust Under the Protector:** If a bubble is caused by a dust particle, gently lift the nearest edge of the protector using a piece of tape. Use another piece of tape or a dust-absorber sticker to carefully lift the dust particle from the screen or the adhesive side of the protector. Reapply the protector slowly.
- **Protector Not Sticking:** Ensure the screen was thoroughly cleaned and dry before application. If the 'Back 1' layer was not fully removed, or if the wrong layer was peeled first, the adhesive may not be exposed correctly. Refer to step 2 and the important note in the Installation Guide.

SPECIFICATIONS

Feature	Detail
Brand	Lamshaw
Compatible Device	AGXOV P20 4.02 Inches MP3 Player
Material	Thermoplastic Polyurethane (TPU)
Item Hardness	6H
Special Features	Anti-Shatter, Anti-Scratch, Self-Healing, Oleophobic Coating, High Transparency
Finish Type	Clear
Product Dimensions	0.5"L x 0.5"W (Note: These are general package dimensions, not the protector itself)
Item Weight	1.76 ounces

WARRANTY AND SUPPORT

For any questions, concerns, or warranty claims regarding your Lamshaw Screen Protector, please contact the seller directly through your purchase platform. Please retain your proof of purchase for warranty validation.

