

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [aiprotabket](#) /

› [aiprotabket Kids Tablet C30 User Manual - 10 inch Android 15 Tablet](#)

## aiprotabket C30

# aiprotabket Kids Tablet C30 User Manual

Model: C30

## 1. INTRODUCTION

---

This manual provides essential information for setting up, operating, and maintaining your aiprotabket Kids Tablet C30. Designed for children aged 6-12, this 10-inch Android 15 tablet offers a secure and engaging environment for learning and entertainment. Please read this manual thoroughly before using the device.

## 2. WHAT'S IN THE BOX

---

Upon opening the package, ensure all items are present:

- aiprotabket Kids Tablet C30
- Protective Case
- USB-C Charging Cable



Android 15



Octa-Core



10.1 inch



24(4+20)GB  
64GB



6000mAh



**64GB large storage space, store more without pressure, Max to 24RAM**

Image: The aiprotab Kids Tablet C30, highlighting its core features including Android 15, Octa-Core processor, 10.1-inch display, 24GB RAM + 64GB ROM, and 6000mAh battery capacity.

### 3. PRODUCT OVERVIEW

Familiarize yourself with the tablet's physical components:

- **Display:** 10.1-inch IPS HD screen (1280 x 800 pixels) with eye protection technology.
- **Front Camera:** Located above the screen.
- **Rear Camera:** Located on the back of the tablet.
- **Power Button:** On/off and screen lock.
- **Volume Controls:** Adjust audio levels.
- **Headphone Jack:** 3.5mm port for wired headphones.
- **MicroSD Card Slot:** For expandable storage up to 1TB.
- **USB-C Port:** For charging and data transfer.
- **Speakers:** Integrated for audio output.



## Parental Controls Peace of mind for parents

Set screen time limits, educational goals, block websites, approve app purchases and downloads, and pause the device right from your phone.

Image: The aiprotabket Kids Tablet C30, showcasing its design and key features such as dual cameras, eye protection, and parental controls.

## 4. SETUP

1. **Initial Charge:** Before first use, fully charge the tablet using the provided USB-C cable and a compatible power adapter.
2. **Power On:** Press and hold the Power Button until the aiprotabket logo appears.
3. **Language & Region:** Follow the on-screen prompts to select your preferred language and region.
4. **Wi-Fi Connection:** Connect to a stable Wi-Fi network to enable internet access and download necessary updates.
5. **Google Account:** Sign in with an existing Google account or create a new one. This is required for accessing Google Play Store and other Google services.
6. **Google Kids Space Setup:** Follow the prompts to set up Google Kids Space, which includes creating a child profile and configuring parental controls.

## 5. OPERATING THE TABLET

### 5.1 Android 15 Interface

The tablet runs on Android 15, offering a user-friendly interface. Swipe down from the top of the screen to access quick settings and notifications. Swipe up from the bottom to access the app drawer.

### 5.2 Google Kids Space

Google Kids Space is pre-installed, providing a curated library of books, videos, games, and apps suitable for children. Content is categorized by age and interest to foster curiosity and learning.

# Google Kids Space

Google Kids Space, pre-installed on our tablets, provides books, videos, games, and apps for children to explore and learn.




Image: The Google Kids Space interface, demonstrating how content is organized to match children's age and interests.

## 5.3 Parental Controls

The tablet features robust parental control options to ensure a safe digital environment for your child. Access these settings to:

- Set daily usage time limits.
- Manage app download permissions.
- Filter internet browsing content.
- View learning reports and progress.



## Android 15 System

Simple to operate, offering greater personalization and seamless integration of entertainment and learning.



Latest Android 15



24(4+20)GB RAM  
64GB ROM



Easy Parental Control



Octa-core CPU



Bluetooth 5.0



10.1 inch  
1280\*800



Wifi 5



6000mAh  
Battery




Image: The Parental Control dashboard, illustrating features like content filtering, child lock, and time limits for managing your child's tablet usage.

## 6. KEY FEATURES & SPECIFICATIONS

Feature	Specification
Operating System	Android 15
Processor	Octa-Core (Unisoc 1.6 GHz)
RAM	24GB (4GB Physical + 20GB Virtual)



## Customize personalized virtual character designs

From skin tone to clothing and hairstyles, create uniquely personalized virtual characters and explore diversity.




Image: Details of the shockproof EVA protective case, emphasizing its durability and functional design.

## 8. TROUBLESHOOTING

- **Tablet Not Turning On:** Ensure the battery is charged. Connect the tablet to a power source and try again.
- **Screen Unresponsive:** Perform a forced restart by holding the power button for approximately 10-15 seconds.
- **Wi-Fi Connection Issues:** Check your router and ensure the tablet is within range. Restart both the tablet and your Wi-Fi router.
- **Apps Crashing/Freezing:** Clear the app's cache or reinstall the app. If the issue persists, consider a factory reset (backup data first).
- **Slow Performance:** Close unnecessary background apps. Consider removing unused apps or files to free up storage space.

## 9. WARRANTY & SUPPORT

The aiprotatable Kids Tablet C30 comes with a 90-day free exchange policy. Additionally, lifetime technical support is provided for this product. For any technical assistance or warranty claims, please contact aiprotatable customer service.