

Bellemave FST00225-TC-AK1

Bellemave Twin Size Floor Bed Frame with Roof

Model: FST00225-TC-AK1

INTRODUCTION

This manual provides detailed instructions for the assembly, use, and maintenance of your Bellemave Twin Size Floor Bed Frame with Roof. Please read all instructions carefully before assembly and use to ensure safe and proper operation.

Safety Information

Always supervise children while they are using this bed. Be cautious of sharp edges during assembly and use. Do not exceed the maximum weight capacity of 350 pounds. Ensure the bed is properly assembled to prevent instability or collapse.

- Ensure all bolts and screws are securely tightened before use.
- Regularly check all connections to ensure they remain tight.
- Do not allow children to jump on the bed.
- Keep small parts away from children during assembly.
- Use only the mattress size specified for this bed frame (Twin).

PRODUCT OVERVIEW

The Bellemave Twin Size Floor Bed Frame is designed to provide a comfortable and engaging sleeping environment for children. Its unique house-shaped roof structure offers a distinct aesthetic, while the low-to-the-ground design promotes independence and minimizes fall risks.



Image: The Bellemave Twin Size Floor Bed Frame with Roof, shown in a child's room with pink bedding and decor.

Key Features:

- **House-Shaped Roof:** Creates a unique and engaging space for sleeping and play.
- **Durable Metal Construction:** Made from high-quality iron for long-lasting durability and stability.
- **Floor-Level Design:** Minimizes fall hazards and encourages child independence.
- **Integrated Slats:** Provides mattress support and ensures proper air circulation.
- **High Load Capacity:** Supports up to 350 pounds.
- **Quiet Operation:** Designed to prevent squeaking for an undisturbed sleep.

ASSEMBLY INSTRUCTIONS

Assembly is required for this bed frame. Please follow these steps carefully. It is recommended to have two adults for assembly.

Required Tools (Not Included):

- Phillips head screwdriver
- Allen wrench (usually included with hardware, but a personal set can be helpful)

Package Contents:

Verify all parts are present before beginning assembly. Refer to the included parts list for identification.




Image: An angled view of the disassembled Bellemave Twin Size Floor Bed Frame components, showing the metal frame pieces and slats.

Step-by-Step Assembly:

1. **Unpack and Identify Parts:** Carefully remove all components from the packaging. Lay them out on a clean, soft surface (like a carpet) to prevent scratches. Identify each part using the provided parts list.
2. **Assemble Side Rails:** Attach the side rails to the headboard and footboard sections using the provided bolts and nuts. Ensure all connections are finger-tight before fully tightening.
3. **Attach Roof Structure:** Connect the roof support beams to the top of the headboard and footboard sections. Secure with the appropriate hardware.
4. **Install Slats:** Place the metal slats onto the designated support points on the side rails. Secure each slat as instructed in the detailed assembly guide. Ensure slats are evenly spaced and firmly attached.
5. **Final Tightening:** Once all components are in place, systematically tighten all bolts and screws using the provided Allen wrench and screwdriver. Do not overtighten.
6. **Inspect:** Before use, thoroughly inspect the assembled bed frame to ensure all parts are secure and stable.

For detailed diagrams and specific hardware identification, please refer to the separate assembly instruction sheet included in your product packaging.

OPERATING INSTRUCTIONS

The Bellemave Twin Size Floor Bed Frame is designed for use with a standard twin-size mattress. Its low profile allows for easy access for children, promoting independence.

Usage Guidelines:

- **Mattress Placement:** Place a twin-size mattress directly onto the installed slats. Ensure the mattress fits snugly within the frame.
- **Weight Limit:** Do not exceed the maximum weight capacity of 350 pounds. This includes the weight of the mattress and any occupants.
- **Supervision:** Always supervise young children when they are using the bed, especially during play.
- **Decorations:** The roof structure can be decorated with lightweight fabrics or lights. Ensure any decorations are securely attached and do not pose a choking or strangulation hazard. Avoid heavy or sharp objects.
- **Ventilation:** The slatted design ensures proper mattress ventilation. Do not block the space beneath the bed frame.

MAINTENANCE

Regular maintenance will help prolong the life and ensure the safety of your Bellemave bed frame.

Cleaning:

- Wipe the metal frame with a soft, damp cloth.
- Avoid using harsh chemicals, abrasive cleaners, or polishes, as these can damage the finish.
- Dry immediately with a clean, dry cloth to prevent water spots or rust.

Inspection:

- Periodically check all bolts, screws, and connections to ensure they are tight. Retighten if necessary.
- Inspect the metal frame for any signs of damage, bending, or rust. If damage is found, discontinue use and contact customer support.
- Ensure all slats are securely in place and not bent or broken.

TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|---------|----------------|----------|
|---------|----------------|----------|

| Problem | Possible Cause | Solution |
|----------------------------------|--|---|
| Bed frame is wobbly or unstable. | Loose bolts or incorrect assembly. | Ensure all bolts and screws are fully tightened. Review assembly instructions to confirm correct installation of all parts. |
| Squeaking noises. | Loose connections or friction between metal parts. | Tighten all bolts. Apply a small amount of silicone lubricant to connection points if squeaking persists. |
| Missing parts during assembly. | Packaging error or lost part. | Carefully check all packaging materials. Contact Bellemave customer support with your model number and a description of the missing part. |
| Mattress does not fit. | Incorrect mattress size. | This bed frame is designed for a standard Twin size mattress. Verify your mattress dimensions. |

SPECIFICATIONS

UNIT INCH




Image: Detailed dimension diagram for the Bellemave Twin Size Floor Bed Frame, showing length, width, and height measurements.

| Feature | Detail |
|---------|--------|
|---------|--------|

| Feature | Detail |
|--------------------------------|-------------------------------------|
| Model Number | FST00225-TC-AK1 |
| Size | Twin |
| Material | Metal |
| Product Dimensions (L x W x H) | 77.6" x 40.5" x 57.1" |
| Item Weight | 20 Pounds |
| Maximum Weight Recommendation | 350 Pounds |
| Color | White |
| Assembly Required | Yes |
| Included Components | Bed Frame, Slats, Assembly Hardware |

WARRANTY INFORMATION

Specific warranty details for the Bellemave Twin Size Floor Bed Frame are typically provided with your purchase documentation. Please refer to the warranty card or contact Bellemave customer support for information regarding warranty coverage, terms, and conditions. Keep your proof of purchase for any warranty claims.

CUSTOMER SUPPORT

If you have any questions, require assistance with assembly, or need to report missing/damaged parts, please contact Bellemave customer support.

Manufacturer: Bellemave

Please refer to your product packaging or the Bellemave official website for the most current contact information (phone number, email, or support portal).