

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Mxnsewr](#) /

› [Mxnsewr CY168 Mattress Vacuum Cleaner User Manual](#)

## Mxnsewr CY168

# Mxnsewr CY168 Mattress Vacuum Cleaner User Manual

Model: CY168

Brand: Mxnsewr

## 1. INTRODUCTION

---

Thank you for choosing the Mxnsewr CY168 Mattress Vacuum Cleaner. This manual provides essential information for the safe and effective operation, maintenance, and troubleshooting of your new appliance. Please read this manual thoroughly before first use and retain it for future reference.

The Mxnsewr CY168 is designed for deep cleaning mattresses, sofas, carpets, and other fabric surfaces, utilizing powerful suction, UV-C light, ultrasonic technology, and heat to remove dust, allergens, and mites.

## 2. SAFETY INSTRUCTIONS

---

- Always ensure the power cord is undamaged before use. Do not operate the appliance with a damaged cord or plug.
- Do not immerse the appliance in water or other liquids.
- Keep the appliance away from heat sources and flammable materials.
- Do not use the appliance on wet surfaces or to pick up liquids.
- The UV-C light is equipped with a gravity sensor and will automatically turn off if the device is tilted or lifted to prevent direct exposure. Avoid looking directly at the UV-C light when it is active.
- This appliance is for household use only. Do not use it for commercial or industrial purposes.
- Unplug the appliance from the power outlet before cleaning or performing any maintenance.
- Keep out of reach of children. This appliance is not intended for use by persons with reduced physical, sensory, or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.

## 3. PRODUCT OVERVIEW

---

The Mxnsewr CY168 Mattress Vacuum Cleaner integrates multiple cleaning technologies for comprehensive fabric care.



Image 3.1: Mxnsewr CY168 Mattress Vacuum Cleaner, showcasing its compact design and transparent dust collection system.

### Key Features:

- **Powerful Suction:** Equipped with a 500W high-power motor providing up to 18Kpa suction force.
- **UV-C Light:** 253.7nm UV-C light for deep sanitization, with gravity sensor for safety.
- **Ultrasonic Technology:** Assists in dislodging tiny allergens and mites.
- **150°F Heat:** Generates hot air to aid in cleaning, moisture removal, and odor reduction.
- **Dual Dust Cups & HEPA Filtration:** Advanced HEPA filter captures 99.97% of fine particles. Dual dust cup design prevents clogging and extends filter life.
- **Side-Retractable Roller Brush:** High-frequency brushing for deep cleaning, easily removable for maintenance.
- **Intelligent Detection:** LED display screen shows dust and impurity levels, and monitors motor temperature.
- **Two Suction Levels:** Adjustable suction power for various cleaning needs.
- **Long Power Cord:** 16.4 feet (5 meters) power cord for extended reach.
- **Fragrance Container:** Integrated container for optional fragrance sticks to freshen the cleaned area.

# 18000PA

## Powerful Suction



**500W**  
Stable Power



**253.7nm**  
UV-C wavelength



**150°F**  
Hot Air Drying



**16.4 feet**  
power cord



**Ultrasonic**  
dust removal



**Smart Mite**  
Detection



**0.5L large dust**  
collection cup




Image 3.2: Visual representation of the Mxsewr CY168's core features including 18Kpa suction, UV-C light, 150°F heat, ultrasonic dust removal, and smart mite detection.

## 4. SETUP

1. **Unpack the Appliance:** Carefully remove the mattress vacuum cleaner and all accessories from the packaging.
2. **Inspect for Damage:** Check the appliance for any signs of damage during transit. Do not use if damaged.
3. **Connect to Power:** Unwind the 16.4ft power cord and plug it into a suitable electrical outlet. Ensure the voltage matches the appliance's requirements.
4. **Optional Fragrance:** If desired, open the fragrance container located on the top of the unit and insert a fragrance stick.

## 5. OPERATING INSTRUCTIONS

### 5.1 Power On/Off

- To turn on the vacuum cleaner, press the power button located on the handle.

- To turn off the vacuum cleaner, press the power button again.

## 5.2 Suction Level Adjustment

- The appliance features two suction levels. Press the suction adjustment button on the handle to switch between the two modes (e.g., standard and strong).
- Select the appropriate suction level based on the cleaning task and surface type.

## 5.3 UV-C Light and Ultrasonic Function

- The UV-C light and ultrasonic functions activate automatically when the vacuum cleaner is in contact with a flat surface.
- A built-in gravity sensor ensures the UV-C light turns off if the unit is lifted or tilted more than 30 degrees, preventing accidental exposure.
- Move the vacuum cleaner slowly and steadily over the surface to allow the UV-C light and ultrasonic waves to effectively sanitize and dislodge particles.



Image 5.1: Illustration of the 253.7nm UV-C light and ultrasonic technology in action, showing how the gravity sensor ensures safe operation by deactivating the UV-C light when lifted.

## 5.4 150°F Heat Function

- The 150°F heat function helps to dry and further sanitize the cleaned surface, removing moisture and

odors.

- This function operates concurrently with the vacuuming process.



Image 5.2: Depiction of the 150°F hot air and ultrasonic waves working together for enhanced cleaning and drying.

### 5.5 Intelligent Detection Display

- The LED display screen provides real-time information on the amount of dust and impurities detected in the cleaning area.
- It also monitors the motor temperature for optimal performance and safety.

### 5.6 Recommended Uses

- **Mattresses:** Ideal for deep cleaning and sanitizing mattresses to reduce allergens and dust mites.
- **Sofas & Upholstery:** Effective for cleaning fabric sofas, chairs, and other upholstered furniture.
- **Carpets & Rugs:** Can be used for surface cleaning of low-pile carpets and rugs.
- **Cribs & Pet Beds:** Suitable for cleaning delicate fabrics and pet sleeping areas.

# MULTI-FUNCTION DEEP CLEANING



Image 5.3: The Mxnsewr CY168 being used for multi-function deep cleaning on various surfaces including beds, cribs, carpets, and sofas.

## 5.7 Official Product Video

Video 5.4: An official product video demonstrating the Mxnsewr Mattress Vacuum Cleaner in use, highlighting its features and effectiveness.

## 6. MAINTENANCE

Regular maintenance ensures optimal performance and extends the lifespan of your Mxnsewr CY168.

### 6.1 Emptying the Dust Cups

1. Ensure the vacuum cleaner is turned off and unplugged.
2. Locate the one-click ash discharge button, typically at the bottom of the dust cup assembly.
3. Press the button to release the dust cup.
4. Empty the contents into a trash bin.
5. Reattach the dust cup securely until it clicks into place.

# MAGNETIC SUCTION SIDE-DISCHARGE BRUSH

Easy to disassemble and install,  
and easy to clean.



Image 6.1: Demonstrates the one-click ash removal feature and the option to add fragrance sheets to the unit.

## 6.2 Cleaning the HEPA Filter and Dual Dust Cups

The Mxnsewr CY168 features a multi-layer filtration system with dual dust cups and a HEPA filter.

1. After emptying the dust cups, separate the components as shown in the diagram.
2. Gently tap the HEPA filter to dislodge trapped dust. If necessary, rinse the filter under cool running water. Ensure it is completely dry before reassembling.
3. Wash the dust cups and other filter components with water. Allow all parts to air dry completely before reassembly.
4. Reassemble the filtration system in reverse order of disassembly.

# MULTI-LAYER FILTRATION



Image 6.2: Exploded view of the multi-layer filtration system, including the stainless steel filter, HEPA filter, double cyclone filtration, dust filtering cup, and 0.5L large dust collection cup.

## 6.3 Cleaning the Roller Brush

1. Ensure the vacuum cleaner is turned off and unplugged.
2. The roller brush is designed for easy removal from the side. Gently pull the roller brush out from its housing.
3. Remove any tangled hair, fibers, or debris from the brush using scissors or a cleaning tool.
4. Wipe the brush and its housing with a damp cloth.
5. Reinsert the roller brush until it locks securely into place.

## 7. TROUBLESHOOTING

If you encounter issues with your Mxsewr CY168, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Appliance does not turn on	Not plugged in; Power outage; Damaged power cord	Check power connection; Verify power outlet; Contact customer support if cord is damaged.
Reduced suction power	Dust cups full; Filter clogged; Roller brush obstructed	Empty dust cups; Clean HEPA filter; Remove obstructions from roller brush.
UV-C light not working	Appliance not in contact with surface; Gravity sensor activated	Ensure the vacuum is flat on the surface; Check if the unit is tilted.
Unusual noise during operation	Obstruction in brush roll or suction path; Loose parts	Inspect and clear any obstructions; Check for loose components.

If the problem persists after attempting these solutions, please contact Mxnsewr customer support.

## 8. SPECIFICATIONS

Feature	Detail
Brand	Mxnsewr
Model Name	CY168
Special Feature	Compact
Filter Type	HEPA Filter
Is Cordless?	No
Capacity	0.5 Liters
Recommended Uses	Mattress, Sofa, Carpet
Form Factor	Handheld
Color	Gray
Product Dimensions	11.6"L x 7.6"W x 7.6"H
Manufacturer	Mxnsewr-cmy
Number of Items	1
Number of Speeds	2
Portable	Yes
Number of Power Levels	2
Indoor/Outdoor Usage	Indoor
Vacuum Collection Technology	Rotating Brush Roll
UPC	756407828333

Feature	Detail
Item Weight	5.46 pounds
ASIN	B0FMY8P4ML
Batteries required	No

## 9. WARRANTY AND SUPPORT

---

For warranty information or technical support, please refer to the product packaging or contact Mxnsewr customer service directly. Keep your purchase receipt as proof of purchase for any warranty claims.