

Pinmoco G700514FP-BLKG-2

Pinmoco Electric Fireplace TV Stand with RGB LED Lights - Instruction Manual

Model: G700514FP-BLKG-2

1. INTRODUCTION

Thank you for purchasing the Pinmoco Electric Fireplace TV Stand with RGB LED Lights. This manual provides essential information for the safe assembly, operation, and maintenance of your new entertainment center. Please read all instructions carefully before beginning assembly and retain this manual for future reference.

Important Safety Information

- Always follow basic safety precautions to reduce the risk of fire, electric shock, and injury to persons.
- Do not operate the electric fireplace if the cord or plug is damaged, or if the heater has malfunctioned or been dropped.
- Keep combustible materials, such as furniture, pillows, bedding, papers, clothes, and curtains at least 3 feet (0.9 m) from the front of the heater.
- Ensure the TV stand is placed on a stable, level surface.
- Do not overload the electrical outlet.
- This product is intended for indoor use only.

2. PACKAGE CONTENTS

Before assembly, please ensure all components are present and undamaged. If any parts are missing or damaged, do not proceed with assembly. Contact customer support for assistance.

- TV Stand Panels (various sizes)
- Electric Fireplace Insert
- RGB LED Light Strips and Controller

- Assembly Hardware (screws, dowels, cam locks, etc.)
- Assembly Tools (e.g., Allen wrench)
- Instruction Manual (this document)

3. SPECIFICATIONS

Brand	Pinmoco
Model Name	G700514FP-BLKG-2
Material	Metal, Wood Composite
Color	Black
Product Dimensions	55.12 x 15.75 x 24.8 inches (L x W x H)
Item Weight	73.6 pounds
Maximum TV Size Supported	Up to 65 inches

4. SETUP AND ASSEMBLY

Assembly typically requires two adults. Follow the step-by-step instructions provided in the separate assembly guide included with your product. Ensure all connections are secure before placing any items on the stand or operating the fireplace.

Product Dimensions and Capacity

Refer to the diagram below for detailed dimensions and weight capacities to ensure proper placement and use.

Product Size




Image Description: This diagram illustrates the overall dimensions of the TV stand: 55.12 inches wide, 15.75 inches deep, and 24.8 inches high. It also indicates the maximum TV size supported (up to 65 inches) and weight capacities for different sections of the stand, including 100 lbs for the top surface, 30 lbs for the upper shelves, and 40 lbs for the lower shelves. All measurements are in inches.

Assembly Options

The TV stand offers flexible assembly options for the central compartment, allowing you to install the electric fireplace or utilize it as an open storage shelf.

TWO ASSEMBLY OPTIONS FOR YOU TO SELECT



AMPLE STORAGE SPACE

Image Description: This image demonstrates two possible configurations for the TV stand. The top configuration shows the electric fireplace installed in the central compartment, providing warmth and ambiance. The bottom configuration shows an alternative setup where the central compartment is used as an open storage shelf, allowing for flexible use of the space for media devices or decorative items.

5. OPERATING INSTRUCTIONS

Electric Fireplace Operation

1. **Power On/Off:** Plug the fireplace into a standard 120V AC outlet. Press the power button on the fireplace unit or remote control to turn it on or off.
2. **Flame Effect:** The flame effect can be operated independently of the heat function. Use the flame button to adjust brightness or turn off the flame effect.
3. **Heat Settings:** Use the heat button to cycle through different heat levels (e.g., low, high) or to turn the heater off. The thermostat may allow setting a desired room temperature.
4. **Timer Function:** If available, use the timer button to set an automatic shut-off time for the fireplace.

RGB LED Lights Operation

1. **Connect:** Ensure the RGB LED light strips are properly connected to the controller and power source as

per the assembly guide.

2. **Power On/Off:** Use the provided remote control or button on the controller to turn the LED lights on or off.
3. **Color Selection:** Select desired colors using the color buttons on the remote control.
4. **Brightness Adjustment:** Adjust the brightness of the lights using the designated buttons.
5. **Mode Selection:** Cycle through various lighting modes (e.g., static, flash, fade, strobe) using the mode buttons.

6. MAINTENANCE AND CARE

Cleaning

- **TV Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Electric Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Use a soft, dry cloth to clean the exterior. Do not spray water directly onto the unit.
- **LED Lights:** Gently wipe the LED strips with a dry cloth if dusty.

General Care

- Regularly check all screws and connections to ensure they remain tight.
- Avoid exposing the stand to direct sunlight or extreme temperature changes to prevent warping or fading.
- Do not place hot items directly on the surface without protection.

7. TROUBLESHOOTING

- **Fireplace not turning on:** Check if the power cord is securely plugged into a working outlet. Ensure the main power switch on the fireplace unit is in the 'ON' position. Check the circuit breaker.
- **No heat from fireplace:** Verify that the heat function is activated and not just the flame effect. Ensure the thermostat setting is higher than the current room temperature.
- **LED lights not working:** Check the connection between the LED strips, controller, and power adapter. Ensure the remote control batteries are functional.
- **Stand feels unstable:** Re-check all assembly hardware to ensure screws and cam locks are fully tightened. Ensure the stand is on a level surface.

8. WARRANTY AND SUPPORT

Pinmoco products are manufactured to high-quality standards. For specific warranty details, please refer to the documentation included with your purchase or contact Pinmoco customer support. If you encounter any issues or have questions regarding your Electric Fireplace TV Stand, please contact our customer service team for assistance.

Customer Support: Please refer to your purchase receipt or the Pinmoco official website for contact information.

