Manuals+
☰

VIZIO VQD75M-0804

VIZIO 75" 4K QLED Smart TV Instruction Manual

Model: VQD75M-0804

1. Introduction

This instruction manual provides essential information for the safe and efficient use of your VIZIO 75" 4K QLED Smart TV, Model VQD75M-0804. Please read this manual thoroughly before operating the television and retain it for future reference.




Figure 1.1: Front view of the VIZIO 75" 4K QLED Smart TV.

2. Setup

2.1 Unpacking

Carefully remove the television from its packaging. Ensure all components are present:

- VIZIO 75" 4K QLED Smart TV
- Remote Control

- Power Cable
- TV Stands (2) and Screws
- Documentation (this manual, quick start guide)

Inspect the TV for any damage incurred during shipping. Contact your retailer immediately if any damage is found.

2.2 Stand Installation

If placing the TV on a flat surface, attach the included stands. Place the TV face down on a soft, clean surface to prevent screen damage. Align each stand with the corresponding slots on the bottom of the TV and secure them with the provided screws.



Figure 2.1: Side profile of the TV with stands attached.

2.3 Wall Mounting (Optional)

For wall mounting, use a VESA-compatible wall mount kit (sold separately). Refer to the wall mount kit's instructions for proper installation. Ensure the wall can support the weight of the television.

2.4 Connecting Devices

Connect external devices such as Blu-ray players, gaming consoles, or sound systems to the TV's input ports. The TV features 3 HDMI 2.1 ports, an optical digital audio output, and an antenna input.



Figure 2.2: Side panel input ports.



Figure 2.3: Rear view of the TV, indicating port locations.

2.5 Initial Power On and Setup Wizard

After connecting the power cable and any external devices, press the power button on the remote control. The TV will guide you through an initial setup wizard to configure language, network connection (WiFi 6), and channel scanning.

3. Operating the TV

3.1 Remote Control

The included remote control allows you to navigate the TV's interface, adjust settings, and access smart features. Insert 2 AAA batteries (not included) into the remote control.

3.2 Smart TV Features (VIZIO OS)

Your VIZIO Smart TV runs on VIZIO OS, providing access to a variety of streaming applications and content. Navigate using the remote control to browse apps like Netflix, Prime Video, and YouTube. WatchFree+ offers over 250 live channels.




Figure 3.1: VIZIO OS home screen.

3.3 Picture Settings

The TV features Quantum Color technology for vibrant colors and supports premium HDR formats including Dolby Vision, HDR10+, HDR10, and HLG. Access the picture settings menu to adjust brightness, contrast, color, and select picture modes for optimal viewing.

3.4 Sound Settings

Adjust audio settings such as volume, sound mode, and balance through the TV's audio menu. The TV includes built-in speakers.

3.5 Gaming Features

With HDMI 2.1 ports, Variable Refresh Rate (VRR), and support for up to 120fps at 1080p, this TV is optimized for gaming. Ensure your gaming console is connected to an HDMI 2.1 port for the best experience.

3.6 Voice Assistants

The TV is compatible with Alexa, Google Assistant, and Apple Homekit, allowing for voice control of certain functions. Refer to the respective voice assistant's setup instructions for integration.

3.7 Connectivity

The TV supports WiFi 6 for fast and stable wireless internet connections and Bluetooth 5.2 for connecting wireless audio devices or other peripherals.

4. Maintenance

4.1 Cleaning the TV

To clean the screen, gently wipe it with a soft, dry, lint-free cloth. For stubborn marks, lightly dampen the cloth with water. Avoid using harsh chemicals or abrasive cleaners. Clean the TV frame with a soft, dry cloth.

4.2 Software Updates

The TV may receive automatic software updates via its internet connection. Ensure the TV is connected to the internet to receive the latest features and performance improvements.

5. Troubleshooting

If you encounter issues with your VIZIO TV, refer to the following common solutions:

- **No Power:** Ensure the power cable is securely connected to both the TV and a working electrical outlet. Try a different outlet.
- **No Picture:** Check that the correct input source is selected. Verify all video cables are securely connected.
- **No Sound:** Check the TV's volume and mute settings. Ensure external audio devices are properly connected and powered on.
- **Network Connection Issues:** Restart your router and modem. Reconnect the TV to your Wi-Fi network through the settings menu.
- **Remote Control Not Working:** Replace the batteries in the remote control. Ensure there are no obstructions between the remote and the TV's IR sensor.

For persistent issues, a factory reset may resolve the problem. This will erase all personalized settings and return the TV to its original state. Consult the TV's on-screen menu for the factory reset option.

6. Specifications

Feature	Specification
Model Name	VQD75M-0804
Screen Size	75 Inches
Resolution	4K (3840 x 2160)
Display Technology	QLED (LED with Quantum Dot)
HDR Support	Dolby Vision, HDR10+, HDR10, HLG
Connectivity	WiFi 6, Bluetooth 5.2
HDMI Ports	3 x HDMI 2.1
Special Features	Ambient Light Sensor, Built-In Speaker, Chromecast, Game Mode, Spatial Scaling Engine

Supported Internet Services	Netflix, Prime Video, YouTube, WatchFree+
Power Consumption	165 watts
Dimensions (with stand)	13.9 x 40.5 x 65.7 inches
Item Weight	44.45 Pounds
Included Components	Remote Control

7. Warranty Information

For detailed warranty information regarding your VIZIO 75" 4K QLED Smart TV, Model VQD75M-0804, please refer to the warranty card included with your product or visit the official VIZIO website. Warranty terms and conditions may vary.

8. Support

If you require further assistance or have questions not covered in this manual, please contact VIZIO customer support through their official website or the contact information provided in your product documentation.

© 2025 VIZIO. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Answered questions about this manual

Why does my VIZIO VQD75M-0804 TV turn itself on without me doing anything?

If your VIZIO VQD75M-0804 is turning on by itself, it is often caused by external triggers or specific settings rather than a hardware failure. Here are the most common causes and how to address...

Read full answer