

[Manuals.plus](#) /

> [Relaxdays](#) /

> Relaxdays Bread Box with Bamboo Lid Instruction Manual (Model 10051569\_127)

## Relaxdays 10051569\_127

# Relaxdays Bread Box with Bamboo Lid Instruction Manual

Model: 10051569\_127

## PRODUCT OVERVIEW

---

The Relaxdays Bread Box is designed for optimal storage of bread, rolls, and other baked goods. Its robust metal construction and tightly fitting bamboo lid help to maintain freshness by protecting contents from air exposure and external elements. The design features a classic retro aesthetic with "BREAD" lettering, making it a functional and decorative addition to any kitchen.



Image: Front view of the Relaxdays Bread Box in beige with its bamboo lid.

This bread box is suitable for various baked items, including loaves of bread, dinner rolls, croissants, and pastries. Its compact, rectangular shape is designed to save countertop space while providing ample storage capacity.

## SETUP

---

1. **Unpacking:** Carefully remove the bread box and its bamboo lid from the packaging.
2. **Initial Cleaning:** Before first use, wipe the interior and exterior of the metal bread box with a damp cloth and mild soap. Rinse thoroughly with a clean, damp cloth. Dry completely.
3. **Lid Preparation:** The bamboo lid can be wiped with a damp cloth. Ensure it is completely dry before placing it on the bread box. Avoid soaking the bamboo lid in water.
4. **Placement:** Place the bread box on a clean, dry, and stable surface in your kitchen.



Image: The bread box with its lid removed, illustrating the interior for cleaning.

## OPERATING INSTRUCTIONS

---

To use the Relaxdays Bread Box for storing your baked goods:

1. **Open the Lid:** Gently lift the bamboo lid from the metal container.
2. **Place Baked Goods:** Carefully place your bread, rolls, or other pastries inside the bread box. Ensure items are not overly compressed.
3. **Close the Lid:** Place the bamboo lid back onto the metal container, ensuring it sits securely to create a tight seal. This helps to keep the contents fresh.



Image: Demonstrating how to place bread into the container for storage.

The bread box is designed to protect baked goods from drying out and from external influences, helping to extend their freshness.

## MAINTENANCE AND CARE

Proper care ensures the longevity and hygiene of your bread box.

- **Metal Container:**

- Wipe the interior and exterior with a soft, damp cloth.
- Use mild dish soap if necessary for stubborn stains.
- Rinse with a clean, damp cloth to remove any soap residue.
- Dry thoroughly immediately after cleaning to prevent water spots or rust.
- Do not use abrasive cleaners, scouring pads, or harsh chemicals, as these can damage the finish.
- Not suitable for dishwasher.

- **Bamboo Lid:**

- Wipe clean with a damp cloth.

- Dry immediately and completely.
- Do not soak the bamboo lid in water or wash it in a dishwasher, as this can cause warping or cracking.
- Periodically, you may apply a food-safe mineral oil to the bamboo lid to maintain its condition and prevent drying.

## TROUBLESHOOTING

---

- **Bread drying out quickly:**

- Ensure the bamboo lid is properly seated and creating a tight seal.
- Avoid opening the bread box unnecessarily, as this exposes contents to air.
- Check if the bread box is placed in an area with excessive airflow or direct sunlight.

- **Lid appears warped or cracked:**

- This can occur if the bamboo lid has been exposed to excessive moisture or not dried properly. Always dry the lid immediately after cleaning.
- Avoid soaking the lid in water.

- **Unpleasant odor inside the box:**

- Thoroughly clean the interior of the bread box and the lid as per the "Maintenance and Care" section.
- Ensure all baked goods are fresh when placed inside. Remove any stale or moldy items immediately.
- Allow the box to air out completely before storing new items.

## SPECIFICATIONS

---

Feature	Detail
Model Number	10051569_127
Overall Dimensions (H x W x D)	Approx. 13.5 x 33 x 19 cm (5.31 x 12.99 x 7.48 inches)
Internal Dimensions (H x W x D)	Approx. 12.5 x 32.5 x 18 cm
Weight	Approx. 1 kg (2.27 pounds)
Material	Iron (container), Bamboo (lid)
Color	Beige
ASIN	B0FMZVRDLR
UPC	4052025856571



Image: Visual representation of the bread box dimensions.

## SUPPORT INFORMATION

---

For further assistance or inquiries regarding your Relaxdays Bread Box, please contact customer support:

- **Manufacturer:** Relaxdays GmbH
- **Email:** [support@relaxdays.de](mailto:support@relaxdays.de)

Please have your model number (10051569\_127) and ASIN (B0FMZVRDLR) available when contacting support.