

[Manuals.plus](#) /

> [GarveeHome](#) /

> GarveeHome 70-Inch TV Stand (Model 3ctvgyL4I) Instruction Manual

GarveeHome 3ctvgyL4I

GarveeHome 70-Inch TV Stand Instruction Manual

Model: 3ctvgyL4I

Brand: GarveeHome

INTRODUCTION

Thank you for choosing the GarveeHome 70-Inch TV Stand. This entertainment center is designed to accommodate flat or curved TVs up to 75 inches, offering ample storage with three drawers and three open compartments. Crafted from high-grade engineered wood, it provides a sturdy and durable solution for your living room or bedroom media needs. This manual provides detailed instructions for assembly, usage, maintenance, and troubleshooting to ensure a smooth experience.



Image: The GarveeHome 70-inch TV Stand, showcasing its design and functionality in a modern living space.

SAFETY INFORMATION

- Read all instructions carefully before assembly and use.

- Keep all small parts and packaging materials away from children and pets to prevent choking hazards.
- Ensure all connections are securely tightened before placing any items on the stand. Periodically check and re-tighten fasteners as needed.
- Do not exceed the maximum weight capacity: 220 lbs for the top surface and 25 lbs for each shelf.
- Place the TV stand on a level, stable surface to prevent tipping.
- Use caution when moving the assembled stand. It is recommended to have two people for relocation.
- Avoid exposing the stand to excessive moisture or direct sunlight to prevent damage to the engineered wood.

PACKAGE CONTENTS

Before beginning assembly, verify that all components listed below are present and undamaged. If any parts are missing or damaged, please contact customer support.

- All engineered wood panels (labeled A, B, C, etc.)
- Hardware pack (screws, dowels, cam locks, drawer slides, handles, etc.)
- Assembly instructions manual



Image: An illustration detailing all components and hardware for assembly.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly typically requires two adults and a Phillips head screwdriver. Follow the numbered steps in the provided assembly manual carefully. All parts are pre-drilled and numbered for ease of installation.

- 1. Prepare Workspace:** Clear a spacious area and lay out all parts on a soft, clean surface to prevent scratches.
- 2. Identify Parts:** Match each wooden panel and hardware piece to the corresponding labels in the instruction manual.
- 3. Assemble Frame:** Begin by connecting the main frame components using the provided screws and dowels. Ensure cam locks are fully tightened.
- 4. Install Shelves:** Insert the fixed and adjustable shelves into their designated slots.
- 5. Assemble Drawers:** Construct the three drawers. Pay close attention to the orientation of the drawer sides and bottom panels. *Note: Some users have reported a misprint in step 8 regarding parts 2 and 4; if drawers do not fit, try swapping these pieces. Ensure washers are used for drawer pulls as indicated.*
- 6. Attach Drawer Slides:** Secure the drawer slides to both the stand frame and the drawers.
- 7. Insert Drawers:** Carefully slide the assembled drawers into the stand.
- 8. Attach Handles:** Secure the metal handles to the front of each drawer.
- 9. Final Check:** Verify all screws and fasteners are tight and the stand is stable.



Image: Visual representation of the TV stand's dimensions (70.1" L x 15.4" W x 20.5" H).

OPERATING INSTRUCTIONS

- TV Placement:** Carefully place your television on the top surface of the stand. Ensure the TV base is centered and stable. This stand is suitable for TVs up to 75 inches.
- Storage:** Utilize the three spacious drawers for storing media accessories, remote controls, or other personal items. The smooth-gliding drawers allow for easy access.
- Open Compartments:** The three open shelves are ideal for media players, gaming consoles, soundbars, or decorative items.
- Cable Management:** Use the integrated cable holes at the back of the stand to route and organize power cords and signal cables, keeping your entertainment area tidy and clutter-free.



Image: Illustration demonstrating the TV stand's compatibility with various TV sizes, up to 75 inches.



Image: Detail of the cable management system with three cable holes for organized wiring.

MAINTENANCE

- **Cleaning:** Wipe the surface with a soft, damp cloth. Avoid using harsh chemicals or abrasive cleaners, which can damage the finish.
- **Spills:** Immediately wipe up any spills to prevent water damage or staining, as the surface is water-resistant but not waterproof.
- **Inspection:** Periodically check all screws and connections to ensure they remain tight. Re-tighten if necessary to maintain stability.
- **Avoid Overloading:** Do not place items heavier than the specified weight limits on the top surface or shelves.

TROUBLESHOOTING

Issue: Stand feels wobbly after assembly.

Solution: Ensure all cam locks and screws are fully tightened. Check that the stand is placed on a completely level surface. Adjust furniture glides if present, or place shims under the feet if needed.

Issue: Drawers do not slide smoothly or fit correctly.

Solution: Verify that the drawer slides are installed correctly and aligned on both the drawer and the stand

frame. Check the assembly steps for the drawers, particularly step 8, as some instructions may have minor misprints regarding part orientation (e.g., parts 2 and 4). Ensure all drawer hardware, including washers for pulls, is installed as directed.

Issue: Visible gaps between panels.

Solution: Loosen the connections slightly, push the panels together to close the gap, and then re-tighten all fasteners. Ensure dowels are fully inserted into their holes.

SPECIFICATIONS

Brand	GarveeHome
Model Number	3ctvgyL4I
Dimensions (L x W x H)	70.1 x 15.4 x 20.5 inches
Item Weight	85 pounds
Material	Engineered Wood
Color	Grey
Max TV Size	Up to 75 inches
Top Surface Weight Capacity	220 lbs
Shelf Weight Capacity	25 lbs each
Number of Drawers	3
Special Features	3 drawers, 3 open compartments, cable management holes, water-resistant, scratch-proof



Image: Detailed view of product features including smooth drawers, cable holes, metal handles, and the waterproof board material.

WARRANTY AND SUPPORT

GarveeHome is committed to providing quality products. For any questions regarding assembly, missing parts, or product defects, please contact GarveeHome customer support. Refer to your purchase documentation for specific warranty details and contact information.

For further assistance, please visit the GarveeHome store on Amazon: [GarveeHome Store](#)

© 2025 GarveeHome. All rights reserved.