

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [KEMEI](#) /

› [KEMEI Professional Hair Clipper and Trimmer Set \(Models 2293gold & 2296\) User Manual](#)

KEMEI 2293gold & 2296

KEMEI Professional Hair Clipper and Trimmer Set (Models 2293gold & 2296) User Manual

Comprehensive instructions for optimal use and care.

1. PRODUCT OVERVIEW

The KEMEI Professional Hair Clipper and Trimmer Set (Models 2293gold & 2296) is designed for versatile hair grooming. This kit includes a cordless hair clipper (Model 2296) and a T-blade trimmer (Model 2293gold), along with various accessories to facilitate precise and efficient haircuts.



Image 1.1: KEMEI Professional Hair Clipper (2296) and Trimmer (2293gold) Set.

Key Features:

- **Dual Grooming Tools:** Includes one cordless hair clipper (2296) and one T-blade trimmer (2293gold).
- **Powerful Motors:** Clipper operates at 7500 RPM, trimmer at 6000 RPM for smooth, snag-free cutting.
- **Quiet Operation:** Engineered for low noise levels, less than 60 decibels.
- **LED Display:** User-friendly digital display on the trimmer shows battery level and charging status.
- **Long-lasting Battery:** Clipper features a 2500 mAh battery (350 mins run time), trimmer a 1200 mAh battery (180 mins run time).

- **Ergonomic Design:** Comfortable and easy to handle for extended use.
- **Comprehensive Accessories:** 8 guide combs for clippers (3mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm), 3 guide combs for trimmers (1mm, 2mm, 3mm), 2 cleaning brushes, 1 hair brush, 2 lubricant bottles, 2 Type-C charging cables, and a barber's cape.

2. SETUP AND INITIAL USE

2.1 Unboxing and Component Check

Carefully remove all items from the packaging. Verify that all components listed in the Product Overview are present and undamaged.

2.2 Initial Charging

Before first use, fully charge both the hair clipper and the T-blade trimmer. Use the provided Type-C charging cables.

- **Hair Clipper (2296):** Connect the Type-C cable. A full charge takes approximately 3.5 hours.
- **T-blade Trimmer (2293gold):** Connect the Type-C cable. The LED display will indicate charging status. A full charge takes approximately 3 hours.

The LED display on the trimmer will show the battery level and alert you when recharging is needed.



Image 2.1: KEMEI hair clipper and trimmer connected to USB-C charging cables.

2.3 Attaching Guide Combs

Select the desired guide comb length for your haircut. Align the comb with the blade and firmly push it into place until it clicks. Ensure the comb is securely attached before operating the device.



Image 2.2: Guide combs for the hair clipper and T-blade trimmer.

3. OPERATING INSTRUCTIONS

3.1 Powering On/Off

To turn on either the clipper or trimmer, press the power button located on the device. Press the button again to turn it off.

3.2 Using the Hair Clipper (Model 2296)

- Attach the appropriate guide comb for the desired hair length.
- For best results, use on clean, dry hair.
- Hold the clipper with the blade teeth pointing upwards and move against the direction of hair growth.
- Use smooth, overlapping strokes for an even cut.

3.3 Using the T-blade Trimmer (Model 2293gold)

The T-blade trimmer is ideal for detailing, outlining, and achieving a zero-gap finish. It can be used for hair, beard, and body trimming.




Image 3.1: Multi-purpose use of the KEMEI clipper and trimmer for hair, beard, and body.

- Use without a guide comb for close trimming and outlining.
- Attach the 1mm, 2mm, or 3mm guide combs for specific beard or body hair lengths.
- Hold the trimmer at a slight angle to the skin and move gently.

4. MAINTENANCE AND CARE

Proper maintenance ensures the longevity and optimal performance of your KEMEI grooming tools.

4.1 Cleaning the Blades

After each use, turn off the device and remove any attached guide comb. Use the provided cleaning brush to remove loose hairs from the blades. For a more thorough cleaning, the blades can be carefully detached and rinsed under running water, ensuring the main body of the device does not get wet. Dry blades completely before reattaching.



Image 4.1: Close-up of the powder metallurgy tool blade, highlighting its sharp and durable nature.

4.2 Oiling the Blades

Regular oiling is crucial for maintaining blade sharpness and smooth operation. After cleaning and drying the

blades, apply 1-2 drops of the provided lubricant oil across the blade teeth. Turn on the device for a few seconds to distribute the oil evenly, then wipe off any excess.



Image 4.2: Applying oil to the clipper blade for smooth cutting.

4.3 Battery Care and Storage

- Avoid fully discharging the battery frequently to prolong its lifespan.
- Store the devices in a cool, dry place, away from direct sunlight and moisture.
- Always ensure the devices are turned off before storing.

4.4 Safety Precautions

- Avoid use near water.
- Keep blades clean and dry.
- Store out of reach of children.
- Do not ingest or inhale small parts.

5. TROUBLESHOOTING

If you encounter any issues with your KEMEI grooming set, refer to the following common solutions:

Problem	Possible Cause	Solution
Device does not turn on	Low or no battery charge	Charge the device fully using the provided Type-C cable.
Poor cutting performance / Pulling hair	Blades are dull, dirty, or not oiled	Clean blades thoroughly and apply lubricant oil. If problem persists, blades may need replacement.
Device stops during use	Battery is low	Recharge the device. The LED display on the trimmer will indicate low battery.
Excessive noise or vibration	Blades are not properly aligned or oiled	Ensure blades are clean and well-oiled. Check for any foreign objects.

6. SPECIFICATIONS

Feature	Specification
Hair Clipper Model	2296
T-blade Trimmer Model	2293gold
Clipper Motor Speed	7500 RPM
Trimmer Motor Speed	6000 RPM
Clipper Battery Capacity	2500 mAh
Clipper Charge Time	3.5 hours
Clipper Run Time	Up to 350 minutes
Trimmer Battery Capacity	1200 mAh
Trimmer Charge Time	3 hours
Trimmer Run Time	Up to 180 minutes
Battery Type	Integrated/Built-in Rechargeable Battery
Charging Interface	Type-C USB
Included Guide Combs (Clipper)	8 (3mm, 6mm, 10mm, 13mm, 16mm, 19mm, 22mm, 25mm)
Included Guide Combs (Trimmer)	3 (1mm, 2mm, 3mm)
Package Dimensions	9.25 x 9.21 x 4.02 inches

Feature	Specification
Weight	3.46 Pounds

7. WARRANTY AND SUPPORT

For warranty information, product registration, or technical support, please refer to the documentation included with your purchase or visit the official KEMEI website. Specific warranty terms and conditions may vary by region and retailer.