

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [VGR](#) /

› [VGR 889C Professional Hair Clippers User Manual](#)

VGR 889C

VGR 889C Professional Hair Clippers User Manual

Model: 889C

1. INTRODUCTION

Thank you for choosing the VGR 889C Professional Hair Clippers. This manual provides essential information for the safe and effective use, maintenance, and care of your new hair clipper. Please read these instructions thoroughly before first use and retain them for future reference.



Image 1.1: VGR 889C Professional Hair Clippers with included accessories.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- VGR 889C Cordless Hair Clipper
- 6 Magnetic Guide Combs (1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm)
- 1 Protection Cap
- 1 Charging Base
- 1 Lubricating Oil
- 1 Cleaning Brush
- 1 USB Charging Cable



Image 2.1: The six magnetic guide combs included with the clipper, ranging from 1.5mm to 12mm.

3. PRODUCT FEATURES

- **High-Speed 9000RPM Motor:** Equipped with a powerful DC motor offering two adjustable speeds (8000/9000 RPM) for efficient and precise cutting.
- **Precision Ceramic & MIM Blades:** Features ultra-sharp ceramic moving blades paired with durable Metal Injection Molding (MIM) blades for cool, sharp, and long-lasting performance.
- **6 Magnetic Guide Combs:** Securely attachable combs (1.5/3/4.5/6/9/12mm) for consistent cutting lengths and easy switching.
- **Smart LED Display:** Shows real-time battery percentage (00–100) and current speed setting.
- **Dual Charging Options:** Rechargeable via USB cable or the included charging base.
- **Long Battery Life:** 2500mAh lithium battery provides up to 250 minutes of cordless use from a 3-hour charge.

- **Adjustable Taper Lever:** Allows for fine-tuning of cutting length from 0.8mm to 2mm without a guide comb.



Image 3.1: Illustration of the high-performance 9000 RPM motor, designed for efficient hair cutting.



Image 3.2: The clipper's LED display indicating power level and engine speed, along with the turbocharger function.

4. SETUP

1. **Initial Charge:** Before first use, fully charge the clipper for approximately 3 hours. Refer to the 'Charging' section for detailed instructions.
2. **Blade Inspection:** Ensure the blades are clean and properly aligned. If necessary, clean with the provided brush.
3. **Lubrication:** Apply a few drops of the included lubricating oil to the blades before the first use and after each cleaning to maintain optimal performance.

5. OPERATING INSTRUCTIONS

5.1 Attaching Guide Combs

Select the desired magnetic guide comb (1.5mm, 3mm, 4.5mm, 6mm, 9mm, or 12mm). Align the comb with the clipper head and allow the magnets to secure it in place. Ensure it is firmly attached before use.



Image 5.1: The six magnetic guide combs and the adjustable taper lever for precise cutting length control.

5.2 Adjusting Cutting Length (Without Guide Comb)

The taper lever on the side of the clipper allows for fine adjustments of the cutting length from 0.8mm to 2mm when no guide comb is attached. Move the lever up or down to select the desired length.

CUTTING GUIDES

Adjustable cutting length: 0.8-2mm



Image 5.2: Visual representation of the adjustable cutting lengths (0.8mm to 2mm) using the taper lever.

5.3 Powering On/Off and Speed Adjustment

Press the ON/OFF button to power on the clipper. The LED display will show the current battery percentage and speed. Press the button again to cycle between the two speed settings (8000 RPM and 9000 RPM Turbo function). Press and hold the button to power off the clipper.

5.4 Hair Cutting Technique

Always start with clean, dry hair. Hold the clipper with the blades facing away from you and move it against the direction of hair growth. Use smooth, even strokes. For best results, practice on a small section first.

PROFESSIONAL CORDLESS HAIR CLIPPER



Image 5.3: The VGR 889C hair clipper in use, demonstrating its professional application.

6. MAINTENANCE

6.1 Cleaning the Blades

After each use, turn off the clipper and remove any attached guide comb. Use the provided cleaning brush to remove loose hairs from the blades. For a more thorough cleaning, the blades can be carefully detached (refer to specific blade removal instructions if provided in a separate guide) and rinsed under running water, ensuring the clipper body remains dry. Allow blades to air dry completely before reattaching.

6.2 Lubricating the Blades

After cleaning and drying, apply 1-2 drops of the lubricating oil to the blades. Turn on the clipper for a few seconds to distribute the oil evenly. This helps maintain blade sharpness and smooth operation.

6.3 Storage

Store the clipper and its accessories in a dry, cool place, away from direct sunlight and moisture. Use the protection cap to cover the blades when not in use.

7. CHARGING

The VGR 889C clipper features a 2500mAh lithium battery, providing up to 250 minutes of cordless operation on a full charge. A full charge typically takes 3 hours.

7.1 Charging Methods

- **Using the Charging Base:** Place the clipper securely onto the charging base. Connect the USB charging cable to the base and then to a compatible USB power source (e.g., power adapter, computer USB port, power bank).
- **Direct USB Charging:** Connect the USB charging cable directly to the charging port on the clipper and then to a compatible USB power source.

The LED display will indicate the charging status and battery percentage. Once fully charged, the display will show 100%.

2 CHARGING METHODS

RECHARGEABLE VIA CHARGING BASE OR USB CABLE
2500mAh lithium-ion battery

3^{CHARGING TIME}
HOURS

260^{USE TIME}
MINUTES



Image 7.1: The two available charging methods: via the charging base or directly with the USB cable.



Image 7.2: Details on the clipper's battery life, showing 3 hours charging time for 260 minutes of use.

8. TROUBLESHOOTING

Problem	Possible Cause	Solution
Clipper does not turn on.	Battery is depleted.	Charge the clipper fully.
Clipper pulls hair or cuts unevenly.	Blades are dull, dirty, or not lubricated.	Clean and oil the blades. Ensure blades are properly aligned.
Clipper makes unusual noise.	Blades may be obstructed or require lubrication.	Clean and oil the blades. If problem persists, contact customer support.
Guide comb falls off.	Comb not securely attached.	Ensure the magnetic comb is fully seated and secured onto the clipper head.

9. SPECIFICATIONS

- **Model Number:** YS-V889C-Orange
- **Brand:** VGR
- **Motor Speed:** Up to 9000 RPM

- **Blade Material:** Ceramic & MIM (Metal Injection Molding)
- **Battery Type:** 2500mAh Lithium-ion
- **Charging Time:** Approximately 3 hours
- **Operating Time:** Up to 250 minutes (cordless)
- **Cutting Lengths (with combs):** 1.5mm, 3mm, 4.5mm, 6mm, 9mm, 12mm
- **Cutting Lengths (without comb):** 0.8mm - 2mm (adjustable)
- **Power Source:** Battery Powered (USB charging)
- **Item Weight:** 1.01 Kilograms
- **Package Dimensions:** 10.98 x 9.33 x 2.36 inches

10. WARRANTY AND SUPPORT

VGR products are designed for quality and reliability. This product comes with a **1-Year Warranty** from the date of purchase, covering manufacturing defects.

For technical assistance, troubleshooting, or warranty claims, please contact VGR customer support. Our support team is available for **24-hour assistance**.

You can visit the official VGR store on Amazon for more information: [VGR Store](#)




Image 10.1: VGR provides a 1-year warranty and 24-hour customer support for their products.

Related Documents - 889C

	<p>VGR V-990 Cordless Hair Trimmer User Guide</p> <p>Comprehensive guide to using the VGR V-990 professional cordless hair trimmer, featuring 8000RPM, barber-grade performance, and easy hair cutting for men.</p>
	<p>VGR V-085 Professional Hair Trimmer User Manual & Safety Instructions</p> <p>This document provides comprehensive safety instructions, component descriptions, usage guidelines, charging, cleaning, and maintenance information for the VGR V-085 Professional Hair Trimmer.</p>
	<p>VGR V-282 Professional Hair Clipper User Manual and Specifications</p> <p>Comprehensive user manual for the VGR V-282 Voyager Professional Hair Clipper. Includes detailed information on components, safety instructions, usage, charging, maintenance, technical features, and disposal guidelines.</p>
	<p>VGR V-930 Professional Hair Trimmer User Manual with AFA Endorsement</p> <p>Comprehensive user manual for the VGR V-930 Professional Hair Trimmer, featuring AFA endorsement with player imagery. Covers safety instructions, components, usage, charging, cleaning, maintenance, and technical specifications for this personal grooming device.</p>
	<p>VGR V-906 Professional Hair Trimmer User Manual</p> <p>Comprehensive user manual for the VGR V-906 electric hair trimmer, detailing features, operation, charging, maintenance, and troubleshooting for professional and home grooming.</p>
	<p>VGR V-085 Professional Hair Trimmer Manual and Safety Instructions</p> <p>This document provides comprehensive safety instructions, components list, usage guidelines, cleaning and maintenance procedures, and technical specifications for the VGR V-085 Professional Hair Trimmer.</p>