

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Merax](#) /

› [Merax Modern TV Stand Set with Adjustable Bridge \(Model B0FN3T3NLG\) - Instruction Manual](#)

Merax Modern TV Stand Set With Adjustable Bridge for TVs Up to 75"

Merax Modern TV Stand Set with Adjustable Bridge

Model: B0FN3T3NLG

Brand: Merax

1. INTRODUCTION

This manual provides detailed instructions for the assembly, installation, and care of your Merax Modern TV Stand Set. Please read all instructions carefully before beginning assembly and retain this manual for future reference. Proper assembly and maintenance are crucial for the product's stability and longevity.

2. SAFETY INFORMATION

Important Safety Precautions:

- Ensure proper installation using the provided anti-tip brackets to prevent tipping.
- Follow all assembly instructions carefully to maintain stability and avoid potential hazards.
- Do not overload shelves or drawers. Distribute weight evenly.
- Keep small parts away from children during assembly.
- Always use appropriate tools as specified in the assembly guide.

3. PRODUCT OVERVIEW

The Merax Modern TV Stand Set is a versatile entertainment center designed to accommodate TVs up to 75 inches. It features a modular 4-in-1 storage system, combining a TV stand, bookcase, wine rack, and display shelves. The overhead bridge is adjustable, allowing for customization to match various TV installation heights.



Figure 3.1: Fully assembled Merax Modern TV Stand Set with a television and various decorative items.

All in One

This set of entertainment wall units includes a right pier, left pier, overhead bridge, and TV console.



TV Stand



Bookcase



Wine Rack



Display Case

Figure 3.2: Illustration of the 4-in-1 storage system, highlighting its adaptability as a TV stand, bookcase, wine rack, and display case.

SIZE:INCH



Figure 3.3: Dimensional drawing of the TV stand set, indicating overall measurements and internal compartment sizes.

4. SETUP & ASSEMBLY

Assembly of the Merax Modern TV Stand Set is required. It is recommended that two people participate in the assembly process to ensure stability and ease of handling. Please refer to the included assembly instructions for a step-by-step guide.

4.1 Tools Required

- Screwdriver (Phillips head recommended)
- Hammer (for dowels, if applicable)
- Measuring tape
- Level

4.2 Assembly Steps Overview

1. Unpack all components and verify against the parts list.
2. Assemble the base console units first, ensuring all cam locks and screws are securely fastened.
3. Attach the side pier units to the main console.

4. Install the adjustable overhead bridge. The height can be customized to fit your television.
5. Secure the entire unit to the wall using the provided anti-tip safety brackets. This step is critical for preventing accidental tipping.
6. Insert adjustable shelves into desired positions.

Note: Some users have reported challenges with part alignment during assembly. Carefully review the diagrams and ensure all components are correctly oriented before tightening fasteners. Do not force parts together; if alignment issues occur, re-check the instructions and component orientation.



Adjustable Height

The height of the overhead bridge can be decided by yourself. This allows for more versatility in matching various TV installation heights.



Figure 4.1: The adjustable overhead bridge allows for flexible TV placement.

5. OPERATING INSTRUCTIONS

Once assembled, your Merax TV Stand Set offers various functionalities:

- **TV Placement:** Position your television within the central opening. The adjustable bridge can be set to accommodate different TV heights, ensuring optimal viewing.
- **Storage:** Utilize the multiple compartments, drawers, and shelves for media devices, books, decorative items, or even as a wine rack. The modular design allows for flexible organization.

- **Cable Management:** While not explicitly detailed, consider using cable ties or adhesive clips (not included) to manage and conceal wires for a tidy appearance.

6. MAINTENANCE

To ensure the longevity and appearance of your TV stand set, follow these maintenance guidelines:

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the finish.
- **Dusting:** Regularly dust with a dry, soft cloth to prevent buildup.
- **Hardware Check:** Periodically check all screws and fasteners to ensure they remain tight. Re-tighten if necessary to maintain structural integrity.
- **Avoid Direct Sunlight:** Prolonged exposure to direct sunlight can cause fading or discoloration.
- **Moisture Protection:** Protect the unit from excessive moisture. Immediately wipe up any spills.



Figure 6.1: Details of the particle board construction, hardware, and anti-tip safety features.

7. TROUBLESHOOTING

If you encounter issues during or after assembly, refer to the following common troubleshooting tips:

- **Parts Not Lining Up:** If parts do not align correctly, disassemble the affected section and carefully re-examine the instruction diagrams. Ensure all pieces are oriented as shown and that the correct fasteners are used for each connection. Sometimes, slight adjustments are needed before fully tightening.
- **Chipped or Damaged Pieces:** If you notice minor chipping during assembly, proceed with caution. For significant damage or missing parts, contact customer support for assistance.
- **Wobbly Unit:** Ensure all screws and cam locks are fully tightened. Verify that the unit is placed on a level surface. If the issue persists, re-check the assembly steps, especially those related to the base and main supports. The anti-tip brackets must be securely installed.
- **Doors Not Aligning:** For doors that do not align properly or have noticeable gaps, check the hinge installation. Most hinges allow for minor adjustments to achieve proper alignment. Refer to the specific hinge adjustment instructions in your assembly guide.

8. SPECIFICATIONS

Brand	Merax
Model Name	Modern TV Stand Set With Adjustable Bridge for TVs Up to 75"
Color	Black
Material	Engineered Wood
Product Dimensions	15"D x 103"W x 76.9"H
Item Weight	60 Pounds
Mounting Type	Floor Mount
Installation Type	Freestanding
Number of Shelves	3
Assembly Required	Yes
UPC	199193419048

9. WARRANTY & SUPPORT

For warranty information or customer support, please refer to the documentation included with your purchase or contact Merax customer service directly. Keep your proof of purchase for any warranty claims.