

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [SWOFY](#) /

› [SWOFY D50 128GB MP3 Player with Bluetooth 5.3 Instruction Manual](#)

SWOFY D50

SWOFY D50 128GB MP3 Player Instruction Manual

Model: D50

1. INTRODUCTION

This manual provides detailed instructions for the proper use and maintenance of your SWOFY D50 128GB MP3 Player. Please read this manual thoroughly before operating the device to ensure optimal performance and longevity.

2. PACKAGE CONTENTS

Verify that all items listed below are present in your product package:

- 1 x SWOFY D50 128GB MP3 Player
- 1 x Wired Earphones
- 1 x USB Type-C Cable
- 1 x User Manual (this document)



Image: The SWOFY D50 MP3 Player, wired earphones, USB Type-C cable, and user manual laid out, illustrating the complete package contents.

3. DEVICE OVERVIEW

The SWOFY D50 features a compact design with essential ports and controls for easy operation.

3.1 Physical Features

- **1.8-inch Screen:** For clear display of menus and content.
- **Touch Buttons:** Intuitive controls for navigation.
- **Built-in HD Speaker:** For audio playback without earphones.
- **3.5mm Headphone Jack:** For wired audio output.
- **Type-C Port:** For charging and data transfer.
- **Micro SD Card Slot:** Supports expansion up to 256GB.
- **Power Button:** Located on the side for turning the device on/off.
- **Volume Buttons:** For adjusting audio levels.




Image: A close-up view of the SWOFY D50 MP3 Player highlighting its touch screen, dedicated touch buttons for navigation, and the Type-C charging port at the bottom.

4. SETUP

4.1 Charging the Device

Before first use, fully charge the MP3 player using the provided USB Type-C cable and a compatible USB power adapter (not included). The battery indicator on the screen will show charging status.

4.2 Inserting a Micro SD Card

The device has 128GB of internal storage and supports Micro SD cards up to 256GB for expanded storage. Locate the Micro SD card slot on the side of the device. Gently insert the card until it clicks into place.

4.3 Initial Power-On and Language Selection

1. Press and hold the Power button on the side of the device for a few seconds until the SWOFY logo appears.
2. Follow the on-screen prompts to select your preferred language and set the date and time.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation


The device features a touch screen and dedicated touch buttons. Swipe left/right or tap icons to navigate through menus. Use the back button to return to the previous screen.

5.2 Music Playback

The SWOFY D50 supports various audio formats including APE, FLAC, WMA, MP3, and ACELP. Transfer your music files to the device's internal storage or an inserted Micro SD card via the USB Type-C cable. Access the 'Music' application to browse and play your tracks.

Lossless Sound & Born for Music

Lossless auditory feast,
bidding farewell to distortion and noise



Supports Formats:




Image: The SWOFY D50 MP3 Player screen showing a music track playing, with icons for various supported audio formats including MP3, WAV, FLAC, APE, and OGG.

5.3 Bluetooth Connectivity

The device features Bluetooth 5.3 for wireless audio streaming to compatible headphones or speakers.

1. Go to 'Settings' and enable Bluetooth.
2. Ensure your Bluetooth headphones or speaker are in pairing mode.
3. Select your device from the list of available devices to pair.

Note: This device cannot connect to mobile phones or tablets via Bluetooth.

MP3 Player with Bluetooth 5.3

Wirelessly connected with your
BT Speaker & BT Earphones



Image: The SWOFY D50 MP3 Player shown wirelessly connected to Bluetooth headphones and a Bluetooth speaker, illustrating its Bluetooth 5.3 capability.

5.4 FM Radio

To use the FM Radio function, connect the wired earphones as they act as the antenna. Navigate to the 'FM Radio' application to scan for and listen to local stations.

5.5 Voice Recorder

The built-in voice recorder allows you to capture audio. Open the 'Voice Recorder' application and press the record button to start recording. Recordings are saved to the device's storage.

Line-in Recording

Transfer & collect music via the included AUX cable




Image: The SWOFY D50 MP3 Player screen showing a recording interface, with diagrams illustrating line-in recording capabilities from devices such as cell phones, CDs, VCDs, DVDs, power amplifiers, vinyl players, and radio/tape drives.

5.6 E-Book Reader and Picture Viewer

The device supports e-book reading and picture viewing. Transfer compatible files to the device and access them through the respective applications.

Multifunctional Mp3 Player

Image: The SWOFY D50 MP3 Player displaying its multi-functional capabilities, including icons for Music, AB Repeat, Bluetooth, Calendar, FM Radio, Picture, Resume, E-Book, Various Speed Playback, Recorder, and 128GB internal memory with 128GB expansion.

6. MAINTENANCE

6.1 Battery Care

To prolong battery life, avoid fully discharging the device frequently. Charge the device regularly, especially if it will not be used for an extended period. Store in a cool, dry place.

6.2 Cleaning

Use a soft, dry cloth to clean the device. Avoid using liquid cleaners or abrasive materials, which may damage the screen or casing.

7. TROUBLESHOOTING

- Device does not power on:** Ensure the device is fully charged. If the issue persists, try pressing the reset button (if available) or contact support.
- Cannot connect to Bluetooth:** Ensure Bluetooth is enabled on both the MP3 player and the target device.

device, and that both are in pairing mode. Verify that the target device is not a phone or tablet.


- **No sound:** Check volume levels. Ensure earphones are properly connected or Bluetooth device is paired and connected.
- **Files not recognized:** Verify that the files are in a supported format (APE, FLAC, WMA, MP3, ACELP). Ensure the Micro SD card is properly inserted and not corrupted.

8. SPECIFICATIONS

Brand	SWOFY
Model	D50
Internal Memory	128 GB
Expandable Memory	Up to 256 GB (Micro SD card)
Bluetooth Version	5.3
Screen Size	1.8 Inches
Connectivity Technology	Bluetooth, USB
Special Features	Built-In Speaker, Equalizer, FM Radio, Voice Recorder
Battery	1 Lithium Polymer battery (included)
Item Weight	5.3 ounces
Dimensions	91.6*41.6*9.8mm (approx. 3.6 x 1.6 x 0.39 inches)

Stylish & Compact

A good sports partner when your morning workout



0.36

Inch Thick

2.18

Oz lightweight

Image: The SWOFY D50 MP3 Player held in a hand, emphasizing its stylish and compact design, with text indicating its 0.36-inch thickness and 2.18-ounce lightweight nature.

9. WARRANTY AND SUPPORT

For warranty information and technical support, please refer to the contact details provided on the product packaging or visit the official SWOFY website. Keep your purchase receipt for warranty claims.


© 2025 SWOFY. All rights reserved.

Related Documents - D50

 USER MANUAL MP3 Player	SWOFY D50 MP3 Player User Manual User manual for the SWOFY D50 MP3 Player. This guide provides detailed instructions on features such as music playback, Bluetooth connectivity, FM radio, recording, e-book reading, and device settings. Learn to maximize your portable digital music experience.
---	---

 <p>SWOFY USER MANUAL MP3 PLAYER D50</p> <p>Thanks for your purchase! Welcome to our official website: www.swofy.com.cn Any other sales service related please feel free to contact us: swofyservice@gmail.com</p>	<p>SWOFY D50 MP3 Player User Manual</p> <p>User manual for the SWOFY D50 MP3 Player, covering button functions, charging, music playback, Bluetooth pairing, E-book reading, FM radio, settings, and specifications.</p>
 <p>SWOFY USER MANUAL MP3 PLAYER M2</p> <p>Thanks for your purchase! Welcome to our official website: www.swofy.com.cn Any other sales service related please feel free to contact us: swofyservice@gmail.com</p>	<p>SWOFY M2 MP3 Player User Manual</p> <p>Comprehensive user manual for the SWOFY M2 MP3 Player, detailing its features, functions, and specifications. Learn how to operate music playback, Bluetooth pairing, FM radio, recordings, e-book reading, and device settings.</p>
 <p>SWOFY User Manual MP3 Music Player</p> <p>If any aspect is incorrect, please feel free to email us: swofyservice@gmail.com</p>	<p>SWOFY M4 Music Player User Manual - Features, Specifications & Operation</p> <p>Comprehensive user manual for the SWOFY M4 Music Player. Learn about its features, specifications, music playback, movie support, FM radio, Bluetooth connectivity, and more.</p>
 <p>SWOFY User Manual MP3 Music Player</p> <p>If any aspect is incorrect, please feel free to email us: swofyservice@gmail.com</p>	<p>SWOFY M4 Music Player User Manual</p> <p>User manual for the SWOFY M4 Music Player, detailing its features, functions, specifications, and operation for music playback, video, e-books, FM radio, and Bluetooth connectivity.</p>
 <p>SWOFY USER MANUAL DIGITAL PLAYER</p> <p>Thanks for your purchase! Welcome to our official website: www.swofy.com.cn Any other sales service related please feel free to contact us: swofyservice@gmail.com</p>	<p>SWOFY M503Pro Digital Player User Manual</p> <p>Comprehensive user manual for the SWOFY M503Pro digital player, covering setup, features, settings, specifications, and warnings. Learn how to use your device effectively.</p>

Documents - SWOFY – D50



[SWOFY D50 MP3 Player User Manual](#)

User manual for the SWOFY D50 MP3 Player, covering button functions, charging, music playback, Bluetooth pairing, E-book reading, FM radio, settings, and specifications.

lang: **score:23** filesize: 2.97 M page_count: 49 document date: 2025-04-14

SWOFY

USER MANUAL
MP3 PLAYER
D50

Thanks for your purchase!
Welcome to download manual at <https://www.swofy.com.cn/>
Any other sales service needed please feel free to contact us:
swofyservice@gmail.com

[SWOFY D50 MP3 Player User Manual](#)

User manual for the SWOFY D50 MP3 Player. This guide provides detailed instructions on features such as music playback, Bluetooth connectivity, FM radio, recording, e-book reading, and device settings. Learn to maximize your portable digital music experience.

lang: **score:21** filesize: 6.65 M page_count: 49 document date: 2025-04-11