

[Manuals.plus](#) /

> [PHILIPS](#) /

> PHILIPS TAS2000W Wireless Bluetooth Speaker User Manual

PHILIPS TAS2000W

PHILIPS TAS2000W Wireless Bluetooth Speaker User Manual

Model: TAS2000W

INTRODUCTION

Thank you for choosing the PHILIPS TAS2000W Wireless Bluetooth Speaker. This compact and powerful speaker delivers rich sound with Bass+ technology, vibrant LED lights, and robust connectivity options. Designed for portability and durability, it features IPX5 splash resistance and a long-lasting battery. This manual provides essential information for setting up, operating, and maintaining your speaker.

WHAT'S IN THE BOX

Carefully unpack your PHILIPS TAS2000W speaker. The package should contain the following items:

- PHILIPS TAS2000W Wireless Bluetooth Speaker
- Quick Start Guide
- Warranty Card
- Safety Leaflet
- Power Cable

PRODUCT OVERVIEW

The PHILIPS TAS2000W speaker combines powerful audio with dynamic LED lighting in a portable design. Key features include:

- **20W Max Output with Bass+ Technology:** Delivers deep, impactful bass.
- **Integrated LED Light Show:** Five RGB light modes synchronize with music.
- **Bluetooth 5.4 Connectivity:** Stable and efficient wireless streaming.
- **Auracast Support:** Connect to multiple Auracast-enabled speakers for a wider soundstage.
- **20-Hour Playback:** Extended battery life for all-day use.
- **IPX5 Splash Resistance:** Protected against water splashes, suitable for outdoor use.
- **USB Playback:** Direct music playback from USB devices.
- **Built-in Microphone:** For hands-free calls.
- **Philips Entertainment App Control:** Manage settings, lighting, and playback.



Image: The PHILIPS TAS2000W speaker, showcasing its Bass+ capabilities and dynamic LED light panel.

SETUP

1. Charging the Speaker

Before first use, fully charge the speaker. Connect the provided power cable to the speaker's charging port and a suitable power adapter (not included). The charging indicator will show the charging status. A full charge takes approximately 2.5 hours and provides up to 20 hours of playback. A quick 30-minute charge can provide 5 hours of playback.

2. Powering On/Off

Press and hold the Power button on the speaker for a few seconds to turn it on or off.

3. Bluetooth Pairing

1. Turn on the speaker. It will automatically enter Bluetooth pairing mode, indicated by a flashing LED light.
2. On your mobile device, enable Bluetooth and search for available devices.
3. Select "PHILIPS TAS2000W" from the list.
4. Once paired, the speaker will emit a confirmation sound, and the LED light will stop flashing.

The speaker supports multipoint connectivity, allowing it to be paired with two Bluetooth devices simultaneously.

OPERATING

1. Audio Playback

- **Bluetooth:** After pairing, play audio from your connected device. Use the speaker's controls or your device to adjust volume, play/pause, and skip tracks.
- **USB Playback:** Insert a USB drive containing audio files into the USB-A port. The speaker will automatically detect and play the music.

Transmisión Bluetooth, multipunto, reproducción USB

¿Listas de reproducción? Bluetooth 5.4 te ofrece una conexión estable para una transmisión perfecta. La conectividad multipunto te permite conectarte a dos dispositivos Bluetooth al mismo tiempo, y puedes conectar un reproductor de música portátil o una unidad USB en el puerto USB-A del altavoz.



Image: Two PHILIPS TAS2000W speakers connected wirelessly, illustrating Bluetooth multipoint and USB playback capabilities.

2. LED Light Modes

The speaker features five RGB LED light modes that synchronize with your music. Press the dedicated Light button on the speaker to cycle through the different modes. You can also control the lights via the Philips Entertainment App.

Espectáculo de luces sincronizado con el ritmo. El arcoíris de LED sigue el ritmo de la música.

Las coloridas luces LED RGB parpadean al ritmo de la música sobre y alrededor de los radiadores pasivos dobles. Hay cinco modos de iluminación diferentes entre los que elegir. Solo tienes que pulsar el botón de luz del altavoz o utilizar nuestra aplicación complementaria para empezar y hacer saber a todo el mundo que vas a darlo todo.



Image: The PHILIPS TAS2000W speaker displaying its colorful LED light show, synchronized with music.

3. Auracast Functionality

Auracast allows you to broadcast audio from your speaker to other compatible Auracast-enabled speakers, creating a multi-speaker audio experience. Refer to the Philips Entertainment App for detailed instructions on setting up Auracast connections.

4. Hands-Free Calling

When connected to a smartphone via Bluetooth, the built-in microphone allows you to answer calls directly through the speaker. Press the Play/Pause button to answer or end a call.

5. Philips Entertainment App

Download the Philips Entertainment App for enhanced control over your speaker. The app allows you to:

- Select audio sources.
- Control playback and Bass+ settings.
- Change LED lighting modes.
- Check battery status.
- Utilize PartyLink mode for connecting multiple speakers via Auracast.

Aplicación Philips Entertainment. Control inteligente del altavoz

Nuestra práctica aplicación complementaria te permite seleccionar una fuente, controlar la reproducción y Bass+, cambiar entre diferentes modos de iluminación, comprobar la duración de la batería y mucho más. Además, el modo PartyLink integrado en la aplicación facilita la conexión a otros altavoces a través de Auracast para disfrutar de un sonido aún más potente.



Image: The PHILIPS TAS2000W speaker, shown with water droplets to emphasize its splash resistance, highlighting smart control via the Philips Entertainment App.

MAINTENANCE

Cleaning

To clean the speaker, use a soft, dry cloth. Do not use abrasive cleaners, alcohol, or chemical solvents, as these may damage the surface. Ensure the charging port cover is securely closed when not charging to maintain IPX5 splash resistance.

Storage

Store the speaker in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, charge the battery periodically to maintain its lifespan.

TROUBLESHOOTING

Problem	Solution
Speaker does not turn on.	Ensure the battery is charged. Connect the speaker to a power source and try again.
Cannot pair via Bluetooth.	Make sure the speaker is in pairing mode. Disable and re-enable Bluetooth on your device. Move closer to the speaker.
No sound or low volume.	Check the volume levels on both the speaker and your connected device. Ensure the speaker is properly paired.

Problem	Solution
LED lights are not working.	Press the Light button to cycle through modes. Check settings in the Philips Entertainment App.
USB playback not working.	Ensure the USB drive is formatted correctly and contains compatible audio files. Try a different USB drive.

SPECIFICATIONS

- **Model Number:** TAS2000W/00
- **Brand:** PHILIPS
- **Speaker Type:** Portable Speaker
- **Connectivity Technology:** Bluetooth, USB
- **Bluetooth Version:** 5.4
- **Bluetooth Range:** 30 meters
- **Audio Output Mode:** Mono
- **Max Speaker Output Power:** 20 Watts
- **Frequency Response:** 20000 Hz
- **Battery Life:** Up to 20 hours
- **Battery Charge Time:** Approximately 30 minutes for 5 hours playback, full charge in 2.5 hours
- **Water Resistance Level:** IPX5 (Splash Resistant)
- **Control Method:** Touch, App
- **Product Dimensions:** 7.1 x 18.1 x 7.1 cm
- **Weight:** 477 g
- **Material:** Plastic
- **Color:** White

WARRANTY AND SUPPORT

Warranty Information

This PHILIPS TAS2000W speaker comes with a **2-year manufacturer's warranty**. Please retain your proof of purchase for warranty claims. The warranty covers manufacturing defects under normal use. It does not cover damage caused by misuse, accidents, unauthorized modifications, or normal wear and tear.

Customer Support

For further assistance, technical support, or warranty inquiries, please visit the official PHILIPS support website or contact their customer service. Refer to the warranty card or the Quick Start Guide for specific contact details in your region. You can also find additional resources, including a PDF user manual, at the following link [PHILIPS TAS2000W User Manual \(PDF\)](#)

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FN48WSWK>

More documents and user manuals: <https://manuals.plus/>