

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Armocity](#) /

› [Armocity 4-Tier White Corner Bookshelf Instruction Manual](#)

## Armocity 4CBS-W

# Armocity 4-Tier White Corner Bookshelf Instruction Manual

Model: 4CBS-W

Brand: Armocity

## INTRODUCTION

---

Thank you for choosing the Armocity 4-Tier White Corner Bookshelf. This instruction manual provides essential information for the safe assembly, operation, and maintenance of your new furniture. Designed to maximize space, this L-shaped bookshelf features four open tiers and rounded corners, making it a versatile addition to various rooms.



Image: The Armocity 4-Tier White Corner Bookshelf, showcasing its L-shaped design and multiple shelves filled with books and decor, positioned in a cozy living room corner.

## SAFETY INFORMATION

Please read and understand all instructions before assembly and use. Keep this manual for future reference.

- **Anti-Tip Device:** Always install the included wall anchors to prevent tipping, especially if children or pets are present. This significantly improves safety.
- **Weight Distribution:** Distribute weight evenly across all shelves. Avoid placing heavy items on upper shelves to maintain stability.
- **Surface Stability:** Ensure the bookshelf is placed on a flat, stable, and level surface.
- **Child Safety:** Keep small parts and packaging materials away from children during assembly. The rounded corners are designed for safety, but supervision is always recommended.
- **Power Outlets:** If your model includes integrated power outlets, ensure they are used according to electrical safety guidelines. Do not overload the outlets.

**Use your corner spaces effectively**



**Anti-tip Device for Improve Safety**

**Rounded Corners and Curved Design**

**90 Degree Design Fits Corner Space**

*Image: Detailed view of the bookshelf's safety features, including smoothly rounded corners to prevent injury, an anti-tip device for wall mounting, and the precise 90-degree design for a snug fit in corners.*

## **PACKAGE CONTENTS**

Before beginning assembly, verify that all parts and hardware are present. If any items are missing or damaged, please contact customer support.

The package includes pre-sorted parts and hardware. Refer to the detailed parts list and illustrations provided in your physical instruction booklet for exact quantities and identification.

### **Typical Components:**

- Engineered Wood Panels (various shapes for shelves and supports)
- Assembly Hardware (screws, dowels, cam locks, wall anchors)
- Power Strip with USB Ports (for models with this feature)
- Assembly Tool (e.g., Hex Key)

## SETUP AND ASSEMBLY INSTRUCTIONS

---

Assembly is straightforward and typically takes about 1 hour without power tools, or approximately 30 minutes with power tools. All parts are labeled with stickers for easy identification. It is recommended to assemble the unit on a soft, clean surface to prevent scratches.

### Step-by-Step Guide:

1. **Prepare the Base:** Identify the bottom panel and attach the necessary hardware (e.g., cam bolts) as indicated in your manual.
2. **Assemble Vertical Supports:** Connect the vertical support panels to the base using dowels and cam locks. Ensure all connections are secure.
3. **Install Shelves:** Gradually add the curved shelf panels, securing them to the vertical supports. Pay attention to the orientation of each shelf to ensure the L-shape is correctly formed.
4. **Attach Back Panels (if applicable):** Some models may include back panels for added stability. Secure these as per the instructions.
5. **Install Top Panel:** Place the top panel, ensuring it aligns with all vertical supports and is securely fastened.
6. **Integrate Power Strip:** If your model includes a power strip with USB ports, carefully insert it into the designated cutout on the top panel and secure it with the provided screws. Route the power cord through the cable management hole.
7. **Apply Anti-Tip Device:** Securely attach the anti-tip device to the top rear of the bookshelf and to a wall stud using the provided hardware. This is a critical safety step.
8. **Final Checks:** Ensure all screws and fasteners are tightened. Gently shake the unit to check for stability.

# Product Dimensions




Image: A technical diagram illustrating the precise dimensions of the 4-Tier Corner Bookshelf, including its overall height of 39.3 inches and shelf depths of 11.8 inches and 10.3 inches, crucial for planning placement.

## OPERATING INSTRUCTIONS

The Armocity 4-Tier Corner Bookshelf is designed for versatile storage and display. Its L-shaped design allows it to fit snugly into room corners, maximizing space.

- **Placement:** Position the bookshelf in any corner of your bedroom, living room, home office, kitchen, or hallway.
- **Storage:** Utilize the four open shelves to store books, display decorative items, plants, photos, or small appliances. The built-in bookends on each shelf help prevent items from slipping.
- **Power Access:** If equipped, use the integrated power strip with USB ports on the top shelf to conveniently charge devices or power small electronics.
- **Versatility:** This unit can serve various functions, from a traditional bookshelf to a display stand for collectibles, or even as corner pantry shelves in a kitchen.



**Rounded corners design is suitable for a kids' room.**

*Image: The 4-Tier Corner Bookshelf in a child's room, showcasing its rounded corners and ample storage for books and toys, making it a safe and functional piece for young users.*



## 4-tier Corner Wine Bar Shelves

*Image: The 4-Tier Corner Bookshelf creatively repurposed as a compact bar shelf, holding various bottles and barware, illustrating its multi-room versatility.*

### MAINTENANCE

Proper care will ensure the longevity and appearance of your bookshelf.

- **Cleaning:** Wipe down the surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners, which can damage the engineered wood finish.
- **Spills:** Promptly clean any spills to prevent staining or damage to the material.
- **Fasteners:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary to maintain structural integrity.
- **Sunlight Exposure:** Avoid prolonged direct sunlight exposure to prevent fading or discoloration of the finish.

### TROUBLESHOOTING

**Common Issues and Solutions:**

- **Wobbly Unit:**

- Ensure all cam locks and screws are fully tightened.
- Verify the unit is on a level surface. Adjust with shims if needed.
- Confirm the anti-tip device is securely installed.

- **Missing Parts:**

- Double-check all packaging materials. Small hardware can sometimes be overlooked.
- Contact Armocity customer support with your model number and a description of the missing part.

- **Difficulty with Assembly:**

- Review the step-by-step instructions and illustrations carefully.
- Ensure parts are oriented correctly before tightening fasteners.
- If using a hex key, ensure it is fully inserted to avoid stripping screw heads.

## SPECIFICATIONS

<b>Model Name</b>	4 Tier Corner Bookshelf
<b>Item Model Number</b>	4CBS-W
<b>Brand</b>	Armocity
<b>Color</b>	White
<b>Material</b>	Engineered Wood
<b>Product Dimensions</b>	23.6"D x 23.6"W x 39.3"H
<b>Item Weight</b>	29.9 pounds
<b>Number of Shelves</b>	4
<b>Installation Type</b>	Freestanding
<b>Special Features</b>	Corner Design, Easy Assemble, Rounded Corners, Built-in Bookends, Optional Power Strip with USB Ports (depending on model)
<b>Assembly Required</b>	Yes

## WARRANTY AND SUPPORT

For warranty information, product support, or to order replacement parts, please contact Armocity customer service directly. Refer to the contact details provided in your purchase documentation or visit the official Armocity website. You can visit the Armocity Store for more products: [Armocity Store on Amazon](#)

