

[Manuals.plus](#) /

> [Elgin](#) /

> Elgin Silence Air Pro Ceiling Fan Instruction Manual - Model 42VEN3PASP00

Elgin 42VEN3PASP00

Elgin Silence Air Pro Ceiling Fan Instruction Manual

Model: 42VEN3PASP00

INTRODUCTION

Thank you for choosing the Elgin Silence Air Pro Ceiling Fan. This manual provides essential information for the safe installation, operation, and maintenance of your new ceiling fan. Please read these instructions thoroughly before installation and keep them for future reference.



Image: The Elgin Silence Air Pro Ceiling Fan, featuring a sleek black design with three aerodynamic blades and a central integrated LED light fixture.

SAFETY INSTRUCTIONS

- Always disconnect power at the circuit breaker before installation, cleaning, or maintenance.
- Installation must be performed by a qualified electrician and in accordance with all local electrical codes.
- Ensure the mounting structure can support the weight of the fan (approximately 1.9 kg).
- Do not insert objects into the fan blades while the fan is operating.
- Keep children away from the fan during operation and maintenance.
- Use only original replacement parts and accessories provided by Elgin.

PACKAGE CONTENTS

Verify that all components are present before beginning installation:

- Ceiling Fan Motor Assembly
- 3 ABS Blades
- LED Light Kit
- Remote Control
- AAA Batteries for Remote Control
- Wall Mount for Remote Control
- Ceiling Mounting Kit (screws, brackets, etc.)
- Instruction Manual

SETUP

1. Installation

The Elgin Silence Air Pro fan features an **Easy Plug** system for simplified installation. Follow the detailed instructions provided in the separate installation guide included with your product. Ensure all connections are secure and the fan is firmly mounted to the ceiling structure.



Image: The Easy Plug system, designed for quick, safe, and straightforward electrical connection during installation.

2. Remote Control Setup

Insert the provided AAA batteries into the remote control, ensuring correct polarity. The remote control is pre-paired with the fan. If pairing is required, refer to the specific instructions in the installation guide.

OPERATING INSTRUCTIONS

Your Elgin Silence Air Pro fan is operated via the included remote control. Ensure the fan has power and the remote control batteries are correctly installed.



Acompanha controle remoto

Acesse todas as funções de forma fácil e prática, sem sair do lugar.

Image: The remote control for the Elgin Silence Air Pro fan, providing convenient access to all fan and light functions.

Remote Control Functions:

Iluminação LED de 18W integrada

Escolha entre luz quente, neutra ou fria e crie a atmosfera perfeita para cada momento. Mais economia, durabilidade e baixo consumo!




Image: A detailed diagram illustrating the various buttons and their functions on the remote control, including speed adjustment, light control, timer settings, and rotation inversion.

- **Power On/Off:** Press the designated button to turn the fan and light on or off.
- **Fan Speed:** Use the numbered buttons (1-6) to select one of six available fan speeds. '1' is the lowest speed, and '6' is the highest.
- **Light Control:** Press the 'Luz on/off' button to toggle the LED light.
- **Light Color Temperature:** The integrated 18W LED light offers three color temperatures: 3000K (Warm White), 4000K (Neutral White), and 6500K (Cool White). Cycle through these options by repeatedly pressing the light button or a dedicated color temperature button if available on your remote.



Image: Visual representation of the three adjustable LED light color temperatures: warm (3000K), neutral (4000K), and cool (6500K), demonstrating the versatility for different ambient lighting needs.

- **Timer Function:** Set the fan to automatically turn off after a specified period (e.g., 1 hour, 4 hours) using the timer buttons.
- **Rotation Inversion:** The 'R' button allows you to reverse the direction of the fan blades, useful for circulating warm air in colder months.
- **Breeze Function:** The 'F' button activates a natural breeze mode, which cycles through different fan speeds to simulate a natural airflow.

MAINTENANCE

1. Cleaning

To maintain the appearance and performance of your fan, clean it regularly. Ensure the power is disconnected before cleaning.

- Wipe the fan blades and motor housing with a soft, damp cloth.
- Do not use abrasive cleaners or solvents, as these can damage the finish.
- Avoid getting water into the motor housing or electrical components.

2. LED Replacement

The integrated LED light is designed for long-lasting performance. If replacement becomes necessary, contact Elgin customer support for guidance and authorized service. The LED module is replaceable.

TROUBLESHOOTING

If you experience issues with your fan, refer to the following common problems and solutions:

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Fan does not turn on	No power supply; Remote control batteries depleted; Loose wiring connection.	Check circuit breaker; Replace remote control batteries; Verify all wiring connections are secure (consult a qualified electrician).
Fan makes excessive noise	Loose mounting screws; Unbalanced blades; Obstruction.	Tighten all mounting screws; Check for balanced blades and ensure they are securely attached; Remove any obstructions.
Light does not work	No power to light; LED module issue.	Check light switch/remote light button; Contact customer support for LED module inspection/replacement.
Remote control not responding	Depleted batteries; Remote out of range; Interference.	Replace batteries; Ensure you are within range of the fan; Minimize electronic interference.

SPECIFICATIONS

Detailed technical specifications for the Elgin Silence Air Pro Ceiling Fan:



Image: An overview of the fan's key features, including its 6 speed settings, silent motor operation, 3 light color temperatures, and bivolt power compatibility.

Model Number: 42VEN3PASP00

Brand: Elgin

Color: Black (also available in White)

Motor Power: 30W

Number of Blades: 3

Blade Material: ABS

Number of Speeds: 6

LED Light Power: 18W

LED Color Temperatures: 3000K (Warm White), 4000K (Neutral White), 6500K (Cool White)

Voltage: Bivolt (110V / 220V)

Special Features: Remote Controlled, LED Light, Silent Operation, Automatic Shutdown, Easy Plug System

Product Dimensions: 106 cm (Depth) x 106 cm (Width) x 54 cm (Height)



Image: A diagram illustrating the physical dimensions of the ceiling fan, indicating a total width of 1060 mm and a height of 165 mm from the ceiling mount to the bottom of the blades.

WARRANTY

The Elgin Silence Air Pro Ceiling Fan comes with a **24-month warranty** from the date of purchase. This warranty covers manufacturing defects and ensures the quality and durability of the product. Please retain your proof of purchase for warranty claims. For full warranty terms and conditions, refer to the warranty card included in the product packaging or contact Elgin customer support.

SUPPORT

For technical assistance, troubleshooting beyond this manual, or warranty inquiries, please contact Elgin customer support. Visit the official Elgin website for contact information and additional resources.

Elgin Official Website: [Visit the Elgin Store on Amazon](#)