

## Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

- › [HIFIT](#) /
- › [HIFIT 72.8" Tall Kitchen Pantry Cabinet with LED & Charging Station Instruction Manual](#)

### HIFIT UP-CG-0199

# HIFIT 72.8" Tall Kitchen Pantry Cabinet with LED & Charging Station Instruction Manual

Model: UP-CG-0199

## 1. INTRODUCTION

---

This manual provides detailed instructions for the assembly, setup, operation, and maintenance of your HIFIT 72.8" Tall Kitchen Pantry Cabinet. Please read all instructions carefully before beginning assembly and retain this manual for future reference. This cabinet is designed to offer ample storage and functional features for your kitchen, dining room, or living area.



Figure 1: HIFIT Tall Kitchen Pantry Cabinet, showcasing its design and functionality in a home environment.

## 2. SAFETY INFORMATION

To ensure safe use of this product, please observe the following precautions:

- **Anti-Tipping Devices:** Always secure the cabinet to the wall using the anti-tipping devices provided to prevent tipping and potential injury.
- **Weight Limit:** Do not exceed the maximum load capacity of 1200 pounds. Distribute weight evenly across shelves.
- **Assembly:** Assembly requires two people. Follow the instructions carefully to ensure proper and stable construction.
- **Electrical Safety:** When using the built-in charging station, ensure appliances are within the specified voltage and current limits (2 AC outlets, 2 USB ports). Do not overload the outlets.
- **Placement:** Place the cabinet on a flat, stable surface. Avoid placing it in areas with excessive moisture or direct sunlight.

## 3. PACKAGE CONTENTS

Your HIFIT Kitchen Pantry Cabinet is shipped in two separate packages, which may arrive at different times. Please ensure you have

received both packages before beginning assembly.  
The packages contain:

- All necessary cabinet panels and components.
- Hardware and installation kit (screws, dowels, hinges, etc.).
- LED lighting strip and power adapter.
- Built-in charging station unit.
- Anti-tipping devices.
- User Manual (this document).




Figure 2: Product dimensions and notification that the cabinet ships in two boxes.

## 4. ASSEMBLY INSTRUCTIONS

Assembly of the HIFIT Kitchen Pantry Cabinet requires careful attention to detail. All parts are labeled, and pre-drilled holes are provided to simplify the process. We recommend assembling the product with at least two people to ensure stability and ease of construction.

1. **Unpack and Identify:** Carefully unpack all components and lay them out. Verify that all parts listed in the package contents are

present and undamaged. Refer to the included assembly diagram for part identification.

2. **Base Assembly:** Begin by assembling the base frame of the cabinet according to the step-by-step illustrations in the separate assembly guide.
3. **Lower Cabinet Construction:** Attach the side panels, back panel, and shelves for the lower section. Ensure all connections are secure.
4. **Drawer Installation:** Assemble the deep storage drawer and install it into its designated slot.
5. **Countertop Placement:** Secure the spacious countertop onto the lower cabinet.
6. **Upper Cabinet Assembly:** Construct the upper cabinet section, including its shelves and compartments.
7. **Attaching Upper to Lower:** Carefully lift and secure the upper cabinet onto the countertop of the lower section.
8. **Door Installation:** Attach all cabinet doors, including the swing-out door, using the provided hinges. Adjust hinges as needed to ensure proper alignment and smooth closing.
9. **Knob Installation:** Install all silver metal knob handles on the doors and drawer.
10. **Anti-Tipping Device Installation:** Securely install the anti-tipping devices to the top rear of the cabinet and anchor them to a wall stud.

*Note: Some customer feedback indicates that door alignment may require careful adjustment of hinges. Take your time during this step to achieve a flush fit.*

Your browser does not support the video tag.

Video 1: Overview of the HIFIT Farmhouse Kitchen Pantry Cabinet, demonstrating its features and assembly process. This video provides a visual guide to the cabinet's structure and functionality.

## 5. SETUP AND FEATURES

---

### 5.1 LED Lighting System

The cabinet features integrated LED lighting in the open countertop area. This provides illumination for your items and enhances the aesthetic appeal.

- **Activation:** The LED lights are controlled by a switch located on the charging station.
- **Placement:** The LED strip is pre-installed under the upper cabinet section, illuminating the countertop.



Figure 3: The LED lighting feature illuminates the countertop, providing visibility and ambiance.

## 5.2 Built-in Charging Station

The spacious 55.1" wide countertop includes a built-in charging station for convenience. This station is equipped with:

- 2 AC Outlets (120V/12A)
- 2 USB Ports (5V/2A)
- A master ON-OFF switch for power control.

To use, simply plug the charging station's power cord into a wall outlet. Use the switch to turn power on or off to the outlets and USB ports.



Figure 4: The charging station provides convenient power access for small appliances and devices.

## 6. OPERATING INSTRUCTIONS

### 6.1 Storage Compartments and Shelves

The cabinet offers 12 closed storage compartments and 4 adjustable shelves to organize various items. The upper cabinet also features two open compartments for easily accessible items like coffee cups or beans.

- **Adjustable Shelves:** The shelves within the closed compartments can be adjusted to different heights to accommodate items of various sizes. To adjust, remove the shelf pins, reposition the shelf to the desired height, and reinsert the pins securely.
- **Deep Storage Drawer:** A deep drawer is located in the center of the lower cabinet, suitable for cutlery, small utensils, or other kitchen essentials.

## ALL-IN-ONE Large Storage Pantry Cabinet



Figure 5: The cabinet's interior provides extensive storage options with adjustable shelves and a deep drawer.

### 6.2 Swing-Out Door


The cabinet includes a swing-out door with a 3-tier internal rack, maximizing storage volume. This rack is ideal for storing bottles, sauces, beverages, or canned goods.

- **Magnetic Catch:** The door is equipped with a magnetic catch to ensure it stays securely closed.
- **Smooth Hinges:** The hinges allow for smooth opening and closing of the door.



Door Adjustable **Shelves**

Storage **Drawer**



Farmhouse Barn **Doors**

Figure 6: Details of the swing-out door's internal rack, deep drawer, and barn door design elements.

## 7. MAINTENANCE

Proper care and maintenance will extend the life and appearance of your cabinet.

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Spills:** Clean up spills immediately to prevent staining or damage to the engineered wood.
- **Hardware:** Periodically check all screws and fasteners to ensure they are tight. Retighten if necessary.
- **Hinges:** If doors become misaligned, adjust the hinges as per the assembly guide.

## 8. TROUBLESHOOTING

Problem	Possible Cause	Solution
---------	----------------	----------

Problem	Possible Cause	Solution
Doors are not aligned or do not close properly.	Hinges are not properly adjusted or installed.	Refer to the assembly guide for hinge adjustment instructions. Loosen screws slightly, adjust door position, and retighten.
Cabinet feels wobbly or unstable.	Fasteners are loose; anti-tipping devices not installed or secured.	Ensure all screws are tightened. Install and properly anchor the anti-tipping devices to a wall stud. Place on a level surface.
LED lights or charging station not working.	Power cord not plugged in; master switch off; faulty connection.	Check if the power cord is securely plugged into a wall outlet. Ensure the master ON-OFF switch on the charging station is in the "ON" position. Verify all connections are secure.
Missing parts during assembly.	Packaging error or lost during unpacking.	Double-check all packaging materials. If parts are still missing, contact customer support with your model number and a list of required parts.

## 9. SPECIFICATIONS

Feature	Detail
Brand	HIFIT
Model Name	tall kitchen cabinet (UP-CG-0199)
Color	Black
Product Dimensions	15.7"D x 55.1"W x 72.8"H
Material	Engineered Wood
Item Weight	253 pounds (115 Kilograms)
Weight Limit	1200 Pounds
Number of Shelves	3 (adjustable)
Number of Compartments	12 closed, 2 open
Special Features	Anti-Tipping, Built-In Charging Station (2 AC outlets, 2 USB ports), Illuminated (LED)
Assembly Required	Yes
Installation Type	Freestanding
Room Type	Dining Room, Kitchen, Living Room

## 10. WARRANTY AND SUPPORT

HIFIT is committed to providing quality products and customer satisfaction. While specific warranty details are not provided in this manual, our post-sale service team is available 24/7 to assist you with any questions or concerns regarding your product.

If you encounter any issues or have questions about assembly, missing parts, or product functionality, please contact HIFIT customer support. Have your model number (UP-CG-0199) ready when contacting support for faster service.

For further information or to explore other HIFIT products, please visit the [HIFIT Store on Amazon](#).



