

[Manuals.plus](#) /

> [LECTRUS](#) /

> LECTRUS T30W Android 15 Tablet 10.1 Inch User Manual

LECTRUS T30W

LECTRUS T30W Android 15 Tablet User Manual

Model: T30W | Brand: LECTRUS

1. INTRODUCTION

This manual provides essential information for setting up, operating, maintaining, and troubleshooting your LECTRUS T30W Android 15 Tablet. This device features a 10.1-inch HD display, an Octa-Core processor, 12GB RAM, 128GB internal storage expandable up to 2TB, dual cameras, and 5G WiFi connectivity. It also integrates Gemini AI for enhanced smart features.

2. PACKAGE CONTENTS

Verify that all items are present in your package:

- LECTRUS T30W Android 15 Tablet
- USB-C Cable
- User Manual (this document)

3. PRODUCT OVERVIEW

Familiarize yourself with the physical components and features of your tablet.

Android 15 & GMS Certification



12GB
RAM



128GB
ROM



2 TB
Support



OS
Android 15.0



Display
10.1in



CPU
Octa Core



IPS
1280*800



Dual Screen
Support



Battery
6000mAh



WIFI
2.4G/5 G



Camera
5MP+13MP



Bluetooth
5.0



3.5mm
Headphone Jack



Figure 3.1: LECTRUS T30W Android 15 Tablet front view, displaying the home screen with various app icons.

Wider Vision, Clearer View

10.1" IPS display with 1280×800 resolution and eye-care mode keeps viewing comfortable even for long hours.



10.1inch



1280*800 IPS



16:9



Eye Protection



Figure 3.2: Side view of the LECTRUS T30W tablet, highlighting the USB-C port, TF card slot, power button, and volume controls.

Store More, Enjoy More

12GB RAM + 128GB ROM, expandable up to 2TB, store thousands of photos, hundreds of movies, and all your apps effortlessly.



12(4+8)GB RAM



128GB ROM



2 TB Support



Figure 3.3: Rear view of the LECTRUS T30W tablet, showing the dual camera module and flash.

4. SETUP

4.1 Charging the Tablet

Before first use, fully charge the tablet. Connect the provided USB-C cable to the tablet's USB-C port and the other end to a compatible power adapter (not included) or a computer's USB port.

4.2 Powering On/Off

- **To Power On:** Press and hold the Power button located on the side of the tablet until the LECTRUS logo appears.
- **To Power Off:** Press and hold the Power button, then select 'Power off' from the options on the screen.
- **To Restart:** Press and hold the Power button, then select 'Restart' from the options on the screen.

4.3 Initial Setup

Upon first power-on, the tablet will guide you through the initial setup process:

1. Select your preferred language.
2. Connect to a Wi-Fi network.
3. Sign in with your Google account or create a new one. This is necessary to download apps from the Google Play Store.
4. Review and accept the terms and conditions.
5. Set up screen lock (PIN, pattern, or password) for security.

4.4 Inserting a MicroSD Card (Optional)

To expand storage, insert a MicroSD card (up to 2TB, not included) into the designated TF card slot on the side of the tablet. Ensure the tablet is powered off before inserting or removing the card.

5. OPERATING INSTRUCTIONS

5.1 Basic Navigation

The tablet uses a touch screen for navigation:

- **Tap:** Select an item or open an app.
- **Swipe:** Scroll through pages or lists.
- **Pinch:** Zoom in or out on images and web pages.
- **Long Press:** Access contextual menus or move icons.

5.2 Connecting to Wi-Fi

1. Go to **Settings > Network & internet > Wi-Fi**.
2. Toggle Wi-Fi **On**.
3. Select your desired network from the list and enter the password if prompted.

5.3 Bluetooth Pairing

1. Go to **Settings > Connected devices > Bluetooth**.
2. Toggle Bluetooth **On**.
3. The tablet will scan for available devices. Select the device you wish to pair with and follow any on-screen prompts.

5.4 Using the Cameras

The tablet features a 13MP rear camera and a 5MP front camera.

1. Open the **Camera** app.
2. Tap the camera switch icon to alternate between the front and rear cameras.
3. Tap the shutter button to take a photo or start/stop video recording.

5.5 Gemini AI Features

Your tablet is powered by Gemini AI, offering intelligent assistance:

- **Voice Assistance:** Use voice commands for tasks, information, and app control.
- **Real-time Translation:** Translate languages on the fly.
- **Smart Recommendations:** Receive personalized suggestions for apps, content, and settings.




Figure 5.1: Image illustrating Gemini AI capabilities, including smart chats, personal assistant, data analysis, text-to-image generation, AI translation, and office improvement.

5.6 Split-Screen Multitasking

To run two applications simultaneously:

1. Open the first app.
2. Swipe up from the bottom of the screen and hold to access recent apps.
3. Tap the app icon at the top of the app's card and select 'Split screen'.
4. Choose the second app from the recent apps list or app drawer.



Smart Parental Controls

Restrict inappropriate content, manage screen time and app access, providing a safe, healthy, and smartonline environment for kids.

Figure 5.2: The LECTRUS T30W tablet demonstrating split-screen multitasking, showing two applications open side-by-side.

5.7 Eye-Care Mode

To reduce eye strain during prolonged use, enable Eye-Care Mode in the display settings. This mode adjusts screen colors to warmer tones.

Widevine L1 Support Streaming

Enjoy crisp, smooth visuals on platforms like Netflix and Prime Video—whether at home, on the go, or during long journeys.




Figure 5.3: The LECTRUS T30W tablet screen highlighting its 10.1-inch IPS display with 1280x800 resolution and eye protection features.

5.8 Widevine L1 Support

The tablet supports Widevine L1, allowing you to stream high-definition content from platforms like Netflix, Disney+, and Prime Video.



Massive Storage for All Your Files

12GB RAM + 128GB ROM, expandable up to 2TB, store thousands of photos, hundreds of movies, and all your apps effortlessly.

- 12GB ROM
- 128GB RAM
- 2 TB Expand

Figure 5.4: The LECTRUS T30W tablet displaying a video streaming service, illustrating its Widevine L1 support for high-definition content.

5.9 Parental Controls

Utilize built-in parental controls to manage content access, screen time, and app usage for children, creating a safe online environment.

Immersive Stereo Sound

Dual speakers deliver rich, clear audio for movies, music, and gaming.

- Dual-Speaker
- 360 degree surround sound




Figure 5.5: A child using the LECTRUS T30W tablet, demonstrating the use of smart parental controls to manage content and screen time.

5.10 Stereo Sound

The tablet features dual speakers for an immersive audio experience, suitable for music, movies, and gaming.

Lightning-Fast WiFi & Bluetooth

Dual-band WiFi and Bluetooth 5.0 deliver up to 30% faster download speeds—stream, work, and connect devices effortlessly.



BT 5.0
Power Saving



2.4G+5G
Dual-band Wi-Fi



3.5mm
Headphone Jack



Figure 5.6: The LECTRUS T30W tablet displaying a music player interface, with an illustration of its dual stereo speakers providing immersive sound.

5.11 Official Product Video

Your browser does not support the video tag.

Video 5.1: Official product video demonstrating the LECTRUS T30W Android 15 Tablet's features, including its design, performance, and camera capabilities.

6. MAINTENANCE

6.1 Cleaning the Tablet

Use a soft, lint-free cloth to clean the screen and body of the tablet. Avoid using liquid cleaners, aerosols, or abrasive materials, as these can damage the device.

6.2 Battery Care

To prolong battery life:

- Avoid exposing the tablet to extreme temperatures.
- Do not leave the tablet fully charged or fully discharged for extended periods.
- Use the provided USB-C cable for charging.

6.3 Software Updates

Regularly check for and install system updates to ensure optimal performance and security. Go to **Settings > System > System update**.

6.4 Storage Optimization

To maintain performance, periodically manage your tablet's storage:

- Clear app caches.
- Uninstall unused applications.
- Move large files to an external MicroSD card.



Figure 6.1: The LECTRUS T30W tablet displaying its storage capabilities, including 12GB RAM, 128GB ROM, and 2TB expandable storage.

7. TROUBLESHOOTING

If you encounter issues with your tablet, refer to the following common solutions:

7.1 Tablet Not Turning On

- Ensure the battery is charged. Connect the tablet to a power source for at least 30 minutes.
- Perform a force restart by pressing and holding the Power button for 10-15 seconds.

7.2 Slow Performance

- Close unnecessary background applications.
- Clear the cache of frequently used apps.
- Restart the tablet.
- If issues persist, consider a factory reset (back up your data first).

7.3 Wi-Fi Connection Issues

- Ensure Wi-Fi is enabled on the tablet.
- Restart your Wi-Fi router.
- Forget the network in tablet settings and reconnect.

7.4 App Crashes or Freezes

- Force close the app.
- Clear the app's data and cache in **Settings > Apps**.
- Reinstall the app.

7.5 Screen Unresponsive

- Perform a force restart as described in section 7.1.

8. SPECIFICATIONS

Feature	Specification
Brand	LECTRUS
Model Name	10.1 inch Tablet
Model Number	T30W
Operating System	Android 15
Processor	ARM Octa-Core (CortexTM-A55, 2 GHz)
RAM	12 GB
Internal Storage (ROM)	128 GB
Expandable Storage	Up to 2 TB (MicroSD)
Screen Size	10.1 Inches
Display Type	IPS
Display Resolution	1280 x 800 Pixels
Rear Camera	13 MP
Front Camera	5 MP
Battery Capacity	6000 mAh
Wi-Fi	2.4G/5G (802.11 b/g/n/a/ac)
Bluetooth	Bluetooth 5.0
Ports	USB Type-C, 3.5 mm Headphone Jack
Item Weight	0.84 Kilograms

9. WARRANTY AND SUPPORT

9.1 Warranty Information

Your LECTRUS T30W tablet comes with a 1-year worry-free warranty from the date of purchase. This warranty covers manufacturing defects and ensures product reliability. Please retain your proof of purchase for warranty claims.

9.2 Customer Support

For any questions, technical assistance, or warranty inquiries, please contact LECTRUS customer support. We

offer 24/7 customer support to assist you.

You can find more information and contact details on the official LECTRUS store page:[LECTRUS Store](#)

© 2026 LECTRUS. All rights reserved.