

Manuals.plus /

› AWESAFE /

› AWESAFE Android Car Radio with 9-inch Touch Screen for Peugeot 206 User Manual

AWESAFE AWESAFE Android 2GB+32GB Car Radio

AWESAFE Android Car Radio with 9-inch Touch Screen for Peugeot 206 User Manual

Model: AWESAFE Android 2GB+32GB Car Radio

INTRODUCTION

This manual provides detailed instructions for the installation, operation, and maintenance of your AWESAFE Android Car Radio with a 9-inch touch screen, specifically designed for Peugeot 206 vehicles. Please read this manual thoroughly before using the product to ensure proper function and to prevent damage. Keep this manual for future reference.

SETUP

1. Unpacking

Carefully remove all components from the packaging. Ensure all items listed below are present:

- AWESAFE Android Car Radio Unit
- Power Harness
- GPS Antenna
- USB Cables
- RCA Cables
- User Manual (this document)

2. Installation

Professional installation is recommended. Disconnect the vehicle's battery before beginning installation to prevent electrical shorts.

1. Remove the original car radio from the dashboard.
2. Connect the provided power harness to the vehicle's wiring.
3. Connect the GPS antenna and route it to a location with a clear view of the sky (e.g., dashboard corner).

4. Connect any additional accessories (e.g., reverse camera, external microphone) to the appropriate RCA or USB ports.
5. Carefully slide the AWESAFE unit into the dashboard opening until it clicks into place.
6. Reconnect the vehicle's battery.

3. Wiring Diagram

Refer to the diagram below for correct wiring connections. Incorrect wiring can damage the unit or vehicle's electrical system.



Image Description: This image displays a detailed wiring diagram for the AWESAFE Android Car Radio. It shows connections for power (ACC, B+, GND), speakers (FL+, FL-, FR+, FR-, RL+, RL-, RR+, RR-), antenna, GPS, USB ports, and RCA inputs/outputs for external devices like amplifiers, subwoofers, and reverse cameras. Each wire is color-coded and labeled for easy identification during installation.

OPERATING INSTRUCTIONS

1. Basic Functions

- **Power On/Off:** Press and hold the power button on the front panel or steering wheel controls.
- **Volume Control:** Use the volume knob or steering wheel controls to adjust audio levels.
- **Home Screen:** Tap the 'Home' icon on the touch screen to return to the main interface.
- **Back Button:** Tap the 'Back' icon to return to the previous screen or menu.

2. Navigation

The unit comes with pre-installed navigation software. Ensure the GPS antenna is properly connected and positioned for optimal signal reception.

1. Tap the 'Navigation' icon on the home screen.
2. Enter your destination using the on-screen keyboard.
3. Select your preferred route and start guidance.

3. Bluetooth Connectivity

Pair your mobile device for hands-free calling and audio streaming.

1. Go to 'Settings' > 'Bluetooth' on the car radio.
2. Enable Bluetooth on your mobile device and search for available devices.
3. Select 'AWESAFE Car Radio' from the list on your phone.
4. Confirm the pairing code on both devices if prompted.

4. Radio Tuner

Access FM/AM radio stations.

- Tap the 'Radio' icon on the home screen.
- Use the 'Scan' function to automatically search for stations.
- Manually tune by dragging the frequency bar or using the arrow buttons.
- Save your favorite stations by pressing and holding a preset button.



Image Description: This image shows the main user interface of the AWESAFE Android Car Radio. It features a clean layout with large, easy-to-read icons for common functions such as Navigation, Radio, Bluetooth, Music, Video, and Settings. The 9-inch touch screen displays vibrant colors and responsive touch controls, typical of an Android operating system.

MAINTENANCE

1. Cleaning

- Use a soft, dry cloth to clean the screen and exterior of the unit.
- For stubborn smudges, lightly dampen the cloth with water or a screen-safe cleaner.
- Avoid using abrasive cleaners or solvents, as they can damage the screen and finish.

2. Software Updates

Periodically check for software updates to ensure optimal performance and access to new features. Updates can typically be found on the AWESAFE official website or through the unit's system settings if connected to Wi-Fi.

TROUBLESHOOTING

If you encounter issues, refer to the table below for common problems and solutions.

Problem	Possible Cause	Solution
Unit does not power on	Loose power connection, blown fuse, vehicle battery low.	Check power harness connections. Inspect vehicle fuses. Charge or replace vehicle battery.
No sound	Volume too low, speaker wires disconnected, mute activated.	Increase volume. Check speaker wiring. Deactivate mute function.
GPS signal lost or inaccurate	GPS antenna improperly placed or disconnected.	Ensure GPS antenna has a clear view of the sky and is securely connected.
Bluetooth pairing failed	Bluetooth not enabled, device out of range, incorrect pairing code.	Ensure Bluetooth is enabled on both devices. Bring devices closer. Re-enter pairing code.
Touch screen unresponsive	Software glitch, screen dirty.	Restart the unit. Clean the screen.

SPECIFICATIONS

Feature	Detail
Brand	AWESAFE
Manufacturer	AWESAFE
Model	Android Car Radio (2GB+32GB)
Screen Size	9 Inches
Memory (RAM)	2GB
Storage (ROM)	32GB
Operating System	Android
UPC	759973264796

WARRANTY AND SUPPORT

AWESAFE products are designed for reliability and performance. This product comes with a standard manufacturer's warranty against defects in materials and workmanship. The specific terms and duration of the warranty may vary by region and purchase date. Please retain your proof of purchase for warranty claims. For technical support, warranty service, or further inquiries, please contact AWESAFE customer service through the retailer where the product was purchased or visit the official AWESAFE website for contact information. No relevant official product videos were found for embedding in this manual.