



[Manuals.plus](#) /

> [YUNCHI](#) /

> YUNCHI K3 Toddler Electric Toothbrush User Manual

YUNCHI K3

YUNCHI K3 Toddler Electric Toothbrush User Manual

Model: K3

[Instructions](#) [Introduction](#) [Maintenance](#) [Safety Information](#) [Troubleshooting](#) [Setup](#) [Specifications](#) [Operating](#) [Warranty & Support](#)

1. INTRODUCTION

The YUNCHI K3 Toddler Electric Toothbrush is designed for children aged 0-6 years, featuring soft DuPont nylon bristles and a playful design to encourage healthy brushing habits. This manual provides essential information for the safe and effective use of your new electric toothbrush.

Package Contents:

- 1 x YUNCHI K3 Electric Toddler Toothbrush Handle
- 4 x Replacement Brush Heads
- 1 x Bristle Cover
- 1 x Mounting Bracket (Suction Cup Base)
- 1 x Screwdriver (for battery compartment)
- 1 x Instruction Manual (this document)

Note: A single 1.5V AAA battery is required and not included in the package.

WHAT YOU WILL GET




Toothbrush Handle X1



Brush Heads X4



Screwdriver X1



User Manual X1

Image: Package contents of the YUNCHI K3 Toddler Electric Toothbrush.

2. SAFETY INFORMATION

Please read all safety instructions before using the YUNCHI K3 Toddler Electric Toothbrush. Keep this manual for future reference.

- **Adult Supervision:** Always supervise children during brushing to ensure proper and safe use.
- **Battery Safety:**
 - Ensure the battery compartment is securely sealed after battery installation.
 - Do not mix old and new batteries.
 - Do not mix alkaline, standard (carbon-zinc), or rechargeable (nickel-cadmium) batteries.
 - Remove batteries if the product is not to be used for an extended period.
- **Bristle Integrity:** The toothbrush features reinforced bristles with wrapped copper implantation to prevent shedding.

Inspect brush heads regularly for wear and replace if bristles become splayed or damaged.

- **Water Resistance:** The toothbrush has an IPX7 waterproof rating, making it safe for use in wet environments and easy to clean. However, do not submerge the entire unit for prolonged periods.
- **Stable Base:** Utilize the stable suction cup base to prevent the toothbrush from falling and getting damaged.
- **Choking Hazard:** Keep small parts, such as brush heads and the screwdriver, out of reach of young children.



Image: The YUNCHI K3 toothbrush is IPX7 waterproof.

3. SETUP

3.1 Battery Installation

The YUNCHI K3 toothbrush requires one 1.5V AAA battery (not included).

1. Locate the battery compartment at the bottom of the toothbrush handle.
2. Use the provided screwdriver to unscrew the battery compartment cover.

3. Remove the inner battery holder.
4. Insert one AAA battery, ensuring the positive (+) and negative (-) terminals align correctly with the markings inside the compartment.
5. Place the battery holder back into the handle.
6. Securely screw the battery compartment cover back on using the screwdriver.

Your browser does not support the video tag.

Video: Demonstrates the unboxing and battery installation process for the YUNCHI K3 Toddler Electric Toothbrush.

3.2 Attaching the Brush Head

1. Align the replacement brush head with the metal shaft on the toothbrush handle.
2. Gently push the brush head down until it clicks securely into place.
3. Ensure the brush head is firmly attached before use.



Image: Key features and components of the YUNCHI K3 toothbrush.

4. OPERATING INSTRUCTIONS

The YUNCHI K3 is designed for simple, one-button operation, making brushing enjoyable for children.

4.1 Brushing Your Child's Teeth

1. Apply a pea-sized amount of children's toothpaste to the brush head.
2. Press the power button on the handle to turn on the toothbrush. The colorful LED light will activate, and gentle vibrations will begin.
3. Guide your child to brush all surfaces of their teeth (outer, inner, and chewing surfaces).
4. The built-in 2-minute timer will ensure the recommended brushing duration. The toothbrush will vibrate every 30 seconds to prompt your child (or you) to move to a different quadrant of the mouth, ensuring thorough cleaning.
5. After 2 minutes, the toothbrush will automatically turn off.
6. Press the power button again to turn off the toothbrush manually if needed.



Image: The 2-minute timer and 30-second pulse reminder feature.



Image: A baby using the YUNCHI K3 toothbrush, highlighting the colorful LED light.

4.2 Colorful LED Light

The toothbrush features a playful colorful LED light that activates with the power button. This light is designed to make brushing more engaging and enjoyable for young children.

5. MAINTENANCE

5.1 Cleaning the Toothbrush

1. After each use, rinse the brush head thoroughly under running water.
2. Wipe the toothbrush handle with a damp cloth. Do not use abrasive cleaners or harsh chemicals.
3. The IPX7 waterproof design allows for easy rinsing of the entire handle, but avoid prolonged submersion.
4. Store the toothbrush upright on its suction cup base or in a clean, dry place.

5.2 Replacing the Brush Head

Dentists recommend replacing toothbrush heads every 3 months, or sooner if the bristles become splayed or damaged.

1. Grip the brush head firmly and pull it straight off the handle.
2. Dispose of the old brush head responsibly.
3. Attach a new brush head as described in the "Attaching the Brush Head" section (3.2).



Image: The soft bristles effectively remove stains.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Toothbrush does not turn on.	Battery is dead or incorrectly installed.	Check battery orientation. Replace with a new 1.5V AAA battery.

Problem	Possible Cause	Solution
Weak vibration.	Low battery power.	Replace the AAA battery.
Brush head feels loose.	Brush head not properly attached.	Remove and reattach the brush head, ensuring it clicks into place. If damaged, replace the brush head.
LED light not working.	Battery issue or internal fault.	Check/replace battery. If problem persists, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model	K3
Brand	YUNCHI
Age Range	Toddler (0-6 years)
Power Source	1 x 1.5V AAA Battery (not included)
Bristle Material	DuPont Nylon
Bristle Firmness	Soft
Operation Mode	Automatic (Vibrate)
Special Features	2-Minute Brushing Timer, 30-Second Zone Reminder, Colorful LED Light, Suction Cup Base, IPX7 Waterproof
Handle Material	ABS + TPE (Plastic)
Item Weight	3.2 Ounces
Color (as reviewed)	Pink
Theme	Unicorn

8. WARRANTY AND SUPPORT

For warranty information or technical support, please refer to the contact details provided with your purchase or visit the official YUNCHI website. Keep your proof of purchase for any warranty claims.

Manufacturer: YUNCHI

Date First Available: August 21, 2025

