

INTETURE BP30

INTETURE BP30 Cordless Vacuum Cleaner User Manual

Model: BP30 | Brand: INTETURE

1. INTRODUCTION

Thank you for choosing the INTETURE BP30 Cordless Vacuum Cleaner. This manual provides essential information for the safe and efficient operation, maintenance, and troubleshooting of your new appliance. Please read it thoroughly before use and retain it for future reference.

2. SAFETY INSTRUCTIONS

Always follow basic safety precautions when using electrical appliances to reduce the risk of fire, electric shock, or injury.

- Do not use outdoors or on wet surfaces.
- Do not allow to be used as a toy. Close attention is necessary when used by or near children.
- Use only as described in this manual. Use only manufacturer's recommended attachments.
- Do not use with damaged cord or plug. If appliance is not working as it should, has been dropped, damaged, left outdoors, or dropped into water, return it to a service center.
- Do not pull or carry by cord, use cord as a handle, close a door on cord, or pull cord around sharp edges or corners. Do not run appliance over cord. Keep cord away from heated surfaces.
- Do not unplug by pulling on cord. To unplug, grasp the plug, not the cord.
- Do not handle plug or appliance with wet hands.
- Do not put any object into openings. Do not use with any opening blocked; keep free of dust, lint, hair, and anything that may reduce air flow.
- Keep hair, loose clothing, fingers, and all parts of body away from openings and moving parts.

- Do not pick up anything that is burning or smoking, such as cigarettes, matches, or hot ashes.
- Do not use to pick up flammable or combustible liquids, such as gasoline, or use in areas where they may be present.
- Do not use without dust bag and/or filters in place.
- Turn off all controls before unplugging.
- Use extra care when cleaning on stairs.
- Do not use to pick up toxic material (chlorine bleach, ammonia, drain cleaner, etc.).
- Do not charge the unit outdoors.
- Do not modify or attempt to repair the appliance.

3. PACKAGE CONTENTS

Verify that all components are present in the package:

- 650W 55KPA Cordless Vacuum Main Body (Main Motor & Canister & HEPA Filter & Sponge Filter & Stainless Steel Filter & Handle)
- An Extra HEPA Filter
- Aromatherapy Tablets x 2
- 2-in-1 Brush
- Sofa Brush
- Mini Cleaning Tool
- Battery & Charger
- Multi-Function Rolling Brush
- Wall-mounted Charging Dock
- Adjustable Tube
- Quick User Manual

4. SETUP

4.1 Assembly

1. Connect the adjustable telescopic tube to the main vacuum body until it clicks into place.
2. Attach the multi-function rolling brush (floor brush) to the other end of the telescopic tube, ensuring it clicks securely.
3. Insert the battery into the designated slot on the main body until it locks.

4.2 Initial Charging

Before first use, fully charge the battery. The detachable battery supports separate charging. The wall-mount charging dock can hold the main unit and all accessories while charging.

Wall Mount Charging Station

Charging and storage 2 in1



Figure 1: Wall-mount charging and storage station for the INTETURE BP30.

The wall-mount charging dock provides convenient storage and charging for the vacuum and its accessories.

5. OPERATING INSTRUCTIONS

5.1 Power On/Off and Mode Selection

The LED touchscreen allows you to control the vacuum's functions:

- Press the power button to turn the vacuum on or off.
- Use the +/- buttons to switch between Energy Saving, Standard, Powerful, and Smart Auto modes.
- The screen displays the working status and remaining battery in real-time.



Figure 2: LED touchscreen for mode selection and battery status.

The intuitive touch screen allows for easy control and monitoring of the vacuum's performance.

5.2 Smart Auto Mode

In Auto mode, the vacuum cleaner automatically adjusts suction power when transitioning between different floor types, such as hardwood and carpet, ensuring optimal cleaning efficiency.



Figure 3: Auto mode intelligently adjusts suction for different surfaces.

The vacuum automatically boosts suction on carpets for a deeper clean.

5.3 LED Green Light Technology

The floor brush features innovative LED green light technology to illuminate hidden dust and debris under

furniture and in dark corners, ensuring no spot is missed.




Figure 4: LED green light reveals hidden dust for thorough cleaning.

The green light makes it easier to spot dirt and ensure complete cleaning.

5.4 Using Attachments

The included accessories (2-in-1 brush, sofa brush, mini brush) can be easily attached to the main unit for handheld cleaning of cars, furniture, sofa crevices, bed corners, stairs, and other hard-to-reach areas.

Video 1: Demonstration of the vacuum's strong portable handheld function and ease of use with attachments.

This video illustrates the strong suction and portability of the vacuum in handheld mode, showcasing its effectiveness for various cleaning tasks.

Video 2: Overview of the vacuum's effective, convenient, and easy-to-use features, including assembly and dustbin emptying.

This video highlights the vacuum's overall user-friendliness, from quick assembly to simple dust disposal.

Video 3: Demonstration of the vacuum's strong suction power on various surfaces, including carpet and hard floors.

Watch this video to see the vacuum's powerful performance in action, effectively cleaning different floor types.

Video 4: A user's perspective on the vacuum's performance, highlighting its effectiveness for everyday cleaning.

This video provides a practical view of the vacuum's capabilities from a user's experience.

Video 5: A brief demonstration showcasing the vacuum's versatility and powerful suction.

This short video illustrates the vacuum's adaptability and strong cleaning power.

Video 6: A user review highlighting the vacuum's amazing performance and features.

This video offers a positive user experience, emphasizing the vacuum's impressive capabilities.

Video 7: A demonstration of the vacuum's 'magical cleaning' ability, showcasing its efficiency.

This video visually demonstrates the vacuum's effective cleaning performance.

Video 8: A short video highlighting the vacuum's lightweight design and ease of handling.

This video emphasizes the vacuum's comfortable and light design, making it easy to maneuver.

6. MAINTENANCE

6.1 Emptying the Dust Cup

To empty the 1.8-liter dust cup, press the red release button located on the side of the canister. The bottom flap will open, allowing debris to fall out. Close the flap securely after emptying.

6.2 Filter Cleaning and Replacement

The multi-layer high-density filtration system includes washable HEPA and sponge filters. Regularly clean these filters to maintain optimal suction and air quality. An extra HEPA filter is included for convenience.

- Remove the filters from the main body.
- Rinse the filters under cold running water until the water runs clear.
- Allow filters to air dry completely for at least 24 hours before reinserting. Do not use a dryer or other heating device.
- Replace filters if they are damaged or if suction power significantly decreases even after cleaning.

6.3 Roller Brush Maintenance

Periodically check the multi-function rolling brush for tangled hair or debris. Remove any obstructions to ensure smooth operation and effective cleaning.

7. TROUBLESHOOTING

| Problem | Possible Cause | Solution |
|-------------------------|---|--|
| Vacuum does not turn on | Battery is not charged or not properly inserted. | Ensure battery is fully charged and correctly inserted. |
| Low suction power | Dust cup is full, filters are clogged, or brush roll is obstructed. | Empty dust cup, clean/replace filters, clear brush roll of obstructions. |
| Brush roll not spinning | Obstruction in brush roll or brush roll is not properly installed. | Remove any obstructions, ensure brush roll is correctly installed. |
| Short battery life | Operating in MAX mode, battery needs replacement. | Use ECO or Standard mode for longer runtime. Consider purchasing a spare battery or replacing the existing one if it no longer holds a charge. |

8. SPECIFICATIONS

- **Brand:** INTETURE
- **Model Name:** BP30
- **Special Feature:** 650W Brushless Motor, 55KPA Powerful Suction, Up to 70 Mins Runtime, Unique LED Green Light, Self-standing Feature, Rechargeable Wall Mount, Automatically Adjust Suction, LED Touch Screen, Fragrant Filter Layer Design, HEPA Washable
- **Filter Type:** Multi-layer High-density Filtration System
- **Included Components:** Main Body, Extra HEPA Filter, Aromatherapy Tablets x 2, 2-in-1 Brush, Sofa Brush, Mini Cleaning Tool, Battery, Charger, Multi-Function Rolling Brush, Wall-mounted Charging Dock, Adjustable Tube, Quick User Manual
- **Is Cordless?:** Yes
- **Capacity:** 1.8 Liters
- **Wattage:** 600 watts
- **Charging Time:** 4 Hours
- **Recommended Uses For Product:** Pet Hair Removal, Hard Floor, Carpet, Tile Floor, Home, Car Interiors
- **Form Factor:** Stick
- **Color:** Purple
- **Product Dimensions:** 13"L x 7"W x 17"H
- **Battery Description:** Lithium-Ion
- **Noise Level:** 64 Decibels
- **Battery Life:** 65 minutes (Note: Up to 70 minutes in ECO mode, approx. 15 minutes in MAX mode)

- **Manufacturer:** INTETURE
- **Controller Type:** Push Button, Touchpad Control
- **Motor Horsepower:** 650 Watts
- **Number of Speeds:** 4
- **Portable:** Yes
- **Indoor/Outdoor Usage:** Indoor
- **Vacuum Collection Technology:** Rotating Brush Roll
- **Item Weight:** 6 pounds
- **Power Source:** Battery Powered
- **Surface Recommendation:** All floors

9. WARRANTY & SUPPORT

INTETURE provides a 3-year free protection plan and 30-day hassle-free returns/exchanges. For any inquiries or assistance, our customer support team is available 24/7.

Please refer to your purchase documentation or visit the official INTETURE website for detailed warranty terms and contact information.