

[Manuals.plus](#) /

> [OneBlis](#) /

> OneBlis 70-inch Fireplace TV Stand User Manual

OneBlis 70-inch Fireplace TV Stand

OneBlis 70-inch Fireplace TV Stand User Manual

Model: 70-inch Fireplace TV Stand

INTRODUCTION

Thank you for purchasing the OneBlis 70-inch Fireplace TV Stand. This manual provides detailed instructions for assembly, operation, maintenance, and troubleshooting to ensure safe and efficient use of your new entertainment center. Please read this manual thoroughly before assembly and operation, and retain it for future reference.



Image: The OneBlis 70-inch Fireplace TV Stand, showcasing its design with integrated electric fireplace and LED lighting.

SAFETY INFORMATION

Important Safety Instructions:

- Read all instructions before using this appliance.
- Do not operate any fireplace with a damaged cord or plug, or if the heater malfunctions or has been dropped or damaged in any manner.

- Do not run cord under carpeting. Do not cover cord with throw rugs, runners, or similar coverings. Arrange cord away from traffic area and where it will not be tripped over.
- To prevent a possible fire, do not block air intakes or exhaust in any manner. Do not use on soft surfaces, like a bed, where openings may become blocked.
- Always plug heaters directly into a wall outlet/receptacle. Never use with an extension cord or relocatable power tap (outlet/power strip).
- This fireplace is hot when in use. To avoid burns, do not let bare skin touch hot surfaces.
- Extreme caution is necessary when any heater is used by or near children or invalids and whenever the fireplace is left operating and unattended.
- The electric fireplace component is CSA/ETL certified for safety.

PACKAGE CONTENTS

Your OneBlis Fireplace TV Stand will arrive in two separate packages. Please ensure you have received both packages before beginning assembly. In the event that packages arrive on different days, please allow for additional delivery time.



Image: The TV stand components are shipped in two separate boxes, which may arrive on different days.

Carefully unpack all components and check against the parts list provided in the assembly instructions (included in one of the packages). If any parts are missing or damaged, please contact customer support.

SETUP AND ASSEMBLY

Assembly typically takes approximately 2 hours with 1-2 people. Detailed assembly instructions with diagrams are included in your package. Please follow them carefully.

Key Assembly Considerations:


- **Tools Required:** Ensure you have the necessary tools as specified in the assembly guide.
- **Clear Area:** Assemble the unit on a soft, clean surface to prevent scratches.
- **Cable Management:** Utilize the integrated cable holes for a tidy setup.
- **Fireplace Installation:** The 36-inch electric fireplace unit is designed to fit into the central opening of the TV stand. Follow the specific instructions for securing it.



High-Gloss Surface



Upper Shelf Space



Cable Holes

Image: Details of the TV stand construction, including the high-gloss finish, internal shelf space, and cable management holes for organized wiring.



Particle Board



Large Storage Space



Cable Management



Mirror Craftsmanship


Image: Features such as particle board construction, ample storage, cable management solutions, and the reflective finish of the cabinet doors.

OPERATING INSTRUCTIONS

1. Electric Fireplace Operation

The integrated 36-inch electric fireplace offers various settings for ambiance and heating. Controls are located on the fireplace unit and may also be accessible via a remote control (if included).

36" WIDE ELECTRIC FIREPLACE



Telecontrol



Time Setting



LED Lights



Temperature Adjustment



Flame Color Adjustable



Flame Brightness Adjustable

Image: Overview of the 36-inch electric fireplace, highlighting its key features including remote control, timer, LED lights, temperature, and flame adjustments.




Image: Detailed view of the electric fireplace control panel, illustrating functions for timer, temperature, heat settings, flame color, and brightness adjustments.

- **Power On/Off:** Press the power button to turn the fireplace on or off.
- **Heat Settings:** Select between 750W (low heat) and 1500W (high heat) for optimal warmth. The fireplace can heat areas up to 400 square feet.
- **Temperature Control:** Adjust the desired room temperature from 60°F to 99°F. The unit will cycle on and off to maintain the set temperature.
- **Timer Function:** Set an automatic shut-off timer from 0 to 8 hours.
- **Flame Colors:** Choose from 12 different flame color options to match your mood or decor.
- **Flame Brightness:** Adjust the flame effect brightness through 5 available settings.

MULTI-COLOR FLAME AND LED CHANGE

● 12 flame colors

● 12 LED colors

● 5 levels dimmer




Image: Visual representation of the 12 distinct flame colors and 12 LED backlight colors, along with the 5 levels of flame brightness adjustment.




Image: Examples of different LED lighting colors and a gradient illustrating the five flame brightness settings from dim to bright.

2. LED Mood Lighting

The TV stand features integrated LED lights to enhance your room's ambiance.

12 LED COLORS CHANGE

According to the atmosphere of your room, you can switch it at will.



Image: The TV stand illuminated with blue LED lights, demonstrating the effect of the 12 available LED color options.

- **Color Selection:** Choose from 12 vibrant LED colors.
- **Brightness Adjustment:** Adjust the LED light brightness through five levels.
- Controls for the LED lights are typically located on the unit or via a dedicated remote control.

3. Integrated Power Outlet

The TV stand includes a built-in power outlet for convenient charging and powering of your devices.

Electrical Power Outlet



3 AC Outlets
125V/12A



1 USB & 1 TYPEC
5V/2.1A



Power Cord 4.92 FT
UL certification

Image: Detailed view of the integrated electrical power outlet featuring three AC outlets, one USB port, and one Type-C port for charging and powering devices.

- **AC Outlets:** 3 AC outlets, 125V/12A.
- **USB Ports:** 1 USB and 1 Type-C port, 5V/2.1A total output.
- **Power Cord:** Features a 4.92 ft UL certified power cord.
- Ensure devices connected do not exceed the maximum rated current for the outlets.

MAINTENANCE

Regular maintenance will help prolong the life and appearance of your TV stand and fireplace.

- **Cleaning the Stand:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish.
- **Cleaning the Fireplace:** Ensure the fireplace is turned off and unplugged before cleaning. Use a soft, dry cloth to clean the exterior. Do not spray liquids directly onto the unit.
- **Ventilation:** Keep the air intake and exhaust vents of the fireplace clear of dust and obstructions to ensure proper operation and prevent overheating.

- **Cord Care:** Periodically inspect the power cord for any signs of damage. If damaged, discontinue use and contact customer support.

TROUBLESHOOTING


Problem	Possible Cause	Solution
Fireplace does not turn on.	No power, power cord not fully plugged in, circuit breaker tripped.	Check power connection. Ensure the wall outlet is functional. Reset circuit breaker if necessary.
No heat output from fireplace.	Heat function not activated, temperature setting too low, overheat protection activated.	Ensure heat setting is on. Increase desired temperature. If overheat protection activated, turn off unit, unplug, wait 15 minutes, then plug back in. Clear any obstructions from vents.
Flame effect not working.	Flame effect not activated, bulb issue (rare for LED).	Ensure flame effect is turned on via controls.
LED mood lights not working.	LED function not activated, power issue.	Ensure LED lights are turned on and brightness is adjusted. Check power connection.
Power outlets not providing power.	No power to the stand, overloaded circuit.	Check the main power connection to the TV stand. Ensure total wattage of connected devices does not exceed the outlet's capacity.

If you encounter issues not listed here or if solutions do not resolve the problem, please contact OneBlis customer support.

SPECIFICATIONS

PRODUCT SIZE

Quality Home Experience



① Fireplace

② TV Console Table



Come With **TWO** Packages



Image: Dimensional drawing of the 70-inch TV console and the 36-inch fireplace insert, detailing overall width, height, and depth, as well as internal compartment sizes.

Feature	Detail
Model Name	70-inch Fireplace TV Stand
Brand	OneBlis
Overall Dimensions	70" W x 13.78" D x 25.2" H (approximate)
Fireplace Insert Size	36" W x 13.7" H (approximate)
TV Compatibility	Up to 80 inches
Heating Area	Up to 400 sq ft
Heat Output	750W / 1500W
Temperature Range	60°F - 99°F
Flame Colors	12 options
Flame Brightness	5 levels

Feature	Detail
LED Mood Light Colors	12 options
LED Mood Light Brightness	5 levels
Power Outlets	3 AC (125V/12A), 1 USB (5V/2.1A), 1 Type-C (5V/2.1A)
Power Cord Length	4.92 ft
Certifications	CSA/ETL (Fireplace), UL (Power Cord)
Material	Particle Board

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact OneBlis customer support directly. If you have any questions, require assistance with assembly, or need troubleshooting help, please reach out to our support team.

Customer Support: Please visit the OneBlis official website or refer to your purchase receipt for contact details.