Keter 259805

Keter Ashwood 100 Gallon Resin Deck Box

Model: 259805 | Brand: Keter

Introduction

This manual provides essential information for the safe and effective use of your Keter Ashwood 100 Gallon Resin Deck Box. Please read all instructions carefully before assembly and use. Keep this manual for future reference.
The Keter Ashwood 100 Gallon Resin Deck Box is designed for outdoor storage, offering a durable and aesthetically pleasing solution for patio cushions, garden tools, pool toys, and other outdoor essentials. Constructed with innovative DecoCoat technology, it provides the look and feel of natural wood without the maintenance.

Safety Information

- **Adult Assembly Required:** This product requires adult assembly. Ensure all parts are correctly installed before use.
- **Weight Capacity:** Do not exceed the maximum weight capacity of 660 lbs (total) or 165 lbs (interior).
- **Not for Seating:** While sturdy, this deck box is not designed as a primary seating solution. Avoid prolonged sitting or standing on the lid.
- **Child Safety:** To prevent entrapment, ensure children do not play inside the deck box. The lid features a soft-close mechanism to prevent sudden closure.
- **Ventilation:** Ensure adequate ventilation if storing items that may generate heat or moisture.
- **Secure Placement:** Place the deck box on a flat, stable surface to prevent tipping.
- **Locking Mechanism:** Utilize the padlock-compatible feature for added security of stored items. Padlock not included.

Package Contents

Before beginning assembly, ensure all components are present and undamaged. If any parts are missing or damaged, do

not proceed with assembly. Contact Keter customer support for assistance.

- Lid Panel
- Side Panels (2)
- Front Panel
- Back Panel
- Base Panel
- Hydraulic Pistons (2)
- Fasteners and Hardware Kit
- Instruction Manual

Setup and Assembly

Assembly typically takes approximately 30 minutes with two people. A power drill may assist with fastening screws, but manual tools are sufficient. Follow the numbered steps below.

1. **Prepare the Area:** Choose a flat, level surface for assembly. Ensure you have enough space to work around the deck box.
2. **Attach Side Panels to Base:** Connect the side panels to the base panel, ensuring they click securely into place. Refer to the included diagrams for correct orientation.
3. **Install Front and Back Panels:** Securely attach the front and back panels to the assembled base and side panels. Verify all connections are firm.
4. **Attach Hydraulic Pistons:** Mount the hydraulic pistons to the designated points on the side panels and the lid. These pistons assist with smooth opening and soft closing of the lid.
5. **Secure the Lid:** Carefully align and attach the lid to the main body of the deck box, ensuring the hinges and pistons operate correctly.
6. **Final Checks:** Confirm all panels are securely fastened and the lid opens and closes smoothly.



Image: Keter Ashwood 100 Gallon Resin Deck Box dimensions and capacity overview.



Image: Key features of the Keter Ashwood Deck Box, including hydraulic pistons and wood-grain texture.

Your browser does not support the video tag.

Video: An overview of the Keter Signature Collection, demonstrating the assembly and features of various Keter products, including the deck box's lid mechanism.

Operating Instructions

- **Opening the Lid:** Gently lift the lid from the front. The hydraulic pistons will assist in opening it fully and holding it in place.
- **Closing the Lid:** Pull the lid down gently. The soft-close mechanism will ensure it closes slowly and safely, preventing sudden drops.
- **Locking the Deck Box:** The deck box is padlock compatible. Align the latch mechanism and insert a standard padlock (not included) to secure your belongings.

DecoCoat Deck Boxes vs Wood Deck Boxes

	KETER DECOCOAT	WOOD
No Maintenance Required	✓	✗
Will Never Splinter, Rot, or Fade	✓	✗
Withstands Sun, Rain, & Extreme Weather	✓	✗
Easy Assembly	✓	✗
Durability Season After Season	✓	✗
Double Wall Construction	✓	✗

Image: Hydraulic piston for easy lid opening and soft closing.




Image: Deck box with lid open, demonstrating versatile storage for items like patio cushions.

Maintenance

The Keter Ashwood Deck Box is designed for low maintenance and durability. Its DecoCoat resin material is UV-protected and weather-resistant, preventing fading, warping, rotting, rusting, denting, or peeling.

- **Cleaning:** Clean the deck box periodically with a mild soap and water solution. Use a soft cloth or sponge. Avoid abrasive cleaners or harsh chemicals, as these can damage the surface.
- **Weather Protection:** The resin material is designed to withstand various weather conditions. However, for prolonged periods of extreme weather, consider placing the deck box in a sheltered area or covering it.
- **Inspection:** Periodically check all fasteners and connections to ensure they remain tight.



Image: Deck box designed to stand up to all weather conditions, being UV-resistant and water-resistant.



Image: Water resistance of the deck box lid.




Image: Comparison of DecoCoat material versus natural wood over time, showing DecoCoat's lasting appearance.

Troubleshooting

- **Lid Not Closing Properly:** Check for any obstructions inside the box or along the edges of the lid. Ensure the hydraulic pistons are correctly installed and not damaged.
- **Water Inside the Box:** While the deck box is water-resistant, extreme weather conditions or improper assembly can lead to water ingress. Verify all panels are securely connected and the lid forms a tight seal. Ensure the box is not placed in an area where water can pool around its base.
- **Difficulty During Assembly:** Re-read the assembly instructions carefully. Ensure all parts are oriented correctly and that you are using the appropriate fasteners. Do not force parts together; if they don't fit, recheck the steps.

Specifications

Feature	Detail
Brand	Keter
Model Number	259805
Color	Ashwood
Material	Resin
Capacity	100 Gallons
Item Dimensions (L x W x H)	24"L x 48.4"W x 27.8"H
Item Weight	41.34 Pounds
Storage Volume	100 Gallons
Total Weight Capacity	660 lbs
Interior Weight Capacity	165 lbs
Special Feature	Lockable (padlock not included)
Water Resistance Level	Water Resistant
Opening Mechanism	Hinge with Hydraulic Pistons



Image: Detailed specifications and sizing information for the deck box.

Warranty Information

Keter products are known for their durability and quality, backed by over 75 years of experience. While specific warranty terms are not detailed in this document, Keter products are designed to be long-lasting and maintenance-free, resisting common issues like warping, rotting, rusting, denting, or peeling.

Support

Should you require assistance with your Keter Ashwood 100 Gallon Resin Deck Box, including assembly questions, missing parts, or troubleshooting, please contact Keter's dedicated customer support team based in the USA.
For further support, visit the official Keter website or refer to the contact information provided with your purchase documentation.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question