



Manuals.plus /

› Aeitto /

› Aeitto HIM001 Countertop Ice Maker User Manual

Aeitto HIM001

Aeitto HIM001 Countertop Ice Maker User Manual

Model: HIM001

IMPORTANT SAFETY INSTRUCTIONS

Please read all instructions carefully before using your Aeitto HIM001 Ice Maker. Retain this manual for future reference.

- Ensure the power outlet voltage matches the appliance's rating.
- Do not immerse the appliance, power cord, or plug in water or other liquids.
- Unplug the ice maker before cleaning, servicing, or when not in use.
- Keep the appliance away from heat sources and direct sunlight.
- Place the ice maker on a stable, level surface with adequate ventilation around it.
- Do not operate the appliance with a damaged cord or plug.
- This appliance is not intended for use by persons (including children) with reduced physical, sensory or mental capabilities, or lack of experience and knowledge, unless they have been given supervision or instruction concerning use of the appliance by a person responsible for their safety.
- Use only potable water in the ice maker.

PRODUCT OVERVIEW

The Aeitto HIM001 is a compact countertop ice maker designed for convenience and efficiency, producing bullet-shaped ice cubes in two sizes.



Image: The Aeitto HIM001 Countertop Ice Maker in black, filled with bullet ice cubes, next to a glass of iced beverage.

Key Components:

- **Control Panel:** ON/OFF button, SELECT button, and indicator lights (POWER, ADD WATER, ICE FULL, SMALL, LARGE, CLEAN).
- **Ice Basket:** Removable basket for collecting ice cubes.
- **Ice Scoop:** For convenient ice retrieval.
- **Water Reservoir:** Internal tank for water supply.
- **Ice Making Mechanism:** Evaporator rods and ice tray.
- **Viewing Windows:** Two windows to monitor ice production and storage levels.

26Lbs of Ice Per Day



Image: The Aeitto HIM001 Ice Maker with its lid open, revealing the ice basket filled with ice cubes. Text indicates "26Lbs of Ice Per Day" and "99+ Cups".

SETUP AND FIRST USE

Unpacking:

- Remove all packaging materials and check for any damage.
- Ensure all accessories (ice basket, ice scoop) are present.

Placement:

- Place the ice maker on a flat, stable surface, away from direct sunlight and heat sources.
- Allow at least 4 inches (10 cm) of space around the unit for proper ventilation.
- Before first use, let the unit stand upright for at least 2 hours if it has been tilted during transport.

Sleek&Space-Saving Design

Without taking up valuable counter space



Image: The Aeitto HIM001 Ice Maker on a countertop, highlighting its compact dimensions (8.74"D x 10.43"W x 10.98"H) and sleek design.

Initial Cleaning:

- Clean the interior with a soft cloth and warm water with a mild detergent. Rinse thoroughly.
- Run a self-cleaning cycle (see Maintenance section) before making ice for consumption.
- Discard the first 2-3 batches of ice produced to ensure cleanliness.

OPERATING INSTRUCTIONS

1. **Add Water:** Open the lid and fill the water reservoir with potable water up to the MAX fill line. Do not overfill.
2. **Power On:** Plug the ice maker into a grounded electrical outlet. Press the **ON/OFF** button to start the ice making process. The POWER indicator will illuminate.
3. **Select Ice Size:** Press the **SELECT** button to choose between SMALL or LARGE ice cube sizes. The corresponding indicator light will illuminate.

Two Sizes of Ice Cubes



Image: Illustration showing two sizes of bullet ice cubes: Small (17*20*27MM) and Large (24*19*27MM).

- Ice Production:** The ice maker will begin producing ice. The first batch of 9 ice cubes will be ready in approximately 6 minutes.

Release Ice in 6 Mins

No need to wait for a long time



Image: Close-up of the ice making mechanism, showing 9 bullet-shaped ice cubes forming. Text indicates "9 cubes / 6 Mins" and "26 Lbs / 24H".

5. **Ice Full Indicator:** When the ice basket is full, the **ICE FULL** indicator will light up, and the ice making process will pause. Remove ice to resume production.
6. **Add Water Indicator:** If the water level in the reservoir is too low, the **ADD WATER** indicator will light up. Add more water and press the **ON/OFF** button to restart.
7. **Storage:** The ice maker does not have a refrigeration function. It is recommended to transfer ice to a freezer for long-term storage.

MAINTENANCE

Self-Cleaning Function:

The Aeitto HIM001 features an automatic self-cleaning function to maintain hygiene and prevent limescale buildup. It is recommended to use this function weekly.

1. Ensure the ice basket is empty.

2. Fill the water reservoir with clean water up to the MAX line.
3. Press and hold the **ON/OFF** button for 5 seconds. The **CLEAN** indicator will illuminate, and the machine will begin a 15-minute cleaning cycle.
4. Once the cycle is complete, drain the water from the reservoir by removing the drain plug located at the bottom of the unit.
5. Rinse the interior with fresh water and drain again.

Self-Cleaning Function

Save your time and energy



Fresh Ice



Removes
Limescale



Keeps Healthy



Image: Diagram illustrating the three steps of the self-cleaning function: 1. Add water, 2. Press and hold ON/OFF for 5s, 3. Self-cleaning for 15 Mins. Icons represent Fresh Ice, Removes Limescale, and Keeps Healthy.

General Cleaning:

- Always unplug the unit before cleaning.
- Clean the exterior with a soft, damp cloth. Do not use abrasive cleaners.
- Remove the ice basket and wash it with warm, soapy water. Rinse and dry thoroughly.
- For thorough internal cleaning, a solution of water and vinegar (10:1 ratio) can be used in the self-cleaning cycle. Follow with several plain water cycles to rinse.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Ice maker not working.	No power, unit unplugged, or power outage.	Check power connection, ensure outlet is functional.
"ADD WATER" indicator is on.	Water reservoir is empty or water level is too low.	Add potable water to the MAX fill line and restart the unit.
"ICE FULL" indicator is on.	Ice basket is full.	Remove ice from the basket. Ice production will resume automatically.
Ice cubes are too small or clumpy.	Water temperature is too high, or ambient temperature is too high.	Use colder water. Ensure the unit is in a cool, well-ventilated area. Select LARGE ice size.
Ice maker is noisy.	Normal operation sounds (compressor, water pump).	This is usually normal. Ensure the unit is on a level surface.
Water leaks from the unit.	Drain plug not properly sealed, or unit is overfilled.	Check and secure the drain plug. Do not overfill the water reservoir.

SPECIFICATIONS

Feature	Detail
Model Number	HIM001
Brand	Aeitto
Product Dimensions (D x W x H)	8.74" x 10.43" x 10.98"
Weight	Approximately 14.33 Pounds
Voltage	110 Volts
Daily Ice Production	Up to 26 lbs / 24 hours
Ice Production Cycle	9 cubes in approximately 6 minutes
Ice Cube Sizes	Small (17*20*27MM), Large (24*19*27MM)
Features	Self-Cleaning Function, Dual Viewing Windows, Ice Full/Add Water Indicators

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the warranty card included with your product or visit the official Aeitto website. You may also contact Aeitto customer service directly for assistance with product issues or inquiries.

For more products and information, visit the Aeitto Store on Amazon.