

LOUTOC SRP9232D

LOUTOC Universal TV Remote Control

Model: SRP9232D

INTRODUCTION

This instruction manual provides detailed guidance for setting up and operating your LOUTOC Universal TV Remote Control, Model SRP9232D. This remote is designed to control a wide range of electronic devices, including televisions, DVD/Blu-ray players, soundbars, and streaming media players. Please read this manual thoroughly to ensure proper use and to maximize your remote control's functionality.



Image: The LOUTOC Universal TV Remote Control, Model SRP9232D.

PRODUCT FEATURES

- **Universal Compatibility:** Controls over 5 types of devices, including TVs, DVD/Blu-ray players, soundbars, streaming media players, and set-top boxes.
- **Wide Brand Support:** Compatible with major TV brands such as Samsung, LG, Hisense, TCL, Vizio, Sony, Onn, Toshiba, Philips, Element, Westinghouse, Sharp, Emerson, Sanyo, RCA, and more. Also supports audio/video brands like Sony, LG, Panasonic, Samsung, Bose, Vizio.
- **Extended Range:** Operates effectively up to 26 feet (approximately 8 meters).
- **Fast Response:** Features a 0.2-second fast response time for immediate command execution.
- **Durable Design:** Tested for over 50,000 presses, ensuring long-lasting durability.
- **Power Source:** Requires 2 AAA batteries (not included).

One Remote for 5+ Devices



Image: The remote control is capable of operating multiple device types, including TV, Soundbar Audio, DVD/Blu-ray Player, Streaming Media Player, and Set Top Boxes.

SETUP INSTRUCTIONS

1. Battery Installation

Before using the remote control, install two new 1.5V AAA batteries. Ensure correct polarity (+/-) when inserting the batteries. Do not mix old and new batteries or different battery brands.

2. Pairing Methods

The remote control offers two methods for pairing with your devices:

Method 1: Manual Code Entry

1. Locate your device's specific 4-digit code in the provided CODE LIST.
2. Press and hold the **SETUP** button on the remote until the remote's red indicator light turns on.
3. Press and release the corresponding device button (e.g., **TV**, **STR**, **AUD**) for the device you wish to control.
4. Enter the 4-digit code for your device using the number buttons. The red light will turn off after the code is entered.


5. Point the remote at the device and test the buttons. If the buttons do not function as expected, repeat steps 2-5 using the next code listed for your device until proper functionality is achieved.

Method 2: Automatic Pairing

For automatic pairing, please refer to pages 8-9 of the physical user manual included with your product for detailed instructions. This method automatically scans for compatible codes.


Method 1: (1-3)

Step 1




Press and hold down the **SETUP** button for 3 seconds until the red light on the remote turns on

Step 2



Press and release the device button on the remote for the type of device you wish to control (for example **TV STR AUD**)

Step 3



Enter the 4-digit code from code list (come with instruction)

Method 2:

Programming Your Remote

1. Manually turn on the device you wish to control.
NOTE: The Auto Code Search process cannot be used for devices without power ON/OFF capability. Use the Direct Code Entry method in these cases.
2. Press and hold down the **SETUP** button on the remote until the red light on the remote control turns on. Release the **SETUP** button. The red light will remain on.
NOTE: The red light will either be a small light at the top of the remote or the power ON/OFF button.
3. Press and release the device button on the remote for the type of device you wish to control, (for example **TV, STRM, AUX**). The red light will blink once and remain on.
4. With the remote pointed at the device, press and release the **POWER** button on the remote. The remote will send 10 different codes to the device. The red light will blink once for each code and remain on after sending the 10 codes.
Did the device turn off?
 - If **YES**, go to Step 5.
 - If **NO**, repeat Step 4 to test the next 10 codes.
5. Manually turn the device back on.
6. With the remote pointed at the device, press and release the **VOL ^** button. The remote will re-send the first code of the 10 codes from Step 4. The red light will blink once and remain on.
Did the device turn off?
 - If **YES**, you have found a code for the device. Press and release the same device button you pressed in Step 3. This will

8

Automatic pairing method on pages 8-9 of the manual

Image: Visual guide for Method 1 (Manual Code Entry) and a reference to Method 2 (Automatic Pairing) in the manual.

OPERATING INSTRUCTIONS

Once paired, your LOUOC Universal TV Remote Control can operate your devices using its various buttons. Below is a general overview of common button functions:



Image: Labeled diagram of the remote control, highlighting each button and its corresponding function.

- **Power Button:** Turns devices ON/OFF.
- **Number Buttons (0-9):** Enter numbers for direct channel selection or code entry.
- **OK Button:** Confirms selections or enters menus.
- **Directional Pad (Up/Down/Left/Right):** Navigates on-screen menus and selections.
- **Volume Up/Down:** Adjusts the volume level.
- **Channel Up/Down:** Changes TV channels.
- **Mute Button:** Mutes or unmutes audio.
- **Input Button:** Selects video input sources.
- **Menu Button:** Displays the on-screen menu.
- **APP Button:** Quick access to popular streaming applications (e.g., Netflix, YouTube).
- **Playback Controls (Play, Pause, Stop, Rewind, Fast Forward):** Controls media playback on compatible devices.
- **Colored Buttons (A, B, C, D):** Provide additional features for DVRs, cable, and satellite receivers, depending on the device.

COMPATIBILITY

The LOUOTC Universal TV Remote Control is designed for broad compatibility:

Compatible TV Brands:

- Samsung, LG, Hisense, TCL, Vizio, Sony, Onn, Toshiba, Philips, Element, Westinghouse, Sharp, Emerson, Sanyo, RCA, and others.

Compatible Other Devices:

- DVD Players, Blu-ray Players, Soundbars, Streaming Media Players, Set Top Boxes, DVRs, VCRs, Audio Devices.
- Supported brands include Sony, LG, Panasonic, Samsung, Bose, Vizio, and others.

Compatible with TV Brands:



- For Samsung TVs
- For LG TVs
- For Hisense TVs
- For TCL TVs
- For Sony TVs
- For Vizio TVs
- For Onn TVs
- For Toshiba TVs
- For Philips TVs

Image: The remote control is compatible with numerous TV brands, including Samsung, LG, Hisense, TCL, Sony, Vizio, Onn, Toshiba, and Philips.

Universal Remote for DVD/Blu ray Player/Soundbar/ Streaming Media Player:

For brand Sony, LG, Panasonic, Samsung, Bose, Vizio ect..



Image: The remote control is compatible with various DVD/Blu-ray players, soundbars, and streaming media players from brands like Sony, LG, Panasonic, Samsung, Bose, and Vizio.

TROUBLESHOOTING

If you encounter issues with your LOUTOC Universal TV Remote Control, try the following steps:

- **Remote Not Responding:** Ensure fresh AAA batteries are correctly installed. Check if the remote's red indicator light flashes when a button is pressed.
- **Device Not Responding:** Verify that the remote is pointed directly at the device's IR receiver. Ensure there are no obstructions between the remote and the device.
- **Incorrect Functionality:** If buttons perform incorrect actions, re-attempt the pairing process (Method 1 or Method 2) using a different code from the CODE LIST for your specific device.
- **Limited Functionality:** Some advanced or brand-specific functions may not be supported by a universal remote.
- **Interference:** Ensure no other devices are causing IR interference.

SPECIFICATIONS

Product Dimensions	6.7 x 1.8 x 0.7 inches
Item Weight	2.08 ounces
Model Number	SRP9232D
Brand	LOUTOC
Special Feature	Ergonomic, Lightweight, Universal
Max Number of Supported Devices	1 (at a time, configured for specific device type)
Compatible Devices	DVD/Blu-ray Player, Set Top Box, Television

Official Product Video

Your browser does not support the video tag.

Video: An overview of the LOUTOC Universal TV Remote Control, highlighting its compatibility with various brands like Samsung, LG, Hisense, and TCL.

Warranty and Support

For warranty information or technical support, please refer to the contact details provided with your product packaging or visit the official LOUTOC website. Keep your purchase receipt for warranty claims.