Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

KAMINIO EF05

KAMINIO Leni Electric Fireplace Heater - User Manual

Model: EF05

1. Important Safety Instructions

Please read all instructions carefully before using your KAMINIO Leni Electric Fireplace Heater. Keep this manual for future reference.

- **Electrical Safety:** Always plug the heater directly into a wall outlet. Do not use extension cords or power strips. Ensure the voltage matches the rating label on the appliance.
- **Overheating Protection:** The unit is equipped with an automatic overheat protection system. If the heater overheats, it will shut off automatically. Unplug the unit, wait 10-15 minutes for it to cool down, then plug it back in. If it continues to shut off, contact customer support.
- **Clearance:** Maintain a minimum distance of 1 meter (3 feet) from combustible materials such as furniture, curtains, bedding, paper, clothes, and other objects.
- **Ventilation:** Do not block air intakes or exhaust openings. Ensure proper ventilation to prevent overheating.
- **Water Exposure:** Do not use the heater in bathrooms, laundry areas, or similar indoor locations where it may come into contact with water. Never immerse the heater in water.
- **Children and Pets:** The exterior surface of the heater remains cool to the touch (Cool-Touch surface), reducing the risk of burns. However, always supervise children and pets around the appliance.
- **Open Window Detection:** The heater features an open window detection function, which automatically turns off the heating if an open window is detected, saving energy.
- **Maintenance:** Unplug the heater before cleaning or performing any maintenance.



Figure 1: Safety Features. This image illustrates the safety features of the KAMINIO Leni Electric Fireplace, including its cool-touch surface, overheat protection, and open window detection system, ensuring safe operation around children and pets.

2. Setup and Installation

The KAMINIO Leni Electric Fireplace is designed for easy "Plug & Play" setup, requiring no complex installation or professional assistance.

1. **Unpacking:** Carefully remove the fireplace from its packaging. Retain packaging materials for future transport or storage.
2. **Foot Assembly:** Attach the feet to the base of the fireplace. This typically involves aligning the feet with the designated slots and securing them with the provided screws. This process usually takes less than 5 minutes.
3. **Placement:** Place the fireplace on a stable, level surface in your desired room. Ensure there is adequate clearance from walls and furniture as specified in the safety instructions. The stable construction prevents tipping.
4. **Power Connection:** Plug the power cord directly into a standard electrical wall outlet. Do not use extension cords or adapters.



Figure 2: Placement and Stability. This image shows the KAMINIO Leni Electric Fireplace placed in a living room, highlighting its stable construction and ease of relocation. It also mentions optional stove pipe for expansion and a large support surface for decoration.

3. Operating Instructions

Your KAMINIO Leni Electric Fireplace offers both realistic flame effects and efficient heating functions, which can be operated independently.

3.1 Controls

The control panel is typically located on the unit. Refer to the diagram below for button identification (if available on the unit itself).

- **Power Button:** Turns the unit ON/OFF.
- **Flame Effect Button:** Activates or deactivates the 3D flame effect. This can be used independently of the heating function.
- **Heat Settings Button:** Cycles through the heating modes:
  - **Mode 1:** Low heat setting (e.g., 900 watts).
  - **Mode 2:** High heat setting (e.g., 1800 watts).

- **Off:** Heating function is off.

3.2 Using the Heater

1. **Turn On:** Press the Power button to turn on the fireplace. The flame effect will usually activate automatically.
2. **Activate Flame Effect:** If the flame effect is not on, press the Flame Effect button. The realistic 3D flame technology provides an ambient glow.
3. **Select Heat Level:** Press the Heat Settings button to choose your desired heat output. The two-level heating system quickly and quietly warms rooms up to 30 m².
4. **Turn Off:** Press the Power button to turn off the unit.



Figure 3: Technology and Heating System. This image highlights the KAMINIO Leni's modern technology, featuring a realistic and vivid 3D flame effect and a 2-level heating system (900/1800 watts) that can be used separately.



Figure 4: Efficient Heating. This image details the efficient heating capabilities of the KAMINIO Leni, including rapid heating, low noise operation, suitability for rooms up to 30 m², and energy savings due to modern components.

4. Maintenance

Regular maintenance ensures the longevity and optimal performance of your electric fireplace.

- **Cleaning:**
  - Always unplug the unit and allow it to cool completely before cleaning.
  - Use a soft, damp cloth to wipe the exterior surfaces. Do not use abrasive cleaners, sprays, or harsh chemicals.
  - Gently vacuum the air intake and exhaust vents to remove dust and debris.
- **Storage:** If storing the fireplace for an extended period, unplug it and store it in a cool, dry place, preferably in its original packaging.
- **Light Bulb Replacement (if applicable):** The 3D flame effect uses LED technology, which typically has a long lifespan and does not require frequent bulb replacement. If the flame effect malfunctions, contact customer support.

5. Troubleshooting

If you encounter any issues with your KAMINIO Leni Electric Fireplace, please refer to the following troubleshooting guide:

Problem	Possible Cause	Solution
Unit does not turn on.	No power supply; Power button not pressed; Overheat protection activated.	Ensure the unit is plugged into a working outlet. Press the Power button. Unplug, wait 10-15 minutes, then plug back in.
No heat output.	Heat setting is off; Overheat protection activated; Open window detected.	Press the Heat Settings button to select a heat level. Check for open windows. Unplug, wait, then plug back in.
Flame effect not working.	Flame effect button not pressed; Internal malfunction.	Press the Flame Effect button. If the issue persists, contact customer support.
Unit makes unusual noise.	Dust in fan; Internal component issue.	Unplug and gently vacuum vents. If noise continues, contact customer support.

If the problem persists after trying these solutions, please contact KAMINIO customer support.

6. Specifications

Detailed technical specifications for the KAMINIO Leni Electric Fireplace Heater.

Feature	Detail
Brand	KAMINIO
Model Number	EF05
Color	Black
Product Dimensions (L x W x H)	23 cm x 37.5 cm x 51 cm
Product Weight	5.1 kg (approx. 4.9 kg as per image)
Material	Metal, Plastic
Special Features	3D Flame Effect, LED Flame, Overheat Protection, Open Window Detection
Power Source	Corded Electric
Installation Type	Freestanding
Heating Levels	2 levels (e.g., 900W/1800W)
Max Room Size	Up to 30 m^2



Figure 5: Product Dimensions and Weight. This image provides a visual representation of the KAMINIO Leni Electric Fireplace, detailing its height (51 cm), width (37.5 cm), depth (23 cm), and weight (4.9 kg).

7. Warranty and Support

KAMINIO is committed to providing high-quality products and customer satisfaction.

- **Warranty Information:** Specific warranty details may vary. Please refer to the documentation included with your purchase or contact the seller for information regarding warranty coverage.
- **Customer Support:** For any questions, technical assistance, or warranty claims, please contact the seller, PIcommerce GmbH, or visit the official KAMINIO brand store.
    - Seller: PIcommerce GmbH
    - KAMINIO Brand Store: Visit KAMINIO Store

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FNCY2NZZ

More documents and user manuals: **https://manuals.plus/**