

[Manuals.plus](#) /

› [SICOTAS](#) /

› SICOTAS 60" Rattan Console Table Instruction Manual

SICOTAS B0FND1V7C5

SICOTAS 60" Rattan Console Table Instruction Manual

MODEL: B0FND1V7C5

1. Product Overview

The SICOTAS 60" Rattan Console Table is a versatile furniture piece designed to enhance various living spaces. It features a warm wood grain finish and drawers adorned with woven rattan decor, offering a distinctive texture that complements coastal and farmhouse boho styles. This table provides ample storage and can function as a side table, sofa table, entryway table, coffee bar, or TV stand.



Figure 1: SICOTAS 60" Rattan Console Table, Reclaimed Caramel Oak.

2. Safety Information

- Always use two people when moving or assembling the table due to its weight.
- Ensure the table is properly assembled and stable before use.
- Do not overload the table as it may cause instability.
- Always follow the assembly instructions carefully to prevent injury.

3. Package Contents

Your SICOTAS Rattan Console Table package includes:

- All necessary furniture components (tabletop, side panels, shelves, drawer parts).
- Assembly Guide with detailed instructions.
- Installation Tool (typically an Allen wrench).
- All required hardware (screws, dowels, drawer slides).

Each part is clearly labeled for easy identification during assembly.

4. Assembly Instructions

Assembly of the SICOTAS Rattan Console Table is designed to be straightforward. Please follow the included Assembly Guide step-by-step. All parts are labeled, and the necessary tools are provided.

Assembly Tips:

- Clear a spacious area for assembly to avoid misplacing parts.
- Identify all components and hardware before starting.
- Do not overtighten screws to prevent damage to the engineered wood.
- For best results and safety, assemble with a second person.

Your browser does not support the video tag.

Video 1: Official SICOTAS 3 Drawer Console Table assembly and feature overview. This video demonstrates the assembly process and highlights key features of the console table.

5. Operating and Usage

The SICOTAS Rattan Console Table is designed for versatile use in various rooms. Its dimensions (14"D x 60"W x 32"H) make it suitable for:

- **Entryway:** Ideal for keys, mail, and decorative items.
- **Living Room:** Functions as a sofa table, accent table, or TV stand.
- **Hallway/Foyer:** Provides a stylish surface and storage in narrow spaces.

Storage Features:

- **Three Large Drawers:** Each drawer measures 12"D x 19"W x 5.8"H, offering concealed storage for smaller items, cables, or personal belongings.
- **Two-Tier Shelf:** The open bottom shelf provides additional space for baskets, books, or decorative displays.
- **Anti-Slip Raised Edge:** The tabletop features a raised edge to prevent items from falling off, especially useful when placed behind a sofa or in high-traffic areas.

Rattan Console Table Size



Figure 2: Ample storage provided by the three large drawers.

Anti-Slip Raised Edge

Providing a stable & safe surface for various items in any room



Figure 3: The anti-slip raised edge on the tabletop helps secure items.



Figure 4: The console table can serve as a narrow TV stand.

6. Maintenance

To maintain the appearance and longevity of your SICOTAS Rattan Console Table, follow these simple care instructions:

- Wipe the surface with a damp cloth to remove dust and spills.
- Avoid using harsh chemicals or abrasive cleaners, as these may damage the finish.
- Protect the surface from direct sunlight and extreme temperatures to prevent warping or fading.
- Periodically check and tighten any loose hardware to ensure stability.

7. Troubleshooting

If you encounter any issues with your console table, please refer to the following common solutions:

- **Wobbling:** Ensure all screws and fasteners are securely tightened. Check that the table is placed on a level surface.
- **Drawer Sticking:** Verify that the drawer slides are correctly installed and free from obstructions. Apply a small amount of silicone lubricant to the slides if necessary.
- **Missing Parts:** If any parts are missing upon arrival, please contact SICOTAS customer support with your product model and a description of the missing items.

8. Specifications

Feature	Specification
Brand	SICOTAS
Model Number	Console Table (B0FND1V7C5)
Product Dimensions	14"D x 60"W x 32"H
Item Weight	43 Pounds
Frame Material	Engineered Wood
Color	Reclaimed Caramel Oak
Number of Drawers	3
Drawer Dimensions	12"D x 19"W x 5.8"H (each)
Style Name	Farmhouse
Product Care Instructions	Wipe with Damp Cloth
Required Assembly	Yes
Included Components	Assembly Guide, Installation Tool

9. Warranty and Support

For warranty information or customer support, please refer to the contact details provided with your purchase documentation or visit the official SICOTAS website. Ensure you have your model number (B0FND1V7C5) and proof of

purchase ready when contacting support.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question