



[Manuals.plus](#) /

› [StarAndDaisy](#) /

› StarAndDaisy Luna Luxe Foldable Baby Stroller Instruction Manual

StarAndDaisy Luna Luxe Baby Stroller

StarAndDaisy Luna Luxe Foldable Baby Stroller

Instruction Manual

1. INTRODUCTION

Thank you for choosing the StarAndDaisy Luna Luxe Foldable Baby Stroller. This manual provides essential information for the safe assembly, operation, and maintenance of your stroller. Please read all instructions carefully before use and keep this manual for future reference. Your child's safety is our top priority.

Important Safety Warnings

- Always secure your child with the safety harness.
- Never leave your child unattended in the stroller.
- Ensure the stroller is fully locked and stable before placing your child in it.
- Do not overload the storage basket or hang bags on the handle, as this can cause instability.
- Avoid placing hot liquids or heavy objects near your child.
- This stroller is designed for children aged 0-3 years, with a maximum weight recommendation of 15 kg.

2. PRODUCT FEATURES

The StarAndDaisy Luna Luxe Stroller is designed for comfort, safety, and convenience. Key features include:

- **Foldable Design:** Lightweight and easy to fold for travel and storage.
- **Multi-Level Recline:** Adjustable backrest and footrest for various positions, from upright to sleeping.
- **Adjustable Canopy:** Large canopy provides protection from sun and wind.
- **360° Swivel & Lockable Front Wheels:** Ensures smooth maneuverability and stability.
- **5-Point Safety Harness:** Provides maximum security for your child.
- **Removable Tray:** Convenient for feeding, toys, or snacks.
- **Shock Absorption:** Four-wheel shock absorption system for a smoother ride.

Luna Luxe Baby Stroller

Every journey made easier with baby.



Figure 2.1: Overview of the Luna Luxe Baby Stroller's main features.

3. SETUP AND ASSEMBLY

Your StarAndDaisy Luna Luxe Stroller comes partially assembled. Follow these steps to complete the setup:

1. **Unfolding the Stroller:** Release the folding latch (if present) and pull the handle upwards until the frame locks into place. Ensure all locking mechanisms are engaged with an audible click.
2. **Attaching Wheels:** Insert the front and rear wheels into their respective slots until they click securely.
3. **Attaching the Canopy:** Secure the canopy to the frame by attaching the clips or snaps provided.
4. **Installing the Tray:** Align the removable tray with the designated slots on the armrest and push down until it locks.

Easy Fold, Smart Storage



Folds in seconds, saves space,
and travels with ease.



Figure 3.1: The stroller in its folded state, highlighting the easy-fold mechanism for compact storage.

4. OPERATING INSTRUCTIONS

4.1 Folding and Unfolding


- **To Fold:** Engage the wheel brakes. Locate the folding mechanism (often a lever or button on the handle or side frame). Follow the specific instructions for your model to collapse the stroller until it locks into its folded position.
- **To Unfold:** Release the folding latch and pull the handle upwards firmly until the frame clicks into its fully open and locked position. Always check that all parts are securely locked before use.

4.2 Adjusting Recline and Footrest

The stroller features a multi-level recline for your child's comfort and an adjustable footrest.

- **Backrest Recline:** Locate the recline lever or strap behind the seat. Adjust to the desired angle (e.g., 95° for comfortable viewing, 135° for feeding/nap, 175° for comfortable sleeping).
- **Footrest Adjustment:** Press the buttons on either side of the footrest to adjust its height and angle.

Easy to Carry Anywhere



Fun to take along, light and convenient
on the go.




Figure 4.1: Demonstrating the adjustable backrest and footrest for various comfort positions.

4.3 Wheel Operation and Brakes

The stroller is equipped with 360° swivel front wheels and a dual brake system.

- **Swivel/Lock Front Wheels:** The front wheels can swivel 360° for easy maneuvering. To lock them for stability on uneven terrain, push down the locking lever located above each front wheel.
- **Brakes:** The stroller features a dual brake system. Push down the brake levers on the rear wheels to engage the brakes. Ensure both brakes are fully engaged when the stroller is stationary. Lift the levers to release.

Four-Wheel Super Shock Absorption & 360° Universal Wheels



Strong shock absorption with smooth 360° rotation for effortless rides.



Figure 4.2: The stroller's 4-wheel shock absorption system and 360° swivel wheels for smooth movement.

4.4 Using the Safety Harness

Always secure your child with the 5-point safety harness.

1. Place your child in the seat.
2. Bring the shoulder straps over your child's shoulders and the waist straps around their hips.
3. Insert the buckle tongues into the central buckle until they click.
4. Adjust the straps to ensure a snug, secure fit without being too tight.
5. To release, press the button on the central buckle.

4.5 Canopy and Removable Tray

- **Canopy:** Adjust the canopy by pulling it forward or backward to provide optimal shade and protection.
- **Removable Tray:** To remove the tray, press the release buttons on either side and lift it off. To reattach, align and push until it clicks into place.



Figure 4.3: Detailed view of the stroller's features, including the detachable food tray and safety belt.

5. MAINTENANCE

Regular maintenance ensures the longevity and safe operation of your stroller.

- **Cleaning Fabric:** Use a mild soap and warm water solution to spot clean fabric components. Do not use harsh detergents or bleach. Allow to air dry completely.
- **Cleaning Frame:** Wipe the frame with a soft, damp cloth. Dry thoroughly to prevent rust.
- **Wheel Maintenance:** Periodically clean debris from the wheels and axles. Lubricate moving parts with a silicone-based lubricant if necessary.
- **Storage:** Store the stroller in a dry, cool place away from direct sunlight and extreme temperatures.
- **Inspections:** Regularly check all screws, rivets, and locking mechanisms to ensure they are secure and in good working order.

6. TROUBLESHOOTING

Problem	Possible Cause	Solution
Stroller does not fold/unfold smoothly	Locking mechanisms are not fully disengaged/engaged; debris in joints.	Ensure all locks are released. Clean any debris from hinges and lubricate if needed. Refer to Section 4.1.
Wheels are stiff or squeaky	Dirt or hair caught in wheels; lack of lubrication.	Clean wheels and axles. Apply a silicone-based lubricant to moving parts.
Stroller feels unstable	Frame not fully locked; overloaded storage basket; child exceeding weight limit.	Ensure frame is fully locked. Do not exceed maximum weight capacity (15 kg). Distribute weight evenly in the basket.
Brakes not engaging/disengaging	Debris in brake mechanism; worn brake pads.	Clean brake mechanism. If problem persists, contact customer support.

7. SPECIFICATIONS

Feature	Detail
Model Number	Luna Luxe Baby Stroller
Maximum Weight Recommendation	15 Kilograms
Material	Alloy Steel
Harness Type	5 Point
Product Dimensions (LxWxH)	85 x 59 x 110 cm
Item Weight	8 kg
Recommended Age	0 - 3 years
Additional Features	360° swivel front wheels, Adjustable Canopy, Foldable, Lockable Wheels, Multi-Level Backrest and Footrest
Country of Origin	India

Product Name:
Luna Luxe Baby Stroller

Brand:
StarAndDaisy

Size:
As the picture shows

Material:
Aluminum Alloy



Figure 7.1: Key product specifications and dimensions of the Luna Luxe Baby Stroller.

8. WARRANTY AND SUPPORT

StarAndDaisy products are manufactured with high-quality materials and undergo strict quality control. For warranty information, product support, or any queries, please contact our customer care.

Customer Care & Whatsapp No: 9990233227

For further assistance, you may also visit the official StarAndDaisy store on Amazon: [StarAndDaisy Store](#)