

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [BoxWave](#) /

› [BoxWave ClearTouch ImpactShield Screen Protector for SSA Wi-Fi Digital Picture Frame ZN-DP1013 \(13.5 in\) - Instruction Manual](#)

BoxWave ClearTouch ImpactShield for ZN-DP1013

BoxWave ClearTouch ImpactShield Screen Protector Instruction Manual

For SSA Wi-Fi Digital Picture Frame ZN-DP1013 (13.5 in)

1. INTRODUCTION

The BoxWave ClearTouch ImpactShield is a protective film designed to safeguard the screen of your SSA Wi-Fi Digital Picture Frame ZN-DP1013 (13.5 in). This screen protector offers enhanced durability and maintains screen clarity. This manual provides instructions for proper installation, usage, and care.



Image: Packaging of the BoxWave ClearTouch ImpactShield Screen Protector.

2. PACKAGE CONTENTS

Each package of the ClearTouch ImpactShield contains the following items:

- Two (2) ClearTouch ImpactShield screen protectors
- Installation accessories (e.g., cleaning cloth, dust removal sticker, squeegee)

3. INSTALLATION GUIDE

Follow these steps carefully for optimal installation of your screen protector.

3.1 Preparation

1. Ensure your device is powered off.
2. Clean the device screen thoroughly using the provided cleaning cloth to remove all dust, smudges, and fingerprints.
3. Use the dust removal sticker to pick up any remaining dust particles from the screen surface. Ensure the screen is completely free of debris.

3.2 Application

1. Carefully peel back a small portion of the protective layer (usually labeled '1') from one end of the screen protector. Avoid touching the adhesive side.
2. Align the exposed adhesive edge of the screen protector with one edge of your device screen. Ensure precise alignment with all cutouts (if any) for cameras or sensors.
3. Slowly and steadily lower the screen protector onto the device screen, gradually peeling off the remaining protective layer '1' as you go.
4. As you apply, use the provided squeegee or a soft card to gently push out any air bubbles towards the edges of the screen protector.



The image shows the packaging for BoxWave ClearTouch IMPACTSHIELD screen protectors. The top half of the packaging is dark purple with a wavy pattern and features the BoxWave logo in white. Below the logo, the text 'ClearTouch®' is written in white, and 'IMPACTSHIELD' is written in large, bold, blue letters. The bottom half of the packaging is light gray and features three feature highlights, each with an icon and a description. To the right of these highlights is a line drawing of a smartphone with a screen protector applied to it.

BOXWAVE

ClearTouch®
IMPACTSHIELD

 **COLOR BRILLIANCE**
High-quality optical film that optimizes color rendition.

 **CLARITY**
Your vibrant screens don't deserve blur or bland. 99% transparency means perfect clarity. No loss of color. No loss of resolution.

 **PRECISION**
Precision cut. Precision

Accuracy. Cut exactly for your device for increased touchpad accuracy and recognition.



REUSABILITY
Cleartouch* comes equipped with installation forgiveness. Reuse and reinstall as needed.



Image: A screen protector being carefully aligned and applied to a digital picture frame.

3.3 Finishing

1. Once the screen protector is fully applied, gently peel off the top protective layer (usually labeled '2').
2. Use the squeegee again to smooth out any remaining small bubbles. Minor bubbles may disappear naturally within 24-48 hours.

4. USAGE AND CARE

The ClearTouch ImpactShield is designed to maintain the original touch sensitivity and visual clarity of your device screen.

4.1 General Use

- The screen protector provides a 9H hardness rating for protection against scratches and impacts.
- It is designed to be flexible and shatterproof, reducing the risk of chipping or cracking.
- The material offers high transparency for clear viewing.



9H Ultimate Protection

Protect against chipping, spills, and drops




Image: Illustration of the screen protector's ability to resist scratches from keys and repel water.



Image: A diamond placed next to a tablet screen, representing the crystal clarity of the screen protector.

4.2 Cleaning

To clean the screen protector, gently wipe it with a soft, lint-free cloth. For stubborn smudges, slightly dampen the cloth with water or a screen-safe cleaning solution. Avoid harsh chemicals or abrasive materials.

5. TROUBLESHOOTING

5.1 Air Bubbles

- **Small Bubbles:** Many small bubbles will dissipate naturally within 24-48 hours.
- **Large Bubbles:** If large bubbles persist, gently lift the nearest edge of the screen protector and reapply, using the squeegee to push the air out as you lay it back down. Ensure the screen is free of dust before reapplication.

5.2 Misalignment

If the screen protector is misaligned, carefully lift it from one corner and slowly peel it off. Clean the screen again to remove any dust that may have settled, then reapply following the installation steps.

6. PRODUCT SPECIFICATIONS

Specification	Detail
---------------	--------

Brand	BoxWave
Model Compatibility	SSA Wi-Fi Digital Picture Frame ZN-DP1013 (13.5 in)
Material	Polyethylene Terephthalate (PET)
Hardness Rating	9H
Screen Surface Description	Glossy
Item Weight	2.5 ounces



Image: Calipers measuring a technical drawing, illustrating the precise manufacturing for a perfect fit.

7. WARRANTY INFORMATION

BoxWave products are manufactured with quality and precision. For specific warranty details regarding your ClearTouch ImpactShield screen protector, please refer to the warranty information provided with your purchase or visit the official BoxWave website.

8. CUSTOMER SUPPORT

If you encounter any issues or have questions regarding the installation or performance of your BoxWave ClearTouch

ImpactShield screen protector, please contact BoxWave customer support. Contact information can typically be found on the product packaging or the official BoxWave website.