Nitemode LED Light Kit Touch Version for Lego 76269

Nitemode LED Light Kit for LEGO Avengers Tower 76269 (Touch Version) - Instruction Manual

Model: LED Light Kit Touch Version for Lego 76269

1. Introduction

This manual provides comprehensive instructions for the Nitemode LED Light Kit, Touch Version, designed to enhance your LEGO Avengers Tower Building Model Set 76269. This kit adds dynamic lighting effects to your model, bringing it to life. Please note that this product includes only the LED light kit and does not include the LEGO model itself.



Figure 1: Important Note: This product is the LED lighting kit only, the LEGO model is not included.

2. Package Contents

Before beginning installation, please verify that all components listed below are present in your package:

- Nitemode LED Light Kit components
- Power supply/charger
- Instruction manual (electronic version)



Figure 2: Contents of the Nitemode LED Light Kit package.

3. Safety Information

Please read and follow these safety guidelines to ensure safe operation and prevent damage to the product or your LEGO model:

- Keep the product away from water and high humidity.
- Do not attempt to modify or disassemble the light kit components.
- Use only the provided power supply.
- Ensure proper ventilation around the installed light kit.
- This product contains small parts and is not suitable for children under 3 years old.

4. Setup and Installation

The Nitemode LED Light Kit is designed for straightforward installation. Detailed, step-by-step online instructions are available to guide you through the process. These electronic instructions provide visual aids and specific guidance for integrating the lights with your LEGO Avengers Tower 76269 model.

To access the electronic instructions:

1. Locate the QR code provided in your package or on the product page.
2. Scan the QR code with your smartphone or tablet.
3. Alternatively, visit the official support website: http://support.nitemodetoy.com
4. Input your product model query to find the specific PDF instructions.



Figure 3: Steps to access the electronic installation manual.

It is recommended to follow the online instructions carefully to ensure correct placement and connection of all lighting components. The installation process involves integrating the lights directly into your LEGO model.



Figure 4: Examples of illuminated sections of the LEGO Avengers Tower model.

5. Operating Instructions

This Nitemode LED Light Kit features a touch-sensitive switch for easy control of your model's lighting. The touch version allows for intuitive interaction with the lights.

- **Turning On/Off:** A simple tap on the designated touch switch will turn the lights on or off. This replicates the iconic blinking effect of the tower's lamp.
- **Adjusting Brightness:** To smoothly adjust the brightness, long-press the touch switch. The lights will dim or brighten, allowing you to set the desired ambiance.



Figure 5: Demonstrating the On/Off functionality of the LED light kit.




Figure 6: Adjusting brightness using the touch switch.

Observe the dynamic lighting effects in the following video:

Your browser does not support the video tag.

Video 1: Demonstration of the Nitemode LED Light Kit for LEGO Avengers Tower 76269, showcasing the lighting effects and touch control.

6. Maintenance

To ensure the longevity and optimal performance of your Nitemode LED Light Kit, follow these maintenance tips:

- **Cleaning:** Gently wipe the LED components and wires with a dry, soft cloth. Avoid using liquid cleaners or abrasive materials.
- **Storage:** If storing the model for an extended period, disconnect the power supply.
- **Handling:** Handle the wired connections with care to prevent damage.

7. Troubleshooting

If you encounter any issues with your Nitemode LED Light Kit, please refer to the following common troubleshooting steps:

Problem	Possible Cause	Solution
Lights do not turn on.	No power, loose connection, faulty component.	◦ Ensure the power supply is correctly connected and plugged into a working outlet. ◦ Check all wire connections for looseness. ◦ Verify the touch switch is functioning by tapping it firmly.
Lights flicker or are dim.	Insufficient power, loose connection, brightness setting.	◦ Confirm the power supply is adequate. ◦ Check all wire connections. ◦ Long-press the touch switch to adjust brightness to maximum.
Specific lights are not working.	Damaged LED, loose connection to that specific light.	◦ Inspect the wiring for the non-functional light. ◦ If a component is damaged, contact customer support.

If these steps do not resolve the issue, please contact Nitemode customer support for further assistance.

8. Specifications

- **Brand:** Nitemode
- **Model:** LED Light Kit Touch Version for Lego 76269
- **Compatible with:** LEGO 76269 Marvel Avengers Tower Building Model Set
- **Operation Mode:** Manual (Touch Control)
- **Power Source:** Battery Pack (or compatible power supply)
- **Material:** Plastic
- **Item Weight:** 0.26 Pounds
- **Item Dimensions:** 7.36 x 4.32 x 1.33 inches
- **Assembly Required:** Yes
- **Educational Objective:** Creative Thinking

- **Additional Features:** Glow in the Dark (referring to the lighting effect)

9. Warranty and Support

Nitemode is committed to providing high-quality products and excellent customer service. If you have any questions, concerns, or require assistance with your product, please do not hesitate to contact us.
For support, you can:

- Email our customer service team.
- Visit our official support website for electronic instructions and FAQs:http://support.nitemodetoy.com

We aim to resolve any issues promptly and efficiently.

© 2025 Nitemode. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question