

[Manuals.plus](#) /

› [MAHOMICO](#) /

› MAHOMICO Power Lift Recliner Chair User Manual

MAHOMICO 1361

MAHOMICO Power Lift Recliner Chair User Manual

Model: 1361

INTRODUCTION

Thank you for choosing the MAHOMICO Power Lift Recliner Chair. This manual provides essential information for the safe assembly, operation, maintenance, and troubleshooting of your new recliner. Please read these instructions carefully before use and retain them for future reference.

IMPORTANT SAFETY INFORMATION

- Do not disassemble the power supply components to avoid short circuit or electric shock risks.
- Ensure all connections are secure before operating the chair.
- Keep children and pets away from the chair's moving parts.
- Do not allow anyone to sit on the footrest when it is extended.
- Avoid placing objects under the chair that could obstruct its movement.
- Maximum weight recommendation: 350 pounds.

PACKAGE CONTENTS

Your MAHOMICO Power Lift Recliner Chair package should contain the following components. Please verify all parts are present before beginning assembly.

ALL IN ONE BOX

Receive & Enjoy it instantly. No more Waiting!



Figure 1: All components are typically shipped in one box for convenience.

- Backrest
- Seat Base with Armrests
- Power Adapter
- Remote Control for Lift and Recline
- Remote Control for Massage and Heat
- Lumbar Pillow (if included)
- Instruction Manual

SETUP AND ASSEMBLY

The MAHOMICO Power Lift Recliner Chair requires assembly. It is recommended to have two people for assembly due to the size and weight of the components. Follow these steps carefully:

1. **Unpack Components:** Carefully remove all parts from the packaging. Place them on a soft, clean surface to prevent damage.
2. **Attach Backrest:** Align the metal brackets on the backrest with the receivers on the seat base. Slide the backrest down until it locks securely into place. You should hear a click.
3. **Connect Wiring:** Locate the power cables extending from the backrest and seat base. Connect them firmly. Ensure all wires are tucked away to prevent pinching.
4. **Connect Power Adapter:** Plug the power adapter into the chair's power input, then into a wall outlet.
5. **Test Functions:** Use the remote controls to test the lift, recline, massage, and heating functions.

Your browser does not support the video tag.

Video 1: Official MAHOMICO video demonstrating the assembly and features of the Power Lift Recliner Chair.

OPERATING INSTRUCTIONS

Power Lift and Recline Function

The chair features a power lift mechanism and electric recline. Use the dedicated remote control for these functions.

- **To Recline:** Press and hold the "Recline" button (usually indicated by a downward arrow or a reclining chair icon) to smoothly adjust the backrest and footrest to your desired angle, up to 135°.
- **To Lift/Stand:** Press and hold the "Lift" button (usually indicated by an upward arrow or a standing chair icon) to gently raise the chair, assisting you to a standing position.
- **To Return to Upright:** Press and hold the "Upright" button to bring the chair back to its standard sitting position.



Figure 2: Power lift and recline functionality for various uses.

Vibration Massage and Lumbar Heating

Your recliner is equipped with an 8-point vibration massage system and targeted lumbar heating. These functions are controlled by a separate remote.

- **Massage Modes:** Select from 5 massage modes and adjust intensity levels using the remote.
- **Lumbar Heat:** Activate the lumbar heating function for soothing warmth to your lower back.
- **Timer:** Set a timer for massage and heat sessions if desired.



Figure 3: Remote control for massage and heat functions.

Convenience Features

The chair includes practical features for enhanced user experience:

- **Cup Holders:** Two integrated cup holders are located in the armrests.
- **Side Pockets:** Store remote controls, magazines, or other small items in the side pockets.
- **USB Charging Port:** A USB port is available for charging your electronic devices.




Figure 4: Overview of convenience features.

CARE AND MAINTENANCE

Proper care will extend the life and appearance of your recliner.

- **Cleaning Fabric:** For general cleaning, use a soft cloth and a mild, non-abrasive cleaner. Test on an inconspicuous area first. Avoid harsh chemicals.
- **Spills:** Blot spills immediately with a clean, dry cloth. Do not rub.
- **Vacuuming:** Regularly vacuum the chair to remove dust and debris.
- **Moving the Chair:** When moving the chair, lift it rather than dragging to prevent damage to the frame and floor.
- **Electrical Components:** Keep electrical components dry. Do not expose to liquids.



Figure 5: The chair features skin-friendly and breathable fabric for comfort and easy maintenance.

TROUBLESHOOTING GUIDE

If you encounter issues with your recliner, please refer to the following common problems and solutions:

Problem	Possible Cause	Solution
Chair does not recline or lift.	Power cord disconnected; remote control battery low/faulty; motor issue.	Check power connections. Ensure the adapter is securely plugged into both the chair and the wall outlet. Replace remote batteries if applicable. Contact customer support if the issue persists.
Massage or heat function not working.	Remote control issue; loose connection to massage/heat unit.	Ensure the massage/heat remote is functioning. Check for any visible loose wires under the chair.

Problem	Possible Cause	Solution
Chair makes unusual noises during operation.	Loose components; obstruction in mechanism.	Inspect for any loose bolts or screws and tighten if necessary. Check for any objects obstructing the reclining mechanism.

If these solutions do not resolve the problem, please contact MAHOMICO customer service for further assistance.

PRODUCT SPECIFICATIONS



Figure 6: Detailed product dimensions.

Brand: MAHOMICO
Model Name: 1361
Color: Grey

Material: Metal frame, Sponge filling, Fabric upholstery

Product Dimensions (D x W x H): 37.4" x 41.34" x 41"

Seat Dimensions (W x D x H): 23.62" x 21.26" x 19.3"

Item Weight: 97.3 pounds

Maximum Weight Recommendation: 350 pounds

Reclining Position Count: 2 (Upright, Reclined up to 135°)

Additional Features: Power Lift, Power Recline, Vibration Massage (8-point, 5 modes, adjustable intensity), Lumbar Heating, Side Pockets, Two Cup Holders, USB Charge Port.

Indoor/Outdoor Usage: Indoor only

Assembly: Required

WARRANTY AND CUSTOMER SUPPORT

MAHOMICO provides a **1-year warranty** on all parts of this Power Lift Recliner Chair, covering manufacturing defects and malfunctions under normal use.

For any questions, concerns, or warranty claims, please contact MAHOMICO customer service. Our team is available **7 days a week, 24 hours a day** to assist you.

Please have your model number (1361) and purchase date available when contacting support.

Contact Information: Refer to your purchase documentation or the MAHOMICO official website for the most current contact details.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FNJZXZ6L>

More documents and user manuals: <https://manuals.plus/>