

manuals.plus /

› **ROOMTEC** /

› **ROOMTEC Large Outdoor Dog Kennel with 4 Bowls (Model NVLA009) Instruction Manual**

ROOMTEC NVLA009

ROOMTEC Large Outdoor Dog Kennel with 4 Bowls

Model: NVLA009

Brand: ROOMTEC

INTRODUCTION

This instruction manual provides detailed guidance for the assembly, operation, and maintenance of your ROOMTEC Large Outdoor Dog Kennel, Model NVLA009. Please read this manual thoroughly before assembly and use to ensure safe and proper operation for your pets.



Figure 1: Fully assembled ROOMTEC Large Outdoor Dog Kennel.

SAFETY INFORMATION

- Always ensure all connections are securely fastened before placing pets inside.
- Regularly inspect the kennel for any signs of damage, wear, or loose components.
- Do not allow children to play unsupervised near or inside the kennel.
- Ensure the kennel is placed on a level, stable surface to prevent tipping.
- Provide adequate water and shelter from extreme weather conditions, even with the roof installed.
- This kennel is designed for pets. Do not use it for purposes other than its intended use.

PACKAGE CONTENTS

Verify that all components are present before beginning assembly. If any parts are missing or damaged, please contact customer support.

- Kennel Panels (various sizes, including door panel)
- Roof Frame Components

- Waterproof/UV-resistant Roof Cover
- Stainless Steel Feeding Bowls (4 units)
- Assembly Hardware (bolts, nuts, washers, etc.)
- Assembly Tools (Allen wrench, small wrench)

SETUP AND ASSEMBLY

Assembly typically requires two adults and approximately 1-2 hours. Follow these steps carefully:

1. **Unpack and Identify Parts:** Lay out all panels and hardware. Refer to the included parts diagram to identify each component.
2. **Assemble Base Panels:** Connect the kennel panels using the provided bolts, nuts, and washers. Ensure the door panel is positioned as desired. The panels are designed to bolt flush against each other for stability.

Your browser does not support the video tag.

Video 1: Overview of the kennel assembly process, showing panels being connected and the roof frame installed.

3. **Install Roof Frame:** Attach the roof frame components to the top of the assembled panels. Secure them firmly.



Figure 2: Detail of the high-carbon steel frame and thick metal mesh construction.

4. **Attach Roof Cover:** Drape the waterproof and UV-resistant roof cover over the roof frame. Secure it using the integrated zippers and straps. The cover is designed to prevent water and snow accumulation.



Figure 3: The 300D thick Oxford cloth roof cover provides weather protection.

5. **Install Feeding Bowls:** Attach the adjustable feeding bowl mechanism to the designated panel. Insert the stainless steel bowls.

OPERATING INSTRUCTIONS

Main Door Operation:

The main door features a secure latch mechanism. To open, slide the latch upwards and pull the door open. To close, push the door shut and ensure the latch slides back into place.

Adjustable Feeding Bowls:

The kennel includes a rotating feeding door with two stainless steel bowls, allowing for easy feeding without entering the main enclosure. The bowls can be adjusted to three heights (4", 8", 12") to suit different pet sizes.

1. To access the bowls, open the small latch on the feeding door.
2. Rotate the feeding door outwards.
3. Fill the bowls with food and water.
4. Rotate the feeding door back into the kennel and secure the latch.



Figure 4: Instructions for using the adjustable rotating feeding bowls.

MAINTENANCE

- **Cleaning:** The raised legs of the kennel facilitate easy cleaning. Rinse the kennel with a hose and use a mild, pet-safe detergent if necessary. Ensure all cleaning agents are thoroughly rinsed off.
- **Roof Care:** The roof cover is waterproof and sun-proof. Periodically check for any tears or damage. Clean the roof cover with water and a soft brush if it becomes dirty.
- **Inspection:** Regularly check all bolts and connections to ensure they remain tight. Tighten any loose hardware as needed. Inspect the metal mesh for any signs of rust or damage.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Kennel feels unstable.	Loose connections; uneven ground.	Tighten all bolts. Relocate to a level surface.

Problem	Possible Cause	Solution
Roof cover sags or collects water.	Improper installation; loose straps.	Ensure roof frame is correctly assembled and cover straps are taut.
Feeding door latch is stiff.	Dirt or debris in mechanism.	Clean the latch mechanism. Apply a small amount of lubricant if needed.

SPECIFICATIONS

- **Model:** NVLA009
- **Dimensions (L x W x H):** 118" x 117" x 78" (10' L x 10' W x 6.5'H)
- **Material:** High Carbon Steel frame, PVC protective mesh, 300D Oxford Cloth roof
- **Pipe Thickness:** 0.7 mm
- **Features:** Removable waterproof/UV-resistant roof, adjustable rotating feeding bowls, raised legs for easy cleaning.
- **Intended Use:** Outdoor enclosure for large dogs and other small to medium pets.




Figure 5: Detailed dimensions of the kennel.

WARRANTY AND SUPPORT

ROOMTEC products are manufactured with quality and durability in mind. For warranty information, technical support, or to order replacement parts, please refer to the contact information provided with your purchase or visit the official ROOMTEC website.

Please retain your proof of purchase for warranty claims.