

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [Giantex](#) /

› [Giantex 6-Drawer Bamboo Dresser \(Model GX-12452NA-VJ\) Instruction Manual](#)

Giantex GX-12452NA-VJ

Giantex 6-Drawer Bamboo Dresser Instruction Manual

Model: GX-12452NA-VJ

Brand: Giantex

PRODUCT OVERVIEW

This manual provides instructions for the assembly, operation, and maintenance of your Giantex 6-Drawer Bamboo Dresser. This storage unit is designed to help organize clothing and accessories, featuring six foldable fabric drawers and a sturdy bamboo frame with a top shelf for additional display or storage.



Image: The Giantex 6-Drawer Bamboo Dresser, fully assembled and placed in a living room, showcasing its design and functionality.

SETUP AND ASSEMBLY

Please follow these steps carefully to ensure proper assembly and stability of your dresser.

Package Contents

- 1 x Bamboo Dresser Frame
- 6 x Foldable Fabric Drawers
- 1 x User Guide
- Assembly Hardware (screws, anti-toppling kits, etc.)

Tools Required

A screwdriver (not included) may be required for some assembly steps, particularly for securing the anti-toppling kit.

Assembly Steps

1. **Unpack Components:** Carefully remove all parts from the packaging and lay them out on a clean, soft surface to prevent scratches. Verify all components listed in the package contents are present.
2. **Assemble the Bamboo Frame:** Connect the bamboo frame pieces according to the diagrams in the included user guide. Ensure all connections are secure.
3. **Insert Drawers:** Unfold each fabric drawer and insert the bottom panel to create its rigid shape. Slide the assembled drawers into the designated slots within the bamboo frame.
4. **Attach Anti-Toppling Kit:** For safety, securely attach the anti-toppling kit to the back of the dresser and to a wall stud using appropriate hardware. This prevents accidental tipping.



Image: An exploded view showing the individual bamboo frame components before assembly, illustrating the structure.

Safety Precautions

- Always use the provided anti-toppling kit to secure the dresser to a wall. Failure to do so can result in serious injury.
- Do not allow children to climb on or play with the dresser.
- Ensure the dresser is placed on a level surface to prevent instability.

OPERATING INSTRUCTIONS

This section details how to effectively use your dresser for storage.

Drawer Usage

- Each fabric drawer is designed for easy opening and closing using the solid beech handle.
- The drawers are foldable for convenient storage when not in use or during relocation.

3-Tier Fabric Drawers



Foldable Drawers for Easy Storage



Image: A diagram illustrating the layered construction of the fabric drawers (non-woven fabric, MDF board) and their foldable nature for easy storage.

Weight Capacity

- **Top Shelf:** Maximum weight capacity of 44 lbs (20 kg).
- **Each Drawer:** Maximum weight capacity of 22 lbs (10 kg).

Do not exceed these weight limits to ensure the longevity and stability of the dresser.

MAINTENANCE AND CARE

Proper care will extend the life and appearance of your dresser.

Cleaning

- **Bamboo Frame:** Wipe clean with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners.
- **Fabric Drawers:** Spot clean with a mild detergent and a damp cloth. Allow to air dry completely. Do not machine wash.

General Care

- Avoid prolonged exposure to direct sunlight or extreme humidity.
- Periodically check all screws and connections to ensure they remain tight.



Image: Detailed views of the dresser's construction, showing the natural bamboo material, the breathable slatted top shelf, and the smooth, painted finish for durability and easy cleaning.

TROUBLESHOOTING

If you encounter any issues, refer to the following common solutions.

Dresser is Wobbly

- Ensure all screws and bolts are tightened securely.
- Verify the dresser is on a level surface. Adjust the non-slip foot pads if necessary.
- Confirm the anti-toppling kit is properly installed and secured to the wall.

Drawers Do Not Slide Smoothly

- Check that the drawers are correctly inserted into their respective slots.
- Ensure drawers are not overloaded, exceeding the 22 lbs (10 kg) weight limit.
- Inspect drawers for any obstructions or damage.



Image: Detailed features of the dresser, including the edge protection design on the top shelf, the convenient fabric handle on drawers, raised support legs for stability, and non-slip foot pads to protect floors.

PRODUCT SPECIFICATIONS

Feature	Detail
Brand	Giantex
Model Name	White Dresser
Item Model Number	GX-12452NA-VJ
Overall Dimensions (L x W x H)	26" x 14" x 31" (66 cm x 35.5 cm x 78.7 cm)
Internal Drawer Dimensions (L x W x H)	12" x 14" x 7.5" (30.5 cm x 35.5 cm x 19 cm)
Raised Height (from floor)	4" (10 cm)
Color	White+Natural
Materials	Bamboo, Non-woven Fabric, Beech, MDF
Number of Drawers	6
Weight Capacity of Top	44 lbs (20 kg)
Weight Capacity of Each Drawer	22 lbs (10 kg)
Item Weight	16.5 lbs (7.5 kg)
Assembly Required	Yes



Image: A diagram illustrating the overall dimensions of the dresser (14"D x 26"W x 31"H) and the internal dimensions of a single drawer (12"D x 14"W x 7.5"H).

WARRANTY AND SUPPORT

For any questions, missing parts, or assistance with your Giantex product, please contact Giantex customer service. Refer to the contact information provided in your purchase documentation or visit the official Giantex website for support.

Please retain your purchase receipt for any warranty claims.

