

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

> [huslog](#) /

> [huslog Desk Lamp B0FNKJ51Q4 User Manual](#)

huslog B0FNKJ51Q4

huslog Desk Lamp B0FNKJ51Q4 User Manual

Model: B0FNKJ51Q4

INTRODUCTION

Thank you for purchasing the huslog Desk Lamp B0FNKJ51Q4. This multi-functional device combines LED lighting with adjustable settings, a digital clock, an inductive charger, and a thermometer. This manual provides detailed instructions for safe and efficient use of your new desk lamp.

SAFETY INSTRUCTIONS

- Ensure the lamp is placed on a stable, flat surface to prevent tipping.
- Do not expose the lamp to water or excessive moisture.
- Do not attempt to disassemble or repair the lamp yourself. Contact qualified service personnel for assistance.
- Use only the provided power cable or a compatible micro USB cable with an appropriate power adapter.
- Keep the lamp away from heat sources and direct sunlight.
- Avoid looking directly into the LED light source for extended periods.

PACKAGE CONTENTS

Please check the package for the following items:

- huslog Desk Lamp B0FNKJ51Q4
- Micro USB Power Cable

PRODUCT OVERVIEW

The huslog Desk Lamp features a sleek design with multiple integrated functions. Familiarize yourself with the main components:

- **Lamp Head:** Contains the LED light source.
- **Adjustable Arm:** Allows for angle and height adjustments.

- **LCD Display:** Shows time, date, and temperature.
- **Control Panel:** Touch-sensitive buttons for lamp functions and display settings.
- **Wireless Charging Pad:** Located on the base for inductive charging.
- **USB Output Port:** For wired charging of devices.
- **Micro USB Input Port:** For powering the lamp.



Figure 1: Overview of the huslog Desk Lamp with key dimensions and features. The image highlights the adjustable arm, lamp head, base, and LCD display, along with measurements of 28cm height, 28cm lamp head length, 11cm base width, and 17cm base depth.






Figure 2: Detailed view of the lamp's base, illustrating the micro USB input, USB output, and the touch control panel for power, brightness, and color temperature adjustments.

SETUP

1. Power Connection

1. Connect the provided micro USB cable to the micro USB input port on the back of the lamp base.
2. Plug the other end of the USB cable into a suitable USB power adapter (not included) and then into a wall outlet.

2. CR2032 Battery Installation (for LCD Display Backup)

The lamp requires a CR2032 button cell battery (not included) to maintain the clock and calendar settings when the main power is disconnected. Locate the battery compartment on the underside of the lamp base, insert the CR2032 battery with the positive (+) side facing up, and close the compartment.

3. Placement

Place the lamp on a flat, stable surface where you intend to use it, ensuring adequate space for adjustments and charging.

OPERATING INSTRUCTIONS

1. Lamp Controls

The lamp functions are controlled via the touch-sensitive buttons on the base:

- **Power Button (○):** Touch to turn the lamp on or off.
- **Brightness Adjustment (▲ / ▼):** Touch to cycle through 5 brightness levels.
- **Color Temperature Adjustment (●):** Touch to switch between three light colors: warm, neutral, and cold.



Figure 3: The lamp demonstrating its three light color modes (warm, neutral, cold) and the clear LCD display showing time, date, and temperature.

2. Adjusting Lamp Angle

The lamp features a two-stage tilt angle adjustment and a rotating top section for optimal light direction. Gently adjust the arm and lamp head to your desired position. The arm can tilt up to 180 degrees, and the lamp head can rotate for maximum flexibility.






Figure 4: Illustration of the lamp's adjustable arm, capable of a 180-degree rotation to direct light as needed.

3. LCD Display Functions

The LCD display shows the current date, time, and temperature. Use the 'M' (Mode) and 'V' (Set) buttons on the base to adjust these settings.

- **Setting Time/Date:** Press 'M' to cycle through display modes (Time, Date, Alarm). When in Time or Date mode, press and hold 'V' to enter setting mode. Use '▲' and '▼' to adjust values, and 'V' to confirm and move to the next setting.
- **Night Mode:** The LCD display has a night mode function that allows you to turn off the backlight without disconnecting the lamp from power. Refer to the specific button combination in the quick start guide for this feature.

4. Charging Functions

The lamp offers two ways to charge your devices:

- **Wireless (Inductive) Charging:** Place your Qi-compatible smartphone or device on the wireless charging pad located on the lamp's base. Ensure the device is centered for optimal charging.
- **Wired Charging (USB Port):** Connect your device's USB charging cable to the USB output port on the back of the lamp base.



Figure 5: A smartphone placed on the lamp's base, indicating active wireless charging with a battery icon.



Figure 6: The desk lamp in a typical setup, simultaneously charging a smartphone wirelessly on its base and another device via its USB port, next to a laptop.

MAINTENANCE

Cleaning

To clean the lamp, ensure it is unplugged from the power source. Use a soft, dry cloth to wipe down the surfaces. Do not use abrasive cleaners, solvents, or spray directly onto the lamp.

CR2032 Battery Replacement

If the LCD display loses time or date settings when the lamp is unplugged, the CR2032 battery may need replacement. Follow the installation steps in the Setup section to replace the battery.

TROUBLESHOOTING

- **Lamp not turning on:** Ensure the micro USB cable is securely connected to both the lamp and the power adapter, and that the power adapter is plugged into a working outlet.
- **Wireless charging not working:** Verify your device is Qi-compatible. Ensure the device is centered on the charging pad without any thick cases interfering. Check if the lamp is powered on.
- **LCD display is blank or incorrect:** Check if the CR2032 battery is installed correctly and has sufficient charge. Replace if necessary.
- **Light flickering:** Ensure the power connection is stable. Try using a different USB power adapter if available.

SPECIFICATIONS

Feature	Specification
Model	B0FNKJ51Q4
Brand	huslog
Dimensions (L x W x H)	28D x 11W x 28H centimetres
Item Weight	458 Grams
Lamp Type	Table Lamp (LED)
Shade Material	Plastic
Shade Color	Black
Base Material	Metal
Switch Type	Push Button (Touch-sensitive)
Power Input	Micro USB (Cable included)
LCD Backup Battery	CR2032 (Not included)
Light Colors	Warm, Neutral, Cold
Brightness Levels	5 levels

WARRANTY AND SUPPORT

This product is covered by a standard manufacturer's warranty. Please refer to your purchase documentation or contact your retailer for specific warranty terms and conditions. For technical support or inquiries, please contact the retailer or the huslog customer service department.