

RALGEND 1301ZDUWH

RALGEND Kitchen Island with Power Outlet and Drop Leaf

Model: 1301ZDUWH | Brand: RALGEND

IMPORTANT SAFETY INFORMATION

The kitchen island is large in size and weight, so please have two people cooperate during handling and installation. Install strictly according to the instructions to ensure the stability of the kitchen island. To ensure overall stability, please note the installation position of the back inserted buckles. Keep the kitchen cart away from water and fire sources. Do not play or climb around the kitchen island to prevent potential injuries from it tipping over.

PRODUCT OVERVIEW

The RALGEND Kitchen Island (Model 1301ZDUWH) is a versatile and functional addition to your kitchen or dining area. It features a spacious countertop, ample storage, and convenient mobility. This island is designed to enhance your kitchen's utility and organization.

Key Features:

- **Ample Storage:** Includes a large cabinet, two drawers, and a 3-tier side shelf for dishes, cookware, spices, and more.
- **Trash Storage Cabinet:** A dedicated space designed for a 10-gallon trash bin (not included) to keep odors contained and your kitchen tidy.
- **Foldable Drop-Leaf Countertop:** Expands to 27.6 inches for additional workspace or dining, supported by three metal brackets. Folds compactly when not in use.
- **Integrated Power Outlet:** Features a 1500W power socket with three three-prong AC outlets and a 4.9-foot long cord for convenient appliance use.
- **Hidden Casters for Mobility:** Equipped with five concealed bottom casters for easy movement, with a central caster for enhanced stability.



Image: The RALGEND Kitchen Island in a kitchen setting, with the drop-leaf extended and two stools, demonstrating its use as a dining table.

SETUP AND ASSEMBLY

Assembly of the RALGEND Kitchen Island requires careful attention to the provided instructions. It is recommended that two individuals perform the assembly due to the size and weight of the components.

Assembly Steps:

1. **Unpack Components:** Carefully remove all parts from the packaging. Verify that all components listed in the hardware kit and instruction manual are present.
2. **Identify Parts:** All parts are labeled with letters or numbers. Refer to the detailed guide for identification.
3. **Follow Instructions:** Assemble the unit strictly following the step-by-step instructions provided in the included manual. Pay close attention to diagrams and warnings.
4. **Secure Connections:** Ensure all screws, cam locks, and other fasteners are securely tightened to guarantee the stability of

the kitchen island.

5. **Back Inserted Buckles:** Confirm the correct installation position of the back inserted buckles for overall stability.
6. **Install Casters:** Attach the five concealed bottom casters as directed.
7. **Power Outlet Installation:** Integrate the power outlet unit according to the instructions.

A detailed, step-by-step assembly instruction manual and all necessary tools are included in the package.

PRODUCT SIZE



Compatible with 10 gallon trash cans.



Trash can not included

Image: Product dimensions and internal layout diagram, indicating various measurements.

OPERATING INSTRUCTIONS

Using the Drop-Leaf Countertop:

To extend the countertop, gently lift the drop-leaf panel and pull out the supporting metal brackets underneath. Ensure the brackets are fully extended and locked into place for stability. To fold, release the brackets and carefully lower the panel.

DROP-LEAF PANEL

Dual-use design: expand or fold the tabletop as desired.



3 metal brackets enhance stability of the foldable tabletop.

Image: Detail of the drop-leaf panel and its supporting metal brackets.

Utilizing the Integrated Power Outlet:

Plug the island's 4.9-foot power cord into a standard 120V AC wall outlet. The integrated power strip provides three three-prong outlets for kitchen appliances and electronic devices. Ensure the total wattage of connected devices does not exceed 1500W.



Image: Detail of the integrated power outlet with three AC sockets.

Moving the Island:

The island is equipped with five concealed bottom casters for easy movement. To relocate the island, gently push it to the desired position. The central caster provides additional stability during movement. Note that the casters do not have locking mechanisms.



Image: Detail of a concealed bottom caster for mobility.

Adjusting Shelves:

The internal shelves within the cabinet are adjustable. To change shelf height, remove the shelf, reposition the shelf pins to the desired slots, and then place the shelf back onto the pins.



Condiment Shelf



Adjustable Shelf



Fenced Side Storage

Image: Illustration of adjustable shelves and side storage compartments.

Using the Trash Storage Cabinet:

The dedicated cabinet is designed to hold a 10-gallon trash bin (not included). The cabinet door tilts open for easy access and cleaning. Ensure the trash bin dimensions are compatible with the cabinet space (approximately 14.5" W x 11.5" D x 22.5" H).



TRASH CAN CABINET

Plenty of storage keeps trash out of sight.



Sleek, sturdy metal supports for easy access and cleaning.



Fits 10 gallon trash cans (not included), suitable for daily use.

Image: The trash can cabinet with its tilting door open, showing internal dimensions.

MAINTENANCE

- **Cleaning:** Wipe surfaces with a soft, damp cloth. Avoid harsh chemicals or abrasive cleaners that may damage the finish. For spills, wipe immediately.
- **Wood Care:** The engineered wood surfaces should be kept dry. Avoid prolonged exposure to moisture or direct sunlight to prevent warping or discoloration.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten as necessary to maintain structural integrity.
- **Power Outlet:** Ensure the power outlet area remains clean and dry. Do not expose the power strip to liquids.



Image: Demonstrating how to clean the countertop surface.

TROUBLESHOOTING

Problem	Possible Cause	Solution
Island is wobbly or unstable.	Loose fasteners; incorrect assembly of back inserted buckles.	Ensure all screws and cam locks are fully tightened. Verify that the back inserted buckles are correctly installed as per the manual.
Drop-leaf countertop does not stay extended.	Metal support brackets not fully engaged.	Ensure the three metal brackets are fully pulled out and locked into their supporting position.
Power outlets are not working.	Island power cord not plugged in; circuit breaker tripped; faulty appliance.	Check if the island's power cord is securely plugged into a functional wall outlet. Reset the household circuit breaker if necessary. Test the appliance in another outlet.
Trash bin does not fit in the cabinet.	Incorrect trash bin size.	Ensure the trash bin is a 10-gallon size or smaller, with dimensions compatible with the cabinet (approx. 14.5" W x 11.5" D x 22.5" H).

SPECIFICATIONS

Brand	RALGEND
Model Number	1301ZDUWH
Colour	White + Walnut
Material	Engineered Wood
Product Dimensions (D x W x H)	70.1D x 143W x 89.9H Centimetres (27.6"D x 56.3"W x 35.4"H)
Weight Capacity Maximum	108 Pounds (approx. 49 kg)
Item Weight	45.21 kg
Power Outlet	1500W, 3 three-prong AC outlets, 4.9ft cord
Number of Drawers	2

Number of Shelves	3 (side shelf) + adjustable internal shelves
Number of Doors	2 (main cabinet) + 1 (trash cabinet)
Base Type	Wheels (5 concealed casters)
Assembly Required	Yes

SUPPORT

Should you encounter any difficulties during assembly or operation, or if you have questions regarding your RALGEND Kitchen Island, please contact our customer support team for professional assistance. Refer to your purchase documentation for contact details.

© 2026 RALGEND. All rights reserved.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page’s manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

<https://manuals.plus/asin/B0FNM5Y96Q>

More documents and user manuals: <https://manuals.plus/>