

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

manuals.plus /

› [GEEZER](#) /

› [GEEZER Wireless Bluetooth Keyboard with Hexagon Keycaps - Instruction Manual](#)

GEEZER B0FNM6L77D

GEEZER Wireless Bluetooth Keyboard

MODEL: B0FNM6L77D

INTRODUCTION

This manual provides detailed instructions for the GEEZER Wireless Bluetooth Keyboard. Designed for portability and efficiency, this ultra-slim keyboard features unique hexagon keycaps and multi-device compatibility, making it ideal for use with Mac, iPhone, iPad, smartphones, and tablets.

Key Features:

- **Hexagon Keycaps Design:** Unique keycap shape for comfortable and precise typing.
- **Broad Compatibility:** Supports iMac/MacBook, iPhone/iPad, smartphones/tablets running Mac/iOS systems.
- **Rechargeable Battery:** Built-in battery provides extended use, eliminating the need for frequent replacements.
- **Dual Device Connection:** Easily switch between multiple paired devices.
- **Ultra-Slim Design:** Compact and lightweight for enhanced portability.

WHAT'S IN THE BOX

- 1 x GEEZER Wireless Bluetooth Keyboard
- 1 x USB-C Charge Cable

SETUP INSTRUCTIONS

1. Charging the Keyboard

Before initial use, ensure the keyboard is fully charged. Connect the provided USB-C Charge Cable to the keyboard's USB-C port and to a compatible USB power source (e.g., computer USB port, wall adapter). The charging indicator light will turn off when fully charged.



Image: Side view of the GEEZER keyboard showing the USB-C charging port, ON/OFF switch, and indicator lights for Bluetooth channels and Caps Lock.

2. Powering On/Off

Locate the ON/OFF switch on the side of the keyboard. Slide the switch to the 'ON' position to power on the keyboard. Slide it to 'OFF' to power off.

3. Connecting via Bluetooth

The GEEZER Wireless Bluetooth Keyboard supports connection to multiple devices. Follow these steps to pair your keyboard:

1. Ensure the keyboard is powered on.
2. Press and hold the **BT button** located in the upper right corner of the keyboard. The indicator light for the active Bluetooth channel (BT1 or BT2) will begin to flash, indicating it is in pairing mode.
3. On your device (Mac, iPhone, iPad, smartphone, or tablet), navigate to the Bluetooth settings.
4. Search for available Bluetooth devices. You should see "**GEEZER Pie**" in the list.
5. Select "**GEEZER Pie**" to connect. The indicator light on the keyboard will stop flashing and remain solid, confirming a successful connection.
6. To connect to a second device, repeat steps 2-5, using the other BT button (BT2).

DUAL MODE CONNECTION




Image: Illustration of the GEEZER keyboard's dual mode connection capability with various devices.

OPERATING INSTRUCTIONS

1. Switching Between Devices

Once paired with multiple devices, you can switch between them by simply pressing the corresponding **BT1** or **BT2** button in the upper right corner of the keyboard. The keyboard will automatically connect to the selected device.

2. Typing Experience

The keyboard features hexagon keycaps and an ultra-slim design for a comfortable typing experience during extended sessions. The layout is optimized for Mac/iOS systems.



Image: A user typing on the GEEZER keyboard, demonstrating its use in a multi-device setup.

MAINTENANCE

1. Cleaning

To clean the keyboard, gently wipe the surface with a soft, dry cloth. Avoid using harsh chemicals or abrasive materials that could damage the finish or keycaps.

2. Battery Care

The keyboard features a rechargeable battery designed for extended use. To prolong battery life, avoid fully discharging the battery frequently. Charge the keyboard when the battery indicator suggests low power.

TROUBLESHOOTING

- **Keyboard not connecting:** Ensure the keyboard is charged and powered on. Verify that Bluetooth is enabled on your device and the keyboard is in pairing mode (flashing BT indicator). Try restarting both the keyboard and your device.
- **Lag or delayed input:** Ensure the keyboard is within the effective Bluetooth range (up to 33ft). Check for any interference from other wireless devices.

- **Keys not responding:** Check the battery level. If individual keys are unresponsive, ensure no debris is lodged beneath them.

SPECIFICATIONS

- **Brand:** GEEZER
- **Model:** B0FNM6L77D
- **Connectivity Technology:** Bluetooth
- **Compatible Devices:** Mac, iPhone, iPad, smartphones, tablets
- **Special Feature:** Hexagon Keycap
- **Color:** Silver white
- **Style:** Classic
- **Material:** Plastic
- **Item Weight:** 1.85 pounds
- **Package Dimensions:** 13.35 x 6.22 x 1.93 inches

WARRANTY AND SUPPORT

For warranty information and customer support, please refer to the documentation included in your product packaging or visit the official GEEZER website. Keep your proof of purchase for any warranty claims.

Manufacturer: GEEZER