Saved from manuals.plus.
Open the live page for links to other documents and user manuals.

Rfgyhet 612

Rfgyhet 61-Key Electronic Digital Piano Model 612 Instruction Manual

Brand: Rfgyhet | Model: 612

Introduction

Thank you for choosing the Rfgyhet 61-Key Electronic Digital Piano Model 612. This portable keyboard is designed for beginners, offering a wide range of features to enhance your musical journey. It includes a built-in speaker, microphone input, and various tones and rhythms for an engaging learning experience.

Key Features:

- **61 Standard Keys:** Provides a comprehensive range for learning and playing.
- **Dual Power Supply:** Operates via a standard power adapter or 1.5V AA batteries (not included) for versatile use.
- **Rich Sound Library:** Features 16 instrument tones, 10 rhythms, and 6 demonstration songs.
- **Recording & Playback:** Allows users to record and listen to their performances.
- **Integrated Microphone:** Enables singing along while playing.
- **Adjustable Controls:** Digital LCD screen with adjustable volume and tempo.
- **Portable Design:** Lightweight and compact for easy transport.

Setup Instructions

1. Unpacking and Placement:

Carefully remove all components from the packaging. Place the keyboard on a stable, flat surface. Ensure adequate space for playing and accessing controls.



Image: The Rfgyhet 61-Key Electronic Digital Piano, highlighting its dimensions of approximately 29.6 inches in width and 10.2 inches in depth, emphasizing its portable size.

2. Power Supply:

The keyboard offers two power options:

- **AC Power Adapter:** Connect the provided power adapter to the DC 9V-12V input port on the back of the keyboard and then plug it into a standard wall outlet.
- **Battery Power:** For portable use, insert 1.5V AA batteries (not included) into the battery compartment located on the underside of the keyboard. Ensure correct polarity.




Image: Close-up of the keyboard's rear panel, illustrating the power supply input, Aux Out, Aux In, Microphone Input, and USB port. This highlights the various connectivity options.

3. Connecting Accessories:

- **Microphone:** Plug the included wired microphone into the "MIC INPUT" jack.
- **Headphones:** For private practice, connect headphones to the "HEADSET" jack.
- **External Audio:** Use the "AUDIO INPUT" jack to connect external audio sources.

Operating Instructions

1. Power On/Off:

Locate the power switch on the side or top panel of the keyboard. Slide it to the "ON" position to power on the device. Slide it to "OFF" to power down.

Your browser does not support the video tag.

Video: Demonstration of the Rfgyhet 61-Key Electronic Digital Piano, showcasing its features, including power on/off, various tones, rhythms, and the overall playing experience. This video provides a general overview of the product in use.

2. Adjusting Volume and Tempo:

Use the dedicated "VOLUME" and "TEMPO" buttons or knobs to adjust the sound output and playback speed to your preference. The digital LCD screen will display the current settings.

3. Selecting Tones and Rhythms:

The keyboard features 16 tones and 10 rhythms. Use the "TONE" and "RHYTHM" selection buttons to browse and select different instrument sounds and background rhythms. The LCD screen will indicate your selection.




Image: The control panel of the keyboard, detailing the selection buttons for 100 rhythms, 10 demo songs, and 5 animal sounds, emphasizing the stereo sound output from the speaker.

4. Demonstration Songs:

Press the "DEMO" button to play one of the 6 pre-programmed demonstration songs. This is a great way to hear the keyboard's capabilities and get inspiration.

5. Recording and Playback:

To record your performance, press the "REC" button. Play your desired melody. Press "PLAY" to listen to your recorded piece. This function is ideal for self-assessment and creative exploration.

Your browser does not support the video tag.

Video: A detailed guide on adjusting various functions of the keyboard, including tones, rhythms, and other settings, demonstrating how to customize the sound and play experience.

Maintenance

1. Cleaning:

Wipe the keyboard surface with a soft, dry cloth. For stubborn dirt, slightly dampen the cloth with water and a mild soap solution, then wipe dry immediately. Avoid using abrasive cleaners or solvents.

2. Storage:

When not in use, store the keyboard in a cool, dry place away from direct sunlight and extreme temperatures. If storing for an extended period, remove the batteries to prevent leakage.

3. Battery Replacement:

If using batteries, replace all batteries simultaneously when the sound becomes distorted or the keyboard fails to power on. Always use new 1.5V AA batteries and dispose of old batteries responsibly.

Troubleshooting

Problem	Possible Cause	Solution
Keyboard does not power on.	Power adapter not connected or faulty; batteries are low or incorrectly inserted.	Ensure the power adapter is securely connected and functional. If using batteries, replace them with new ones and check polarity.
No sound output.	Volume is too low; headphones are connected; speaker is faulty.	Increase the volume. Disconnect headphones if external sound is desired. Test with different headphones or external speakers if available.
Microphone not working.	Microphone not properly connected; microphone is faulty.	Ensure the microphone is fully plugged into the "MIC INPUT" jack. Test with another microphone if possible.
Keys are unresponsive or produce incorrect sounds.	Incorrect tone selected; internal malfunction.	Verify the selected tone. Power cycle the keyboard (turn off, then on). If the issue persists, contact customer support.

Specifications

Feature	Detail
Model Number	612
Number of Keys	61

Feature	Detail
Dimensions (L x W x H)	29.5 x 8.7 x 2.3 inches
Item Weight	4.14 pounds
Power Supply	AC Power Adapter (DC 9V-12V) or 1.5V AA Batteries (not included)
Tones	16
Rhythms	10
Demo Songs	6
Special Features	Record & Playback, Microphone Input, Headset Jack, Adjustable Volume/Tempo
Skill Level	Beginner

Warranty and Support

For warranty information, technical support, or any inquiries regarding your Rfgyhet 61-Key Electronic Digital Piano Model 612, please refer to the contact details provided with your purchase or visit the official Rfgyhet website. Keep your purchase receipt as proof of purchase for warranty claims.

© 2026 Rfgyhet. All rights reserved.

Ask a question about this manual

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. Privacy details.

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question

Open the live page

https://manuals.plus/asin/B0FNM6R7TH

More documents and user manuals: **https://manuals.plus/**