

ATK ATK Sky Mousepad

ATK Sky XSoft Esport Gaming Mousepad User Manual

Model: ATK Sky Mousepad

INTRODUCTION

The ATK Sky XSoft Esport Gaming Mousepad is engineered for precision and comfort, featuring an XSoft composite fiber surface and a stable dual-layer base. This manual provides essential information for setting up, using, and maintaining your mousepad to ensure optimal performance and longevity.

SETUP

Follow these steps to set up your ATK Sky XSoft Esport Gaming Mousepad:

1. **Unpack the Mousepad:** Carefully remove the mousepad from its packaging.
2. **Choose a Surface:** Place the mousepad on a clean, flat, and stable surface. Ensure the area is free of dust or debris to maximize the non-slip base's effectiveness.
3. **Flattening:** If the mousepad shows any signs of curling from packaging, allow it to lay flat for a short period. The recessed edge design helps prevent persistent curling.




Image: ATK Sky XSoft Esport Gaming Mousepad, Orange, 14.2L x 11.8W inches

OPERATING INSTRUCTIONS

The ATK Sky XSoft Esport Gaming Mousepad is designed for immediate use. Its XSoft composite fiber surface provides a balanced glide with controlled stopping power, making it suitable for various gaming styles and general computer tasks. The low-friction surface facilitates smooth and rapid mouse movements, while the fine texture ensures precise optical and laser sensor tracking.

MAINTENANCE

Proper care will extend the life and performance of your mousepad:

- **Light Cleaning:** For everyday dust and minor smudges, gently wipe the surface with a soft, slightly damp cloth.
- **Deep Cleaning:** For more stubborn dirt, use a small amount of mild soap diluted in water on a soft cloth. Gently scrub the affected area, then wipe with a clean, damp cloth to remove all soap residue.

- **Drying:** Always allow the mousepad to air dry completely before resuming use. Do not expose it to direct sunlight or use a heat source for drying.
- **Avoid Harsh Chemicals:** Do not use harsh chemicals, abrasive cleaners, or alcohol-based solutions, as these can damage the surface and base materials.
- **Storage:** Store the mousepad flat or rolled loosely with the surface facing outwards to prevent creases or damage to the recessed edges. Avoid folding the mousepad.

TROUBLESHOOTING

- **Mouse Tracking Issues:** If your mouse cursor movement is inconsistent or erratic, ensure the mousepad surface is clean and free of any debris, dust, or crumbs. Also, check your mouse's sensor for any obstructions.
- **Mousepad Sliding:** If the mousepad moves during use, ensure the desk surface beneath it is clean, dry, and smooth. The dual-layer non-slip base is designed for stability, but dust or moisture can reduce its grip.
- **Edge Curling:** While the recessed edge design minimizes curling, if you notice any, try placing heavy, flat objects on the affected areas overnight to help flatten them.

SPECIFICATIONS

Brand	ATK
Model	ATK Sky Mousepad
Surface Material	XSoft Composite Fiber
Base Material	Korean PU with Japanese Inoue Poron
Dimensions (Small)	360 x 300 x 4 mm (14.17"L x 11.81"W x 0.16"H)
Special Features	Recessed Anti-Curl Edge, Non-slip Base

WARRANTY INFORMATION

The ATK Sky XSoft Esport Gaming Mousepad includes a **6-Month Warranty** from the original date of purchase. This warranty specifically covers manufacturing defects under normal use. Please retain your proof of purchase, such as a receipt or order confirmation, as it will be required for any warranty claims. For comprehensive details regarding warranty terms, conditions, and exclusions, please refer to the official ATK website or contact customer support.

SUPPORT

For further assistance, technical support, or inquiries regarding your ATK Sky XSoft Esport Gaming Mousepad, please visit the official ATK support page or contact customer service. You can find more information and contact options through the [ATK Store on Amazon](#).

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question