

[manuals.plus](#) /› [Olayks](#) /› [Olayks Travel Steamer and Mini Rice Cooker User Manual](#)

Olayks B0FNMB2G5K

Olayks Travel Steamer and Mini Rice Cooker User Manual

Model: B0FNMB2G5K

1. INTRODUCTION

Thank you for choosing the Olayks Travel Steamer and Mini Rice Cooker. This versatile appliance combines the convenience of a portable garment steamer with the functionality of a compact rice cooker, designed for modern lifestyles. Please read this manual carefully before use to ensure safe and optimal operation.

The Olayks travel steamer features an elegant, unique design and is lightweight at 1.1 lbs, making it easy to handle and transport. Its mini size allows for efficient packing in backpacks or travel suitcases, complemented by an included luxury travel bag.

The handheld steamer incorporates a no-leak design, enabling use from any angle without water stains. It is suitable for various fabrics including T-shirts, shirts, coats, wool, denim, curtains, furniture, toys, silk, and lace. This steamer is designed for use in 100-120V countries and regions, such as the United States, Canada, and Japan.

For rapid wrinkle removal, the steamer utilizes 3-layer pressurization technology and 5 contact sprays, achieving steam preheating in just 15 seconds. It delivers 250% steam flow and 200% steam distance, allowing clothes to become wrinkle-free quickly, typically within 8 minutes.

The integrated mini rice cooker offers multi-functional capabilities, supporting various cooking habits including white rice, brown rice, porridge, soup, oatmeal, and grains. Its touch screen design simplifies function selection. With a 1.2L capacity, it cooks up to 4 cups of white rice (from 2 cups uncooked), ideal for 1 to 2 people.

2. IMPORTANT SAFETY INSTRUCTIONS

To reduce the risk of fire, electric shock, or injury, always follow these basic safety precautions:

- Read all instructions before using the appliance.
- Do not immerse the appliance, cord, or plug in water or other liquids.
- Keep the appliance out of reach of children.
- Always unplug the appliance from the electrical outlet when not in use, before filling or emptying water, and before cleaning.
- Use only distilled or demineralized water in the steamer to prevent mineral buildup.
- Do not operate any appliance with a damaged cord or plug, or after the appliance malfunctions or has been damaged in any manner.
- Use the appliance only for its intended household use.

- Exercise caution when handling hot steam and hot surfaces.
- Ensure the voltage rating of the appliance matches your local power supply (100-120V).

3. PRODUCT OVERVIEW AND COMPONENTS

The Olayks Travel Steamer and Mini Rice Cooker is a dual-function device. Familiarize yourself with its main components:



Image 3.1: The Olayks Travel Steamer (left) and Mini Rice Cooker (right) with included accessories such as a measuring cup and rice paddle.

3.1 Travel Steamer Components:

- Steam Nozzle
- Water Tank

- Power Button
- Power Cord

3.2 Mini Rice Cooker Components:

- Main Unit
- Inner Pot with Handles
- Lid
- Control Panel / Touch Screen
- Measuring Cup
- Rice Paddle
- Power Cord

4. SETUP AND OPERATION - TRAVEL STEAMER

4.1 Steamer Setup:

1. Ensure the steamer is unplugged and cool.
2. Open the water tank cap.
3. Fill the water tank with distilled or demineralized water. Do not overfill. The tank capacity is approximately 70ml.
4. Close the water tank cap securely.
5. Plug the power cord into a 100-120V electrical outlet.

4.2 Steamer Operation:

1. Press the power button to turn on the steamer. The indicator light will illuminate.
2. Allow approximately 15 seconds for the steamer to preheat and begin producing steam.
3. Hold the steamer upright or horizontally, ensuring the steam nozzle is directed away from your body. The no-leak design allows for steaming at any angle.
4. Hold the fabric taut with your free hand and move the steamer slowly over the wrinkles.
5. The steamer provides continuous steam for up to 8 minutes on a full tank.
6. After use, press the power button to turn off the steamer and unplug it from the outlet.

15S Ultra-fast Preheat

Strong steam quickly
smoothes wrinkles



15S
Fast Preheat



8 Minute
continuous
Steam Time



70ml Water Tank
Capacity



Three-layer
Vaporization




Image 4.1: The steamer features ultra-fast 15-second preheat, 8 minutes continuous steam, 70ml water tank capacity, and three-layer vaporization technology.



No-spilling Design

2-in-1 vertical and horizontal steaming for better results.

Image 4.2: The no-spilling design allows for effective vertical and horizontal steaming.

Quickly Get Rid of Wrinkles

Make your clothes tidier



Image 4.3: Demonstration of the steamer's effectiveness in quickly removing wrinkles from clothing.

4.3 Fabric Compatibility:

The Olayks Travel Steamer is suitable for a wide range of fabrics:

- Chiffon
- Cotton
- Silk
- Linen
- Wool
- Nylon



Suitable for Various Fabrics

Image 4.4: The steamer is suitable for various fabric types, indicated by a 3.8-inch steaming area.

5. SETUP AND OPERATION - MINI RICE COOKER

5.1 Rice Cooker Setup:

1. Place the inner pot inside the main unit.
2. Use the provided measuring cup to add the desired amount of rice or other ingredients to the inner pot.
3. Add the appropriate amount of water according to the type of food and desired consistency.
4. Close the lid securely.
5. Plug the power cord into a 100-120V electrical outlet.

5.2 Rice Cooker Operation:

1. The touch screen control panel allows you to select various cooking functions.
2. Choose your desired cooking function: White Rice, Brown Rice, Porridge, Soup, Oatmeal, or Grains.
3. For delayed cooking, use the **24 Hours Cooking Reservation** function. Set the desired cooking start time from 0.5 to 24 hours in advance. The cooker will automatically begin cooking at the set time.
4. Once cooking is complete, the cooker will automatically switch to the **Keep Warm** function, which can maintain warmth for up to 24 hours.
5. The **Quick Cooking** option allows for faster preparation, typically around 30 minutes.
6. After cooking, use the inner pot's double handles to safely remove it from the main unit. The inner pot can also serve as a serving bowl.




Image 5.1: The rice cooker offers versatile menu options for various cooking needs.



24 Hours Cooking Reservation

You can set the time from 0.5 hours to 24 hours in advance, and it will cook automatically when the time comes.



24 Hours
Keep Warm



30 Minute
Quick Cooking



Image 5.2: Features include 24-hour cooking reservation, 24-hour keep warm, and 30-minute quick cooking.

5.3 Capacity Information:

The 1.2L mini rice cooker can cook up to 2 cups of uncooked rice, yielding approximately 4 cups of cooked white rice. It is suitable for 1 to 2 people.

2-Cup Uncooked Capacity(1.2L)



Cups of Rice



2CUPS



1CUPS

Cups of Porridge



1/2CUPS

Image 5.3: Visual representation of the 2-cup uncooked (1.2L) capacity for rice and porridge.

Liner Design with Handle

The liner has double handles on both sides

You can use it as a bowl when the cooking progress is over



Image 5.4: The inner pot features double handles, allowing it to be used as a serving bowl after cooking.

6. MAINTENANCE AND CLEANING

Regular cleaning ensures the longevity and optimal performance of your Olayks appliance.

6.1 Travel Steamer Cleaning:

1. Ensure the steamer is unplugged and completely cool before cleaning.
2. Empty any remaining water from the water tank.
3. Wipe the exterior of the steamer with a soft, damp cloth. Do not use abrasive cleaners or immerse the unit in water.
4. For mineral buildup in the nozzle, use a cotton swab dipped in white vinegar to gently clean the openings. Rinse with a small amount of distilled water.

6.2 Mini Rice Cooker Cleaning:

1. Unplug the rice cooker and allow it to cool completely.
2. Remove the inner pot and lid. Wash them with warm, soapy water using a soft sponge. Rinse thoroughly and dry completely.
3. Wipe the exterior of the main unit with a soft, damp cloth. Do not immerse the main unit in water.
4. Ensure all parts are dry before reassembling or storing.

6.3 Storage:

Store the appliance in a cool, dry place, away from direct sunlight and moisture. Use the provided travel bag for convenient and protected storage during travel.

7. TROUBLESHOOTING

If you encounter issues with your Olayks appliance, refer to the following common problems and solutions:

7.1 Steamer Troubleshooting:

- **No steam or weak steam:**
 - Check if the water tank is empty. Refill with distilled water.
 - Ensure the steamer is properly plugged into a working outlet.
 - Allow sufficient preheating time (15 seconds).
 - Check for mineral buildup in the steam nozzle. Clean as per maintenance instructions.
- **Water leaking from nozzle:**
 - Ensure the water tank cap is securely closed.
 - Avoid overfilling the water tank.

7.2 Rice Cooker Troubleshooting:

- **Cooker not turning on:**
 - Ensure the power cord is securely plugged into both the cooker and a working electrical outlet.
 - Check if the inner pot is correctly placed inside the main unit.
- **Rice not cooking properly (too hard/soft):**
 - Verify the correct water-to-rice ratio for the type of rice being cooked.
 - Ensure the lid is properly closed during cooking.
 - Select the appropriate cooking function for your ingredients.
- **Food sticking to the inner pot:**
 - Ensure you are using the correct amount of water.
 - Do not use metal utensils that could scratch the non-stick coating.

If problems persist, please contact Olayks customer support.

8. SPECIFICATIONS

Feature	Specification
Model Number	B0FNMB2G5K
Brand	Olayks
Voltage	100-120V (US, Canada, Japan regions)
Steamer Weight	1.1 lbs
Steamer Preheat Time	15 seconds
Steamer Continuous Steam Time	Up to 8 minutes
Steamer Water Tank Capacity	70ml
Rice Cooker Capacity	1.2L (2 cups uncooked rice, approx. 4 cups cooked)
Rice Cooker Functions	White Rice, Brown Rice, Porridge, Soup, Oatmeal, Grains
Rice Cooker Reservation Time	0.5 to 24 hours
Rice Cooker Keep Warm Time	Up to 24 hours
Date First Available	November 6, 2024

9. WARRANTY AND SUPPORT

All Olayks products undergo thorough pre-testing at the factory to ensure excellent quality and performance. Each unit is tested to confirm proper functionality before shipment. For any questions, concerns, or technical support regarding your Olayks Travel Steamer and Mini Rice Cooker, please contact Olayks customer service through the retailer's platform or the official Olayks website. Please have your model number (B0FNMB2G5K) and purchase information ready when contacting support.

© 2024 Olayks. All rights reserved.

Related Documents - B0FNMB2G5K

	<p>Olayks Sandwich Maker OLK-02-08 User Manual</p> <p>User manual for the Olayks Sandwich Maker model OLK-02-08, covering safety instructions, product overview, usage, cleaning, maintenance, troubleshooting, specifications, and warranty information.</p>
---	---

	<p>Olayks Multifunctional Food Processor - Product Manual</p> <p>User manual for the Olayks Multifunctional Food Processor (Model OLK-04-02), detailing product components, installation, features, usage methods, mixing guide, precautions, care and maintenance, and troubleshooting.</p>
	<p>Olayks CG206 Coffee Grinder: User Manual, Specifications, and Operation Guide</p> <p>Detailed user manual for the Olayks CG206 coffee grinder. Includes setup instructions, operating guide, grind size recommendations, cleaning procedures, troubleshooting tips, and product specifications. Learn how to use your coffee grinder for optimal results.</p>
	<p>Olayks Desktop Utensil Sterilizer: User Manual, Specifications, and Warranty</p> <p>Comprehensive user manual for the Olayks Desktop Utensil Sterilizer, covering product illustration, instructions for use, main specifications, maintenance, troubleshooting, environmental compliance, and warranty information.</p>