



[Manuals.plus](#) /

> [kleankin](#) /

> kleankin Pedestal Sink Storage Cabinet Model 834-574V80WT User Manual

kleankin 834-574V80WT

kleankin Pedestal Sink Storage Cabinet Model 834-574V80WT User Manual

Model: 834-574V80WT

Brand: kleankin

1. INTRODUCTION

This manual provides essential information for the assembly, operation, and maintenance of your kleankin Pedestal Sink Storage Cabinet, Model 834-574V80WT. This cabinet is designed to maximize storage in bathrooms with pedestal or wall-mounted sinks, offering a practical and elegant solution for organizing bathroom essentials.

The cabinet features a U-shaped cutout to fit neatly around your sink base, two doors, and an adjustable interior shelf for flexible storage. Please read these instructions thoroughly before assembly and use to ensure proper installation and longevity of your product.



This image displays the front of the white pedestal sink storage cabinet with its two doors closed, featuring black handles and a U-shaped cutout on the top surface for a sink.

2. SAFETY INFORMATION

WARNING: This product contains chemicals known to the State of California to cause cancer, birth defects, or other reproductive harm. (California Proposition 65 warning)

- Ensure all parts are present and undamaged before assembly. Do not proceed with assembly if any parts are missing or damaged.
- Keep small parts away from children during assembly to prevent choking hazards.
- Assemble the cabinet on a soft, clean surface to prevent scratches.
- Do not overtighten screws, as this may damage the material.
- Always use the provided anti-tipping hardware to secure the cabinet to the wall, especially if children or pets are present.

3. PACKAGE CONTENTS

Please verify that all components listed below are included in your package:

- Cabinet Panels (Top, Bottom, Sides, Back)
- Cabinet Doors (2)
- Adjustable Shelf (1)
- Hardware Pack (screws, dowels, hinges, handles, shelf pins, anti-tipping kit)
- User Manual

4. SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of this cabinet is required. Please follow the detailed instructions provided in the included user manual for step-by-step guidance. Below are general guidelines and important considerations:

1. **Pre-Assembly Check:** Before beginning, measure your sink base to ensure compatibility with the cabinet's U-shaped cutout. The cutout dimensions are 8.7" W x 7.9" D. The cabinet is suitable for wash basins with a width of 23.6" and basins over 60 cm (23.6") in height.
2. **Unpack and Identify:** Carefully unpack all components and lay them out on a protected surface. Identify each part using the diagrams in the assembly manual.
3. **Assemble Frame:** Begin by assembling the main frame of the cabinet according to the numbered steps in the manual, ensuring all connections are secure.
4. **Install Shelf:** Insert the shelf pins into the desired height adjustment holes for the adjustable shelf. Place the shelf onto the pins.
5. **Attach Doors:** Secure the hinges to the cabinet doors and then attach the doors to the cabinet frame. Install the handles.
6. **Position Cabinet:** Carefully slide the assembled cabinet under your pedestal or wall-mounted sink, aligning the U-shaped cutout with the sink base.
7. **Secure Cabinet:** Use the provided anti-tipping hardware to secure the cabinet to the wall, preventing accidental tipping.



This diagram illustrates the overall dimensions of the cabinet: 23.6 inches width, 11.8 inches depth, and 23.6 inches height, along with the U-cutout dimensions.



Sink with Pedestal



Sink without Pedestal

This image demonstrates how the cabinet fits around both pedestal sinks and wall-mounted sinks, highlighting the U-shaped cutout for the pedestal.

NOTE :

- ① Fits basins **over 60 cm** height
- ② Measure under-basin space before buying



This graphic advises that the cabinet fits basins over 60 cm in height and emphasizes measuring the under-basin space before purchase to ensure proper fit and to account for any visible distance between the cabinet top and the basin.

Your browser does not support the video tag.

This video provides a visual overview of the kleankin Pedestal Sink Storage Cabinet, showcasing its U-shaped cutout design, interior storage capacity, and the adjustable shelf feature. It demonstrates how the cabinet fits around a pedestal sink and offers practical storage solutions for bathroom items.

5. OPERATING INSTRUCTIONS

The kleankin Pedestal Sink Storage Cabinet is designed for straightforward use:

- **Accessing Storage:** Open the two front doors to access the interior storage compartments.
- **Adjustable Shelf:** The interior shelf can be adjusted to different heights to accommodate items of various sizes. To adjust, remove the shelf pins, reposition them to the desired holes, and place the shelf back on the pins. This allows for customized storage of towels, cleaning supplies, toiletries, and more.
- **Maximizing Space:** Utilize the space around the sink pedestal for items that fit the U-shaped cutout, and the shelf for smaller items.

FIT WHATEVER YOU NEED

An adjustable shelf inside to meet your ever-changing storage needs



This image shows how the interior shelf can be adjusted up or down by 1.3 inches, allowing for flexible storage configurations.

6. MAINTENANCE

To ensure the longevity and appearance of your cabinet, follow these maintenance guidelines:

- **Cleaning:** Wipe the cabinet surfaces with a soft, damp cloth. Avoid using abrasive cleaners, harsh chemicals, or solvents, as these can damage the painted finish.
- **Spills:** Promptly wipe up any water spills or moisture to prevent damage to the particle board material. The painted finish offers resistance to water splashes, but prolonged exposure to moisture should be avoided.
- **Hardware:** Periodically check all screws and fasteners to ensure they remain tight. Retighten if necessary.
- **Placement:** Ensure the cabinet is placed on a level surface to maintain stability and prevent stress on the joints.

7. TROUBLESHOOTING

If you encounter any issues with your kleankin Pedestal Sink Storage Cabinet, consider the following

common solutions:

- **Cabinet Does Not Fit:** Double-check your sink base measurements against the product specifications (U-cutout dimensions: 8.7" W x 7.9" D; suitable for wash basin width: 23.6"; basin height over 60 cm). Ensure the cabinet is positioned correctly.
- **Instability/Wobbling:** Verify that all assembly screws are securely tightened. Ensure the cabinet is placed on a flat, level surface. If applicable, confirm the anti-tipping hardware is properly installed and secured to the wall.
- **Doors Not Closing Properly:** Check the alignment of the hinges. Adjust if necessary. Ensure no items inside the cabinet are obstructing the doors.
- **Damaged Parts:** If any parts were damaged during shipping or assembly, contact customer support for replacements.

8. SPECIFICATIONS

Feature	Specification
Brand	kleankin
Model Name	Bathroom Sink Cabinet
Model Number	834-574V80WT
Color	White
Material	Engineered Wood
Overall Dimensions (D x W x H)	11.8" x 23.6" x 23.6"
U-Cut-Out Dimensions (W x D)	8.7" x 7.9"
Suitable Wash Basin Width	23.6"
Weight Capacity (Total)	44 lbs
Weight Capacity (Shelf)	11 lbs
Number of Shelves	1 (Adjustable)
Mounting Type	Floor Mount
Installation Type	Freestanding
Assembly Required	Yes
Item Weight	19.8 lbs

9. WARRANTY AND SUPPORT

For warranty information, product support, or to inquire about replacement parts, please contact the manufacturer, Aosom LLC, or your original retailer. Keep your purchase receipt and model number (834-574V80WT) handy for faster service.

