

[Manuals.plus](#) /

› [Huuger](#) /

› Huuger Nightstand Set of 2 with Charging Station Instruction Manual

Huuger Nightstand Set of 2 with Charging Station

Huuger Nightstand Set of 2 with Charging Station Instruction Manual

Model: Nightstand Set of 2 with Charging Station

INTRODUCTION

Thank you for choosing the Huuger Nightstand Set of 2 with Charging Station. This manual provides essential information for the safe assembly, operation, and maintenance of your new nightstands. Please read these instructions carefully before beginning assembly and retain them for future reference.



Image: Fully assembled Huuger Nightstand with a charging station, phone, and decorative items on top, and two fabric drawers below.

SAFETY INFORMATION

- Ensure all parts are present and undamaged before assembly. Do not use if any parts are missing or broken.
- Assemble on a soft, clean surface to prevent scratches.
- Do not overtighten screws during assembly to avoid damaging the material.
- Keep small parts away from children during assembly.
- Do not exceed the weight capacity of the tabletop or shelves.
- Only use the integrated charging station for compatible electronic devices. Do not overload the outlets.
- Keep liquids away from the charging station to prevent electrical hazards.

PACKAGE CONTENTS

Your package should contain all necessary components for assembling two nightstands. Please verify all parts against the included parts list in your physical instruction manual.

The X-shaped side rails provide structural stability and prevent items from falling off the sides.

X-Shaped Side Rail



Elegant & Practical, Prevents Falls

Image: Detail of the X-shaped side rail, highlighting its design and function.

OPERATING INSTRUCTIONS

Charging Station Usage


The integrated charging station features 2 AC outlets, 1 USB port, and 1 Type-C port with a 4.9ft power cord. This allows for convenient charging of multiple devices directly from your nightstand.

- Plug the nightstand's power cord into a standard wall outlet.
- Connect your electronic devices to the available AC outlets, USB port, or Type-C port.
- Ensure devices are compatible with the charging station's output specifications.

Meet All Charging Needs



2 AC Outlets



1 USB Port



1 USB-C Port

Image: The charging station on the nightstand's top surface, actively charging a smartphone, smartwatch, and tablet.

Drawer and Shelf Storage

The nightstand includes two fabric drawers and an open shelf for organized storage. The tabletop provides ample space for lamps, books, or beverages.

- Use the fabric drawers for discreet storage of personal items, remotes, or charging cables.
- The open shelf is suitable for books, decorative items, or frequently accessed essentials.



Image: The nightstand with its fabric drawers partially open, revealing storage space, and various items placed on the tabletop and open shelf.

MAINTENANCE AND CARE

To ensure the longevity and appearance of your Huuger Nightstand, follow these care guidelines:

- **Cleaning:** The wood-grain top surface is water-resistant and easy to clean. Wipe spills immediately with a dry cloth. For general cleaning, use a soft, damp cloth and mild detergent. Avoid abrasive cleaners.
- **Dusting:** Regularly dust all surfaces with a soft, dry cloth.
- **Drawer Care:** The fabric drawers can be spot cleaned with a damp cloth. Do not machine wash.
- **Stability:** Periodically check all screws and connections to ensure they remain tight. Adjust the leveling feet as needed to maintain stability on uneven floors.



Image: Close-up of water droplets on the nightstand's surface, illustrating its water-resistant and easy-to-clean properties.

TROUBLESHOOTING

- **Wobbly Nightstand:** Check that all screws are tightened. Adjust the leveling feet at the bottom of the legs to compensate for uneven floor surfaces.
- **Charging Station Not Working:** Ensure the power cord is securely plugged into both the nightstand and a functional wall outlet. Verify that your devices are properly connected and compatible with the charging station. Avoid overloading the outlets.
- **Drawers Not Sliding Smoothly:** Ensure the fabric drawers are correctly inserted and not obstructed. Check for any debris in the drawer slots.
- **Missing Parts:** If any parts are missing upon arrival, please contact Huuger customer support immediately.

SPECIFICATIONS

Brand	Huuger
Product Dimensions	11.81"D x 15.75"W x 23.6"H
Item Weight	8.94 kg
Frame Material	Metal
Top Material Type	Engineered Wood
Color	Oak
Number of Drawers	2
Charging Station	2 AC Outlets, 1 USB Port, 1 Type-C Port
Power Cord Length	4.9 ft
Special Features	Waterproof top, Adjustable Feet

WARRANTY INFORMATION

Huuger products are manufactured with quality and durability in mind. This product comes with a standard manufacturer's warranty covering defects in materials and workmanship. Please refer to the warranty card included in your product packaging for specific terms, conditions, and duration of coverage. Keep your proof of purchase for warranty claims.

CUSTOMER SUPPORT

For any questions, concerns, or assistance with your Huuger Nightstand, please contact our customer support team. You can find more information and contact details by visiting the official Huuger Store:

[Visit the Huuger Store](#)

Please have your model number (Nightstand Set of 2 with Charging Station) and ASIN (B0FNMJ6BDM) ready when contacting support.

ASK A QUESTION ABOUT THIS MANUAL

Ask about setup, troubleshooting, compatibility, parts, safety, or missing instructions. Manuals+ will review the question and use this page's manual context to help answer it.

Name

Anonymous

Email

you@example.com

After a successful submission, we securely hash the supplied account or form email before sending it to Microsoft Advertising for conversion attribution. [Privacy details](#).

Question

Example: How do I reset this device or fix this error?

Details

Model number, symptoms, what you tried, or the section of the manual you are using.

Submit question