

Manuals+

[Q & A](#) | [Deep Search](#) | [Upload](#)

[manuals.plus](#) /

› [Bellemave](#) /

› [Bellemave Full Over Full Bunk Bed Instruction Manual](#)

Bellemave Full Over Full Bunk Bed

Bellemave Full Over Full Bunk Bed Instruction Manual

Model: Full Over Full Bunk Bed

PRODUCT OVERVIEW

This manual provides detailed instructions for the assembly, operation, and maintenance of your Bellemave Full Over Full Bunk Bed. This versatile bed features a robust metal construction with a walnut-finished headboard, designed to offer a space-saving solution for your home. It can be configured as a traditional full-over-full bunk bed, or separated into a full-size loft bed and a full-size platform bed.

Please read all instructions carefully before assembly and use to ensure safe and proper operation.

IMPORTANT SAFETY INFORMATION

- Always follow the assembly instructions carefully to prevent instability or collapse.
- Do not exceed the weight capacity: **Upper Bed: 350 lbs, Bottom Bed: 500 lbs.**
- Be cautious of sharp edges during assembly and use.
- Ensure guardrails and headboard are securely attached to prevent injury.
- Keep the area around the bunk bed clear to prevent tripping or falling.
- This product is certified by the Children's Product Certification (CPC).
- Only use mattresses that comply with the recommended dimensions for full-size beds.
- Periodically check all connections and tighten hardware as needed.

PACKAGE CONTENTS

Your Bellemave Full Over Full Bunk Bed will arrive in two separate boxes. Please verify that all components listed in the assembly guide (not included in this document but typically provided with the product) are present and undamaged before beginning assembly. Common components include:

- Bed frames (upper and lower)
- Headboards
- Guardrails

- Ladder
- Slats for both beds
- All necessary hardware (screws, bolts, nuts, etc.)
- Assembly tools (usually an Allen wrench)

Note: If any parts are missing or damaged, please contact customer support immediately.

SETUP AND ASSEMBLY INSTRUCTIONS

Assembly of the Bellemave Full Over Full Bunk Bed requires two adults and approximately 1-2 hours. Ensure you have ample space and all parts are accounted for before beginning. Detailed step-by-step instructions with numbered parts are included in the product packaging.

Assembly Video Guide

Your browser does not support the video tag.

Video demonstrating the assembly process for the Bellemave Full Over Full Bunk Bed. This video provides a visual guide to complement the written instructions.

Key Assembly Steps (Visual Aids)



Step 1: Begin by assembling the lower bed frame components, including the headboard and side rails. Secure all connections with the provided hardware.



Step 3: Assemble the upper bed frame, including its headboard and side rails, and carefully lift it onto the vertical support posts. Secure all connections.



Step 4: Install the metal slats onto both the upper and lower bed frames. Ensure each slat is properly seated and secured according to the instructions. Finally, attach the ladder and guardrails.

OPERATING INSTRUCTIONS

Your Bellemave Full Over Full Bunk Bed offers flexible configurations to suit your needs. It can be used as a traditional bunk bed or separated into a loft bed and a platform bed.

Standard Bunk Bed Configuration

In its standard configuration, the bed functions as a full-over-full bunk bed, providing two sleeping surfaces while maximizing floor space. Ensure the ladder is securely attached for safe access to the upper bunk, and that all guardrails are in place.



The Bellemave Full Over Full Bunk Bed in its traditional stacked arrangement.

Convertible Configurations

The bunk bed can be separated into two independent beds: a full-size loft bed and a full-size platform bed. This allows for greater flexibility in room arrangement and usage.

- **Loft Bed:** The upper bunk can be used as a standalone loft bed, providing space underneath for a desk, seating, or storage.
- **Platform Bed:** The lower bunk can be used as a separate full-size platform bed.

To convert the bed, carefully disassemble the connecting components between the upper and lower bunks, following the reverse steps of the assembly guide. Ensure all parts are stored safely if not in use.



The bunk bed disassembled into a loft bed and a separate platform bed, offering versatile room layouts.

Product Features Overview

Your browser does not support the video tag.

Video showcasing the features and design of the Bellemave Full Over Full Bunk Bed in Walnut, including its convertible nature.

MAINTENANCE

Regular maintenance will help prolong the life and ensure the safety of your bunk bed.

- **Cleaning:** Wipe down metal surfaces with a soft, damp cloth. Avoid abrasive cleaners or harsh chemicals that could damage the finish. For the wooden headboard, use a wood-safe cleaner or a damp cloth.
- **Hardware Check:** Periodically (e.g., every 3-6 months) inspect all bolts, screws, and connections. Tighten any loose hardware to maintain stability and prevent squeaking.
- **Structural Integrity:** Check for any signs of wear, damage, or bending in the metal frame or slats. If any damage is found, discontinue use and contact customer support for replacement parts or advice.
- **Mattress Care:** Ensure mattresses are of appropriate size and thickness for the bunk bed. Rotate and flip

mattresses regularly according to their manufacturer's recommendations.

TROUBLESHOOTING


Problem	Possible Cause	Solution
Bed feels wobbly or unstable	Loose hardware connections. Uneven floor surface.	Tighten all bolts and screws. Ensure the bed is placed on a level surface; use shims if necessary.
Squeaking noises	Loose connections. Friction between metal parts.	Tighten all hardware. Apply a small amount of lubricant (e.g., silicone spray) to connection points if tightening does not resolve the issue.
Difficulty assembling parts	Incorrect orientation of parts. Missing or damaged hardware.	Refer to the detailed assembly guide and ensure parts are oriented correctly. Verify all hardware is present. Contact customer support if parts are missing or damaged.

If you encounter any issues not listed here or require further assistance, please contact Bellemave customer support at US-VC@bellemavehome.com.

SPECIFICATIONS

Brand	Bellemave
Model Number	Full Over Full Bunk Bed
Size	Full
Material	Metal (Frame), Wood (Headboard)
Product Dimensions (L x W x H)	77.6" x 59.1" x 59.1"
Item Weight	57 Pounds
Upper Bed Weight Capacity	350 lbs
Bottom Bed Weight Capacity	500 lbs
Compatible Mattress Size	Full
Assembly Required	Yes

UNIT:INCH



Detailed dimensions of the Bellemave Full Over Full Bunk Bed.

WARRANTY AND SUPPORT

For warranty information, please refer to the documentation included with your purchase or contact Bellemave customer support directly. Bellemave offers a 90-day easy return policy through Amazon.

For any questions, concerns, or assistance with your product, please reach out to our customer support team:

Email: US-VC@bellemavehome.com